

AX Series Motion Controller Instructions Manual



www.deltaww.com

Revision History

AXSeries-MotionControllerManual

Version	Revision	Date
1 st	The first version was published.	2020/03/31
2 nd	 Updated Sections 2.1.1 ~ 2.1.18, 2.2.1 ~ 2.2.16, 2.3.1.1 ~ 2.3.1.9, 2.3.1.11, 2.3.2.1 ~ 2.3.2.2, and 2.3.2.5 ~ 2.3.2.22: Added supported product AX-364E Updated Sections 2.3.1.1, 2.3.1.3 ~ 2.3.1.8, 2.3.2.1 ~ 2.3.2.2, 2.3.2.5 ~ 2.3.2.11, and 2.3.2.15 ~ 2.3.2.16: Updated ErrorID Added Sections 2.3.1.10, 2.3.1.12, 2.3.1.13, and 2.3.2.3 ~ 2.3.2.4 Updated Section 2.3.1.11: Updated blnVelocity and bDone Updated Section 2.3.2.6: Updated GroupErrorID Updated Section 2.3.2.12: Updated dwErrorID Updated Sections 2.3.3.1 ~ 2.3.3.16: Removed supported product AX-8 and added supported product AX-364E Updated Appendix A1: Added DMC_ImmediateStop_P, DMC_GroupInterrupt, _GroupContinue, DMC_GroupWriteParameter Updated Appendix A2: Updated DMC_GROUP_TRANSITION_MODE Added DMC_GROUP_PARAMETER Updated Appendix A.3.1 Updated Appendix A.3.2 	2021/02/28

Table of Contents

Preface	3
P.1 Introduction P.1.1 Applicable Products	4
P.1.2 Associated Manuals	4
Chapter 1 Introduction to Motion Control	5
1.1 Introductions of Motion Control	6
1.1.1 Basic Knowledge on Motion Control Instructions	6
1.2 Categories of Motion Control Instructions	9
Categories	9
Type	9
Function Group	99
Positioning on single axis	9
Administrative	9
Administrative functions on single axis	9
Motion	9
Administrative	9
Chapter 2 Motion Control Instruction	10
2.1 Motion Control Instructions	
2.1.1 MC_Home	11
2.1.2 MC_Stop	
2.1.3 MC_Halt	
2.1.4 MC_MoveAbsolute	22
2.1.5 MC_MoveRelative	
2.1.6 MC_MoveAdditive	
2.1.7 MC_MoveSuperImposed	
2.1.8 MC_CamIn	
2.1.9 MC_CamOut	64
2.1.10 MC_MoveVelocity	69
2.1.11 MC_PositionProfile	74
2.1.12 MC_VelocityProfile	79
2.1.14 MC_Jog	
2.1.15 MC_GearIn	92
2.1.16 MC_GearOut	96
2.1.17 MC_GearInPos	101
2.1.18 MC_Phasing	107
2.2 Administrative Motion Control Instructions	
2.2.1 MC_Power	113

2.2.2 MC_SetPosition	119
2.2.3 MC_ReadParameter	126
2.2.4 MC_WriteParameter	129
2.2.5 MC_ReadBoolParameter	132
2.2.6 MC_WriteBoolParameter	135
2.2.7 MC_ReadActualPosition	137
2.2.8 MC_ReadActualVelocity	140
2.2.9 MC_ReadActualTorque	143
2.2.10 MC_Reset	145
2.2.11 MC_ReadStatus	148
2.2.12 MC_ReadAxisError	153
2.2.13 MC_CamTableSelect	156
2.2.14 MC_TouchProbe	161
2.2.15 MC_AbortTrigger	168
2.2.16 MC_DigitalCamSwitch	172
2.3 Delta Motion Control Instructions	180
2.3.1 Motion Control Instructions	180
2.3.2 Administrative Instructions	252
2.3.3 Positioning Axis Instructions	359
Appendix A 410	

A.1.Instruction Tables and Indexes	
A.1.1 By Function	411
A.1.2 By Model	416
A.1.3 By Letter	
A.2 Data Type: Enumeration and Structure	
A.3 Error Codes and Troubleshooting	
A.3.1 For Synchronous Axes	
A.3.2 For Positioning Axis	
A.4 Explanation of DMC_Home_P	

Preface

P.1 Introduction

Thank you for purchasing AX series Motion Controller with our advanced motion control system. Delta's AX series motion controller based on COSESYS intergrates the control function of PLCs and motion controllers into one platform.

This manual introduces PLCOpen standard motion control instructions and Delta-defined instructions including single-axis, multi-axes instructions and motion control applications.

Please ensure that you fully understand the configuration and operations of the AX series motion control system, and use the AX series Motion Controller CPU correctly.

P.1.1 Applicable Products

This manual relates to the following products

- AX-3 series/ AX-8 series

P.1.2 Associated Manuals

The related manuals of the AX Motion Controller series are composed of the following.

1. DIADesigner-AX User Manual

Contents include the use of DIADesigner-AX, the programming languages (ladder diagrams, sequential function charts, function block diagrams, and structured texts), the concept of POUs and Task, and the operation of motion control programming.

2. AX-3 Series Operational Manual

It introduces basic knowledge of motion control structure, software/hardware setup, quick start of Software operations, devices to be used, motion control operations, troubleshooting, Input/ Output modules, modules of temperature measurement and etc.

3. AX-8 Series Operational Manual

It introduces basic knowledge of motion control structure, software/hardware setup, quick start of Software operations, devices to be used, motion control operations, troubleshooting, Input/ Output modules, modules of temperature measurement and etc.

Chapter 1 Introduction to Motion Control

1.1 Introductions of Motion Control

This manual introduces the elements for motion control programming including devices, symbols and motion control instructions.

Motion control instructions are defined as function blocks (FB) and are used in the program for performing a variety of motion control purposes. The motion control (MC) instructions are developed based on the specifications of PLCopen* motion control function blocks. In addition to the PLCopen-based instructions, Codesys also provides Delta-defined function blocks for users to achieve complete motion control applications.

This section gives an overview of the motion control instructions for both PLCopen-based function blocks and Delta-defined function blocks. PLCopen defines the program and function block interfaces so as to achieve a standardized motion control programming environment for the languages specified in IEC61131-3. Using PLCopen-based instructions together with Delta-defined instructions reduces the costs for training and support.

Before using the instructions, please be sure that you understand the devices, symbols and the function of instructions sufficiently.

You can also refer to the Appendices for a quick reference of the motion control instruction list and error codes.

*Note:

PLCopen is an organization promoting industrial control based on IEC61131-3, which is an international standard widely adopted for PLC programming. For more information regarding PLCopen, check the official website at: <u>http://www.plcopen.org/</u>

1.1.1 Basic Knowledge on Motion Control Instructions

Using motion control instructions requires the basic knowledge of motion control defined in the specifications of PLCopen motion control function blocks. This section provides an overview of these specifications.

Name of Motion Control Instructions

PLCopen-based motion control instructions begin with "MC_", while Delta-defined function block instructions begin with "DFB_".

Туре	Description		
MC_	PLCopen-based motion control instructions		
DMC_	Delta-defined function block instructions*		

***Note:** Delta-defined function block instructions (DFB) include Delta-defined motion control function blocks and other administrative/non-administrative function blocks which are applicable for AH Motion series CPUs. Therefore you can look up a function block (FB) in this manual.

• Types of Motion Control Related Instructions

Different categories of motion control instructions are divided by functions such as single-axis motion instructions. Refer to Ch2 Motion Control Instructions for more details.

• Execution of a Function Block

Function block instructions generally include two types of inputs for execution: Execute and Enable. When the instruction is executed or enabled, the outputs of the function block can indicate the status. The basic outputs include Busy, Done, CommandAborted, and Error. For

detailed information of inputs and outputs of each function block, refer to Ch2 Motion Control Instructions.

Error Handling

Information regarding error codes, indicators and troubleshooting are set out in Appendice A for a quick reference.

• Re-execution of a Function Block

Re-execution of a function block refers to triggering Execute again after resetting it. You can change the input values and trigger Execute again while the function block is during operation (in busy status). Such output status would remain unchanged (in busy status) which also means the previous executed instruction would be aborted by Aborting of buffer mode.

• Multi-execution of Multiple Motion Control Instructions

Multi-execution of motion control instructions refers to that multiple instructions on the same axis are executed in the same task execution period. The pattern of multi-execution is defined by the input variable BufferMode which is specified to blend the two motions. Therefore, the instruction at the back will determine the behavior of the previous instruction according to BufferMode. Please refer to AX-3 Series Operation Manual for more details.

Buffer Modes

Some motion instructions have an input called BufferMode.You can execute a different instruction instance during axis motion when the values for BufferMode are specified.This input decides whether the instruction executes immediately (non-buffered mode) or it waits till current motion instruction sets its status outputs

(Done/InVelocity/InPosition, etc.)

BufferMode determines the behavior to combine the axis motions for this instruction and the previous instruction. When the instruction is executed;

- The selected buffer mode is valid if the previous instruction is executing.
- The selected buffer mode is invalid if the axis is in Standstill state.
- The following Buffer Modes are supported.

Buffer Mode	Function		
0 : Aborting	Aborts the ongoing motion. The next instruction takes effect immediately.		
1 : Buffered Automatically executes the next instruction after the ongoing motion completed.			
2 : BlendingLow	Takes the lower target velocity as the transit velocity between the current instruction and the buffered instruction. (The transit velocity is the velocity that the current instruction uses as the transit point.)		
3 : BlendingPrevious	Takes the target velocity of the current instruction as the transit velocity.		
4 : BlendingNext	Takes the target velocity of the buffered instruction as the transit velocity.		
5 : BlendingHigh	Takes the higher target velocity as the transit velocity between the current instruction and the buffered instruction.		

Please refer to AX-3 Series Operation Manual for more details of buffer mode.

• Structure Applicable for Motion Control

In PLCopen technical standard, the information and parameters required for configuring motion control on axis are defined in a Structure.

For AX Motion CPUs, a Structure is a data type applicable to group the data elements together, which is easier for users to specify proper parameters.

For AX Motion CPUs, the applicable Structure is as below:

MC ReadStatus 0 TRUE MC ReadStatus ┨╟ EN ENO Axis SM_Drive_ETC_Delta_ASDA A2 Valid Enable Busy Error ErrorID VAR_IN_OUT MC_ReadStatus.Axis : AXIS_REF_SM3 Reference to axis Disabled Errorstop Stopping StandStill DiscreteMotion ContinuousMotion SynchronizedMotion Homing ConstantVelocity Accelerating Decelerating FBErrorOccured

Single-axis Function Block

For single-axis FB, the applicable Structure is AXIS_REF_SM3 °

Function Block for Axis Group

oupReadStatus_0	DMC_Gr
roupReadStatus	TRUE DMC_G
ENO	EN
bValid	DMC_Axis_Group
bBusy	-bEnable
bError	
ErrorID	VAR_IN_OUT DMC_GroupReadStatus.AxisGroup : DMC_AXIS_GROUP_REF
bGroupMoving	
bGroupHoming	
bGroupErrorStop	
bGroupStandby	
bGroupStopping	
bGroupDisabled	
bConstantVelocity	
bAccelerating	
bDecelerating	
bInPosition	

For AxisGroup FB, the applicable Structure is DMC_AXIS_GROUP_REF °

Note: For more details, please find Appendix A.2 Data Types: Enumeration and Structure.

1.2 Categories of Motion Control Instructions

For AX Motion CPUs, motion control instructions are divided into two categories based on PLCOpen.

Categories	Туре	Function Group	Description	
	Motion	Positioning on single axis	"SMC": Motion instructions	
		Velocity control on single axis		
Single-axis motion control instructions		Torque control on single axis	"MC_": PLCopen motion control	
		Synchronized control on single axis	Difference instructions "DMC_": Delta-defined motion	
	Administrative	Administrative functions on single axis	control instructions	
Multi-axis motion control	Motion	Multi-axis coordinated control	Performing coordinated movement of an axis group	
instructions Motion modules	Administrative	Administrative functions on multi axis	Controlling, monitoring or resetting axis group status.	

Chapter 2 Motion Control Instruction

2.1 Motion Control Instructions

Motion control instructions are generally used to control motors on performing specific movement after the specified instruction being executed. The function blocks used in this chapter are from the library "SM3_Basic" and able to operate synchronously with drives. As a result, synchronous axis type should be selected in axis settings. For more details about configuration related to synchronous axes, please refer to section 7.4 in AX-3 Series Operational Manual.

2.1.1 MC_Home

MC_Home controls the axis to perform the homing operation.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Home	MC_Home Axis AXIS_REF_SM3 BOOL Done Execute BOOL Busy Position LREAL BOOL CommandAborted BOOL Error SMC_ERROR ErrorID	MC_Home_instance (Axis :=, Execute:=, Position:=, Done =>, Busy =>, CommandAborted =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting value (Default value)	Timing for updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
Position	Specifies the set position. (Unit: user unit)	LREAL	Negative number, positive number, or 0 (0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output range (Default value)
Done	True when homing is completed.	BOOL	True/False(False)
Busy	True when the instruction is executed	BOOL	True/False(False)

Name	Function	Data Type	Output range (Default value)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Outputs Update Timing

Name	Timing for shifting to True	Timing for shifting to False	
Done	 When the homing is completed. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	 When Execute changes to True. 	 When Done shifts to True. When Error shifts to True. When CommandAborted shifts to True. 	
CommandAborted	 When this instruction is aborted by another instruction. When this instruction is aborted by MC_Stop. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 	
Error	When an error occurs in the		
ErrorID	execution conditions or input values for the instruction.(Error code is recorded)	• When Error code is cleared.	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute is rising edge triggered and Busy is False.

***Note**: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- When Execute changes to True, the homing operation starts to be performed on the axis specified in Axis.
- Position is to specify the set position for homing.
- In case the MC_Home command is interrupted by MC_Stop and

xWaitForHaltWhenStopInterruptsHome is TRUE, MC_Stop has to wait till the driver reaches velocity zero before setting Done. Instead, if xWaitForHaltWhenStopInterruptsHome is FALSE, .Done will shift to true once MC_Stop interrupts MC_Home.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

Example 1: Explain on how to perform homing by using MC_Home and setting homing mode on parameter configuration page with the software DIAdesigner-AX.



Timing Diagram



■ Use MC_Home with the following parameters:

Homing mode Speed during search for switch		Speed during search for zero	Homing acceleration
33	100	50	100

The above parameters can be configured on the Homing Setting page:

General Setting Commissioning Homing Setting	Homing Mode Mode 33 Homing speed during search for switch 100 Homing speed during search for z phase pulse 50 Homing Acceleration 100
IEC Objects	Description
Status	Mode 33 : Depending on Z pulse in the negative direction
Information	In mode 33, The homing instruction is executed and the axis moves at the second-phase speed (Homing speed during search for Z phase pulse) in the negative direction. And the place where the axis stands is the home position once the first Z pulse is met.
	0
	Stop point Negative direction
	Z pulse

After MC_Home being executed, the axis would move in the negative direction till finds Z phase pulse. And the place where the axis stands is the home position once the first Z pulse is met.

- Supported Products
 - AX-308E, AX-8, AX-364E

2.1.2 MC_Stop

MC_Stop decelerates an axis to a stop.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Stop	MC_Stop – Axis <i>AXIS_REF_SM3 BOOL</i> Done – – Execute <i>BOOL</i> Busy – – Deceleration <i>LREAL BOOL</i> Error – – Jerk <i>LREAL SMC_ERROR</i> ErrorID –	MC_Stop_instance (Axis :=, Execute :=, Deceleration :=, Jerk :=, Done =>, Busy =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
Deceleration	Deceleration rate (Unit: user unit/s2)*	LREAL	Positive number or 0(0)	When Execute is rising edge triggered, the rate would be updated.
Jerk	Jerk value (Unit: user unit/s3)*	LREAL	Positive number or 0(0)	When Execute is rising edge triggered, the value would be updated.

Outputs

Name	Function	Data Type	Output Range (Default Value)	
Done	True when zero velocity is reached.	BOOL	True/False(False)	
Busy	True when the instruction is executed.	BOOL	True/False(False)	
Error	True when an error occurs.	BOOL	True/False(False)	
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)	

Name	Function	Data Type	Output Range (Default Value)
	descriptions.		

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for shifting to True	Timing for shifting to False	
Done	• True when the axis decelerates to a stop and reaches zero velocity.	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	• True when Execute shifts to True.	When Done shifts to True.When Error shifts to True.	
Error	• When an error occurs in the	When Execute shifts from True to	
ErrorID	values for the instruction.	False.(Error code is cleared)	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute is rising edge triggered and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- You can specify the deceleration rate when decelerating the moving axis to a stop. Also, State Machine will be stopping.
- When MC_Power is False during deceleration, the motor is in Free Run state.
- The Done output is set to True when axis has reached velocity zero. At the same time, the input Execute changes to False, while State Machine in stopping state changes to

standstill.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

The example below shows the behavior and position tracking when MC_Stop is executed after MC_MoveVelocity.



Timing Diagram



- When Execute of MC_Stop changes to True, it triggers CommandAboted of MC_MoveVelocity at the same time and the motion controller starts to decelerate the axis to a stop. The Axis state is moved to the "Stopping".
- When the axis reaches zero velocity, the Done output will change to True. Execute is still True so the axis state remains in the state "Stopping". After the stop is finished and Execute is false, the axis will change to Standstill.
- In case MC_MoveVelocity is executed again while the axis state is "Stopping", an error will be reported. (Error Code: SMC_AXIS_NOT_READY_FOR_MOTION)

• Supported Products

AX-308E, AX-8, AX-364E

2.1.3 MC_Halt

MC_Halt commands a controlled axis motion stop.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Halt	MC_Halt Axis AXIS_REF_SM3 BOOL Done Execute BOOL BOOL Busy Deceleration LREAL BOOL CommandAborted Jerk LREAL BOOL Error SMC_ERROR ErrorID	MC_Halt_instance (Axis :=, Execute :=, Deceleration :=, Jerk :=, Done =>, Busy =>, CommandAborted =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
Deceleration	Deceleration rate. (Unit: user unit/s2)	LREAL	Positive number or 0 (0)	When Execute shifts to True, the rate will be updated.
Jerk	Jerk value. (Unit: user unit/s3)	LREAL	Positive number or 0 (0)	When Execute is rising edge triggered, the value would be updated.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when zero velocity is reached.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for shifting to True	Timing for shifting to False
Done	 When the axis decelerates to a stop and reaches zero velocity. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	 When Execute shifts to True. 	 When Done shifts to True. When Error shifts to True. When CommandAborted shifts to True.
CommandAborted	• When this instruction is aborted because of other function blocks.	 When Execute shifts from True to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False.
Error	• When an error occurs in the	• When Execute shifts from True
ErrorID	input values for the instruction.	to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting value (Default value)	Timing for updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute is rising edge triggered and Busy is False

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- Any next motion command can be executed when MC_halt is in Standstill mode (opposite to MC_Stop, which cannot be interrupted by other motion FBs.).
- When MC_Halt is executed, the axis will enter the discrete_motion state. Once the axis reaches zero, the axis state would transfer to Standstill.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

- The example below shows the behavior and position tracking when MC_Halt is executed after MC_MoveVelocity.
- The MC_Halt stops MC_MoveVelocity if there is no another instruction executed before the axis enters "Standstill" state.I".
- If MC_MoveVelocity executes again during the deceleration, it will abort MC_Halt immediately and accelerate again without entering "Standstill" state. This re-execution behavior is allowed for MC_Halt but not allowed iMC_Stop.



300 Velocity MC_MoveVelocity Execute InVelocity Busy CommandAborted Error MC_Halt Execute Done Busy CommandAborted Error continuous motion(5) discrete motion(4) standstill(3) State Machine

Timing Diagram

- When Execute of MC_Halt changes to True, it triggers CommandAborted of MC_MoveVelocity at the same time and the motion controller starts to decelerate the axis to a stop. The Axis state is moved to the "DiscreteMotion".
- When the axis reaches zero velocity, Done will change to True. The axis state will transfer to "Standstill".
- In case MC_Halt is not decelerating the axis to zero velocity and Execution is True, the Execute input of MC_MoveVelocity will change to True again and stop MC_Halt. Which CommandAboted will change to True with the axis state transferred from discrete_motion to continuous_motion.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.4 MC_MoveAbsolute

 $\mathsf{MC}_\mathsf{MoveAbsolute}$ controls the axis to move to the specified absolute target position at a specified behavior.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_MoveAbsolute	Axis XXIS_REF_SMB BOOL Done Execute BOOL BOOL Busy Position LREAL BOOL CommandAborted Velocity IREAL BOOL Error Acceleration LREAL SMC_ERROR ErrorID Deceleration LREAL Jerk LREAL Direction MC_Direction Direction	MC_MoveAbsolute_instance(Axis :=, Execute :=, Position :=, Velocity :=, Acceleration :=, Deceleration :=, Jerk :=, Direction :=, Done =>, Busy =>, CommandAborted =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting value (Default value)	Timing for updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
Position	Absolute target position (Unit: user unit)	LREAL	Negative number, positive number or 0 (0)	When Execute shifts to True and Busy is False.
Velocity	Target velocity (Unit: user unit/s)	LREAL	Positive number or 0 (0)	When Execute shifts to True and Busy is False.
Acceleration	Acceleration rate (Unit: user unit/s²)	LREAL	Positive number or 0 (0)	When Execute shifts to True and Busy is False.
Deceleration	Deceleration rate (Unit: user unit/s²)	LREAL	Positive number or 0 (0)	When Execute shifts to True and Busy is False.
Jerk	Jerk value (Unit: user unit/s ³)	LREAL	Positive number or 0 (0)	When Execute shifts to True and Busy is False.

Name	Function	Data Type	Setting value (Default value)	Timing for updating
Direction	Rotation direction	MC_Direction*	3:fastest 2:current 1:positive 0:shortest -1:negative (shortest)	When Execute shifts to True and Busy is False.

*Note: MC_Direction: Enumeration (Enum)

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when absolute target position is reached.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the axis is being controlled	BOOL	True/False(False)
Error	True if an error occurs	BOOL	True/False(False)
ErrorID	Record the error code when the error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration (Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When the absolute positioning is completed. 	 When Execute shifts to False If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.

Name	Timing for Shifting to True	Timing for Shifting to False
Busy	 When Execute changes to True. 	 When Done shifts to True. When Error shifts to True. When CommandAborted shifts to True.
CommandAborted	 When this instruction is aborted by another function block. When this instruction is aborted because of the execution of MC_Stop instruction. 	 When Execute shifts to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False.
Error	• When an error occurs in	
ErrorID	input values for the instruction.	to False. (Error code is cleared)

Timing Diagram



• In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute is rising edge triggered and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- Direction
 - Direction is used to define the rotation of servo axis and is effective only for modulo/rotary axis.
 - When the direction value is different, the motion direction and the travel distance of the rotary axis will be different as follows. Suppose the output unit of the physical device is "degree", the motion direction of the rotary axis is illustrated as follows:





Troubleshooting

- If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.
- Example
 - The example below describes the behavior of 2 MC_MoveAbsolute instructions which are connected with each other.



Timing Diagram

4000				
Velocity 2000				
0				1
20000		ı ! 		
Position		1		
0				
MC MoveAbsolute 0				
mo_moveAbsolute_o				
Execute				
Done				
			1	
Busy				
		1	1	
CommandAborted				
			J	
Error				
MC_MoveAbsolute_1				
Execute				
		1 1 1	ļ	
				i
Done				
				ļ
				1
Busy				
]	ļ
CommandAborted		1 1 1		
		1		
Error		1 1 1		
			discrete motion(4)	
State Machine	standstill(3)			i
State Machine		-		

- If Execute is True when MC_MoveAbsolute_0 block is running, the axis will move towards the target position. Once the Execute input of MC_MoveAbsolute_1 changes to True, the execution of MC_MoveAbsolute_0 block would be aborted, which CommandAborted turns True. The final position will be 20,000.
- When MC_MoveAbsolute_1 block is executed, the axis would move towards the absolute target position according to MC_MoveAbsolute_1 parameters.
- When axis reaches the absolute position 20000 set by MC_MoveAbsolute_1, the Done input of MC_MoveAbsolute_1 would turn True as Busy changing to False.
- In case Execute of MC_MoveAbsolute_1 switches to False, the Done output would also change to False state.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.5 MC_MoveRelative

MC_MoveRelative controls the axis to move a specified relative distance with a specified behavior.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_MoveRelative	MC_MoveRelative Axis_AXIS_REF_SM3 BOOL Execute BOOL Distance LREAL Olistance LREAL Velocity LREAL Acceleration LREAL Deceleration LREAL Jerk LREAL	MC_MoveRelative_instance(Axis :=, Execute :=, Distance :=, Velocity :=, Acceleration :=, Deceleration :=, Jerk :=, Done =>, Busy =>, CommandAborted =>, Error =>, Error ID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating	
Execute A rising edge of the input Execute starts the function block.		BOOL	True/False (False)	-	
Distance	Relative distance to be moved. (Unit: user unit)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.	
Velocity	Target velocity. (Unit: user unit/s)	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.	
Acceleration	Acceleration rate. (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.	
Deceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.	
Jerk	Jerk value. (Unit: user unit/s³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.	

• Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when relative distance is completed.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration (Enum)

Output Updating Time

Name Timing for Shifting to True		Timing for Shifting to False	
Done	• When the relative positioning is completed.	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	When Execute changes to True.	 When Done changes to True. When Error changes to True. When CommandAborted shifts to True. 	
 When this instruction is aborted by another function block. When this instruction is aborted because of the execution of MC_Stop instruction. 		 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 	
Error ErrorID	• When an error occurs in the execution conditions or input values for the instruction.	• When Execute shifts from True to False. (Error code is cleared)	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

The instruction performs relative positioning with specified target velocity (Velocity), acceleration rate (Acceleration),

deceleration rate (Deceleration) and Jerk value (Jerk) when execute changes to True.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

■ The example below describes the behavior of the MC_MoveRelative instruction.



• Timing Diagram



- When Execute changes to True, MC_MoveRelative drives the axis to the target position.During movement, Busy is True in the state of Discrete motion.
- When the axis moved the specified relative distance (1,000), Done changes to True, and Busy changes to False.
- When Execute changes to False, Done changes to False too.
- When Execute changes to True again, the instruction will be executed again to drive the axis to the target position and reaching the position of 2,000.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.6 MC_MoveAdditive

MC_MoveAdditive controls the axis to move an additional distance at a given speed and acceleration.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_MoveAdditive	MC_MoveAdditive Axis AXIS_REF_SM3 BOOL Execute BOOL BOOL Distance LREAL Velocity LREAL Acceleration LREAL Deceleration LREAL Jerk LREAL	MC_MoveAdditive_instance (Axis :=, Execute :=, Distance :=, Velocity :=, Acceleration :=, Deceleration :=, Jerk :=, Done =>, Busy =>, CommandAborted =>, Error =>, Error ID =>);

• Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
Distance	Relative distance to be moved. (Unit: user unit)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.
Velocity	Target velocity. (Unit: user unit/s)	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.
Acceleration	Acceleration rate. (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	Deceleration rate.	LREAL	Positive	When Execute shifts to True
Name	Function	Data Setting Data Value Type (Default Value)		Timing for Updating
------	-------------------------------------	---	-----------------------	--
	(Unit: user unit/s²)		number(0)	and Busy is False.
Jerk	Jerk value. (Unit: user unit/s³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.

• Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when additive distance is completed.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorlD	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration (Enum)

Output Updating Timing

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 True when the additive positioning is completed. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False.
Busy	 True when Execute changes to True. 	 When Done changes to True. When Error changes to True. When CommandAborted changes to

Name	Timing for Shifting to True	Timing for Shifting to False	
		• True.	
CommandAborted	• When this instruction is aborted because of the execution of MC_Stop instruction.	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 	
Error	When an error occurs in the	When Execute shifts from	
ErrorID	values for the instruction.	cleared)	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- MC_MoveAdditive executes the instruction based on user-defined parameters to drive the specific axis to move an additional distance.
- When MC_MoveAdditive executes alone, the behavior would be identical to a MC_MoveRelative.
- In case the previous instruction is on-going, an additional distance will be added again for the re-execution of MC_MoveAdditive instruction.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Chapter 2

• Example

The example below describes the behavior of MC_MoveRelative and MoveAdditive instructions which are executed in a series.



• Timing Diagram



- When Execute changes to True, MC_MoveRelative drives the axis to the target position. After Execute changes to True at the position 3500, the MC_MoveRelative instruction would be aborted and CommandAborted changes to True. At the same time, the axis remains in Discrete motion state.
- Meanwhile, the MC_MoveAdditive instruction is executed and adds a relative distance of 6,500 to the previous commanded position 5,000, and results the new commanded position 11,500.
- When the axis reaches 13,500, Done changes to True.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.1.7 MC_MoveSuperImposed

 $MC_MoveSuperimposed$ controls the axis to move a relative superimposed distance at a specified behavior while the axis is moving.

FB/F C	Instruction	Graphic Expression	ST language
FB	MC_MoveSuperImpose d	MC_MoveSuperImposed Axis AXI5_REF_SM3 BOOL Done = Execute BOOL Busy = Distance LREAL BOOL CommandAborted VelocityDiff LREAL BOOL CommandAborted Acceleration LREAL SMC_ERROR ErrorID = Deceleration LREAL SMC_ERROR ErrorID = Jerk LREAL	MC_MoveSuperImpose d _instance (Axis :=, Execute :=, Distance :=, VelocityDiff :=, Acceleration :=, Deceleration :=, Jerk :=, Done =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Name Function		Setting Value (Default Value)	Timing for Updating
Execute	Execute A rising edge of the input Execute starts the function block.		True/False (False)	-
Distance	Additional relative distance to be moved. (Unit: user unit)	LREAL	Negative number, positive number or 0 (0)	When Execute shifts to True and Busy is False.
VelocityDiff	Additional target velocity (Unit: user unit/s)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Acceleration	Additional acceleration rate (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	Additional deceleration rate	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
	(Unit: user unit/s²)			
Jerk	Additional jerk value (Unit: user unit/s³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	Done True when the superimposed movement is completed.		True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False	
Done	• When the superimposed distance is completed.	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	 When Execute changes to True. 	When Done changes to True.When Error changes to TrueWhen Commandaborted shifts	

Name	Timing for Shifting to True	Timing for Shifting to False	
		to True	
CommandAborted	 When one instruction is aborted by another instruction with the Buffer Mode set to Aborting. When this instruction is aborted because of the execution of MC_Stop instruction. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 	
Error	• When an error occurs in the	When Execute shifts from True	
ErrorID	values for the instruction.	to False.(Error code is cleared)	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- The input values of VelocityDiff, Distance, Acceleration, Deceleration and Jerk are superimposed on the on-going motion of the previous instruction.
- If executing MC_MoveSuperImposed block in Standstill state, the function would be identical to MC_MoveRelative.
- MC_MoveSuperImposed can be aborted by other function blocks.
- An error will occur when MC_MoveSuperImposed is repeatedly executed on the same axis.
- If changing the input values during the execution of MC_MoveSuperImposed or reexecute the function block before the instruction finished, the axis will react according to the new superimposed values and instruction, which are the sum of the previous

instruction and MC_MoveSuperimposed instruction. When the superimposed distance is reached, the axis will resume the operation of the previous instruction until the superimposed total distance is reached.

MC_MoveSuperimposed and the function block, which is previously executed, would be aborted if a new function block is started while MC_MoveSuperimposed is superimposed on other function blocks.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

The example below describes the behavior of MC_MoveSuperImposed applied to MC_MoveVelocity.



Timing Diagram



- When Execute of MC_MoveVelocity changes to True, the specific axis starts to move towards the target velocity (500) at the constant speed.
- When Execute of MC_MoveSuperImposed changes to True, the MC_MoveSuperImposed instruction starts and applies the additional values (velocity, distance, acceleration, deceleration and jerk) to the axis and the axis performs a superimposed motion path. Since VelocityDiff is set as 600 and the target superimposed distance is far enough, the velocity will be superimposed to 1100(500 + 600).
- When the execution of MC_MoveSuperImposed is finished, Done will turn True and MC_MoveVelocity will keep going.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.1.8 MC_CamIn

MC_	CamIn	performs	cam	operation.
-----	-------	----------	-----	------------

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_CamIn	MC_CamIn Master AXIS_REF_SM3 BOOL InSync Slave AXIS_REF_SM3 BOOL Busy Execute BOOL BOOL CommandAborted MasterOffset LREAL BOOL Error SlaveOffset LREAL SMC_ERROR ErrorID MasterScaling LREAL BOOL EndOfProfile SlaveScaling LREAL SMC_TappetData Tappets StartMode CamTableID VelocityDiff LREAL Acceleration LREAL Jerk LREAL TappetHysteresis LREAL	MC_CamIn_instance (Master :=, Slave :=, Execute :=, MasterOffset :=, SlaveOffset :=, SlaveOffset :=, SlaveScalling :=, StarMode :=, CamTableID :=, VelocityDiff :=, Acceleration :=, Deceleration :=, Jerk :=, TappetHysteresis :=, InSync =>, Busy =>, CommandAborted =>, Error ID =>, ErrorID =>, EndOfProfile =>, Tappets =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
MasterOffset	Shifts the position of the master axis by the specified offset value. (Unit: user unit)	LREAL	Negative number, positive number or 0 (0)	When Execute shifts to True and Busy is False.
SlaveOffset	Shifts the displacement of the slave axis by the specified offset value. (Unit: user unit)	LREAL	Negative number, positive number or 0 (0)	When Execute shifts to True and Busy is

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
				False.
MasterScaling	Scales the master axis up and down with the specified factor.	LREAL	Negative number, positive number or 0 (0)	When Execute shifts to True and Busy is False.
SlaveScaling	Scales the slave axis up and down with the specified factor.	LREAL	Negative number, positive number or 0 (0)	When Execute shifts to True and Busy is False.
StartMode	Specifies the engagement behavior of the slave axis	MC_StartMode	0:absolute 1:relative 2:ramp_in 3:ramp_in_pos 4:ramp_in_neg (absolute)	When Execute shifts to True and Busy is False.
CamTableID	Cam table identifier, which is from output of CamTableSelect.	MC_ CAM_ID	MC_CAM_ID [∗]	When Execute shifts to True and Busy is False.
VelocityDiff	Maximum velocity difference under ramp_in mode. (Unit: user unit/s)	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.
Acceleration	The acceleration rate under ramp_in mode. (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	The deceleration rate under ramp_in mode. (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Jerk	The jerk value under ramp_in mode. (Unit: user unit/s³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
				False.
TappetHysteresis	The hysteresis rate of tappet.	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.

***Note:** MC_CAM_ID(Struct): Cam table variables, from output of MC_CAMTableSelect, are input to MC_CamIn.

Name	Function	Data Type	Setting Value (Default Value)
рСТ	Internal information stored in the cam table	POINTER TO BYTE	Positive number or 0(0)
Periodic	Periodic mode	BOOL	True/False (True)
MasterAbsolute	MasterAbsolute mode	BOOL	True/False (True)
SlaveAbsolute	SlaveAbsolute mode	BOOL	True/False (True)
StartMaster	The start master axis position in the cam table	LREAL	Negative number, positive number or 0 (0)
EndMaster	The end master axis position in the cam table	LREAL	Negative number, positive number or 0 (0)
StartSlave	The start slave axis position in the cam table	LREAL	Negative number, positive number or 0 (0)
EndSlave	The end slave axis position in the cam table	LREAL	Negative number, positive number or 0(0)
byCompatibilityMode	Compatibility mode	BYTE	Positive number or 0(0)

Outputs

Name	Function	Data Type	Output Range (Default Value)
InSync	True when the specified master/slave cam operation is synchronized.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAbort ed	True when this instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*1	SMC_ERROR(SMC_NO_ERR OR)
EndOfProfile	True when the end point of the cam profile is completed.	BOOL	True/False(False)
Tappets	Can be used with the function block of SMC_GetTappetVal ue.	SMC_TappetDat a ^{*2}	SMC_TappetData

*Note:

- 1. SMC_ERROR: Enumeration(Enum)
- 2. SMC_TappetData: Structure(Struct)

Name	Function	Data Type	Output Range (Default Value)
ctt	Tappet action active when axis passes tappets in the specified direction (positive or negative).	SMC_CAMTAPPETTYPE	0:TAPPET_pos (Pass in positive direction) 1:TAPPET_all (No specific direction) 2:TAPPET_neg (Pass in negative direction) (TAPPET_pos)
cta	The action activated when axis passes tappets.	SMC_CAMTAPPETACTI ON	0:TAPPETACTION_on(Swit ch ON) 1:TAPPETACTION_off(Swit ch OFF) 2:TAPPETACTION_inv (Inverts)

Name	Function Data Type		Output Range (Default Value)
			3:TAPPETACTION_time (Switches on after a delay for a certain time period.)
			(TAPPETACTION_on)
dwDelay	Specify the delay time for switching ON under TAPPETACTION_ti me mode.	DWORD	Positive number or 0(0)
dwDuratio n	Specify the time duration for which the tappet is switched to ON under TAPPETACTION_ti me mode.	DWORD	Positive number or 0(0)
iGroupID	Track ID of tappets	INT	Positive number, negative number or 0(0)
x	Master position where tappet is switched.	LREAL	Positive number, negative number or 0(0)
dwActive	Internal variable	DWORD	Positive number or 0(0)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
InSync	• When the synchronization between master and slave axis is completed.	 When a falling edge is detected at input <i>Execute</i>. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	 When an instruction is being executed. 	 When a rising edge is detected at output CommandAborted. When a rising edge is detected at output <i>Error</i>.
CommandAborted	 When MC_CamOut is executed. When one instruction is aborted by another instruction. When a function block instruction is aborted by MC_Stop. 	 When a falling edge is detected at input <i>Execute</i>. If Execute is False and <i>CommandAborted</i> shifts to True, <i>CommandAborted</i> will be True for only one period and immediately shift to False.

Name	Timing for Shifting to True	Timing for Shifting to False
Error	• When an error occurs in	 When a falling edge is detected
ErrorID	or input values for the instruction.	at input Execute. (Error codes are cleared.)
EndOfProfile	 Cyclic end of the cam profile 	 Shift to True for only one period and immediately shift to False if MC_CamTableSelect Periodic is 1(period).
Endorronie		 Shift to False when a falling edge is detected at input Execute and MC_CamTableSelect Periodic is 0.

Timing Diagram



When Execute shifts from FALSE to TRUE and Busy is TRUE, InSync shifts from False to True as soon as the synchronization between master and slave axis is completed. When coming to the end of CAM cycle, EndOfProfile shifts from FALSE to TRUE for only one period, then switch back to FALSE. Once the coupling of master and slave axis is deactivated, such as executing MC_CamOut, CommandAborted shifts from FALSE to TRUE, while both InSync and Busy shifts from TRUE to FALSE. Then, CommandAborted will shift from TRUE to FALSE as well as Execute.

In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Master	Reference to the master axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
Slave	Reference to the slave axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- Relationship between master axis position and slave axis position
 - The cam relationship which is planned in the software is the position relationship between the master axis and slave axis. The "position" mentioned here is the cam phase of the master axis / slave axis instead of the actual axis position. If the cam relationship which is planned is seen as the function CAM as below, the input of the function CAM is the master axis cam phase and the output is the slave axis cam phase. The formula is shown as below.

y = CAM(x)

x: The master axis cam phase

y: The slave axis cam phase

- The cam phase comes from the axis positions and there is a conversion between them. The conversion between the axis position and cam phase is related with the MasterAbsolute, SlaveAbsolute, MasterOffset, SlaveOffset, MasterScaling, and SlaveScaling.
- The slave axis follows the master axis to make the synchronous cam motion by using the MC_CamIn instruction. In the synchronous cam motion, the corresponding relationship between the master axis position and slave axis position is based on the pre-planned cam relationship (the cam curve or cam table). The process in which the slave axis position is calculated through the master axis position is illustrated as follows.



The following formula is generated from the figure above:

Position_Slave=SlaveScaling×CAM(MasterScaling×MasterPosition+MasterOff set)+ SlaveOffset

It can be seen that when master axis is in absolute mode, master position is the remainder of the current master position divided by modulo; When master axis is in relative mode, master position is the start point position (usually 0) of master axis in the corresponding cam curve.

Relation between StartMode and MasterAbsolute/ SlaveAbsolute of CamTableSelect

- Absolute mode (StartMode = 0): The slave current position is not involved in the Cam calculation as the cam synchronization starts, However, a jump can be caused if the current position of slave axis and its start position from the Cam are not the same
- Relative mode (StartMode = 1): Cam changes according to the current position of slave axis, which the slave axis position would be added to the slave current position for calculation. If the slave setpoint position according to the cam is not at the start point 0, a jump may occur.
- Ramp mode (StartMode = 2, 3, 4): Add a motion curve for compensation according to VelocityDif, Acceleration, Deceleration, and Jerk, so as to prevent a jump in cam

when coupling starts.

MC_CamTableSelect.MasterAbsolute	Master axis
absolute	Absolute mode
relative	Relative mode

MC_CamIn.StartMode	MC_CamTableSelect.SlaveAbsolute	Slave axis
absolute	True	Absolute mode
absolute	False	Relative mode
relative	True	Relative mode
relative	False	Relative mode
ramp_in	True	Ramp in Absolute mode
ramp_in	False	Ramp in Relative mode
ramp_in_pos	True	Ramp in positive Absolute mode
ramp_in_pos	False	Ramp in positive Relative mode
ramp_in_neg	True	Ramp in negative Absolute mode
ramp_in_neg	False	Ramp in negative Relative mode

Cam table



1. Absolute mode on master axis(MasterAbsolute = true)

Absolute mode on slave axis (SlaveAbsolute = true)

1.1 Absolute mode(StartMode = 0)

Coupling positions for master and slave axis, respectively, are master current position and the slave position from the cam table.



1.2 Absolute mode (StartMode = 1)

Coupling positions for master and slave axis, respectively, are master current position and the slave position on the cam table plus slave current position (180+64 = 244). In addition, a jump would occur if the start point of master axis is not same as the start position on cam table.



1.3 Ramp in mode (StartMode=2)

Coupling positions for master and slave axis, respectively, are master current position and the slave position added with a motion curve for compensation, which is configured via VelocituDiff, Acceleration and Deceleration settings, for the purpose of preventing a jump while ramping in.



- 1.4 Ramp in positive, Ramp in negative (StartMode = 3, 4) With a rotary/ modulo slave axis, ramp_in_pos compensates only in the positive direction and ramp_in_neg in the negative direction. For linear slaves the compensation direction is generated automatically with ramp_in_pos, ramp_in_neg, and ramp_in mode which also means these three modes are under the same execution condition.
- 2. Absolute mode on master axis (MasterAbsolute = true), Relative mode on slave axis (SlaveAbsolute = false)
- 2.1 Absolute/ Relative mode (StartMode = 0, 1)

The defined positions of master and slave axis when cam is engaged, respectively, are master current position and the slave position from the cam table added on the slave current position (180+65 = 245). In addition, a jump would occur if the start point of master axis is not same as the start position on cam table



2.2 Ramp in mode (StartMode = 2)

The defined positions of master and slave axis when cam is engaged, respectively, are master current position and the slave position added with a motion curve for compensation, which is configured via VelocituDiff, Acceleration and Deceleration settings, for the purpose of preventing a jump while ramping in. The slave coupling position would be the position on the cam table plus slave current position (61 + 180 = 241).



3. Master absolute mode (MasterAbsolute = false)/ Slave absolute mode (SlaveAbsolute = true)

3.1 Absolute mode (StartMode = 0)

Master-slave coupling position: The current position of master axis would be the start position as well as the zero position on the cam table. The corresponding position of the slave axis on the cam table should also be zero, while the slave position (coupling) is zero under absolute mode.



3.2 Relative mode (StartMode = 1)

Master-slave coupling position: The current position of master axis would be the start position as well as the zero position on the cam table. The corresponding position of the slave axis on the cam table should also be zero, while the slave position (coupling) under relative mode should be the sum of corresponding position and slave current position (0+180=180).



4. Master relative mode (MasterAbsolute = false)/ Slave relative mode (SlaveAbsolute = false)

4.1 Absolute/ Relative mode (StartMode = 0, 1)

Master-slave coupling position: The current position of master axis would be the start position as well as the zero position on the cam table. The corresponding position of the slave axis on the cam table should also be zero, while the slave position (coupling) under relative mode should be the sum of corresponding position and slave current position (0+180=180).



4.2 Ramp in mode (StartMode = 2)

Master-slave coupling position: The current position of master axis would be the start position as well as the zero position on the cam table. A compensating curve is added to the slave position according to the settings of VelocityDiff, Acceleration and Deceleration to avoid jumps.



- Offsets and scaling (MasterOffset/MasterScaling/SlaveOffset/Slavescaling)
 - Position offsets and scaling can be performed by modifying the parameters based on the preplanned cam curve. For example, you can specify the scaling factor to adjust phase and offset between master and slave in cam table with only one cam curve needed for a processed product, which comes in multiple sizes, so as to switch between different sizes of the product during production. In addition, offsets and scaling factors of master and slave axis can be configured respectively.
 - Offsets and scaling between master and slave axis determine the actual operation for cam profile, which is demonstrated in the following example. The preplanned cam profile curve is shown below.



If the master and slave axis are under absolute mode, the start position of master and slave axis would be zero while performing coupling action. Without any offset and scaling (default setting), the relationship between the actual positions of master and slave axis are shown below.



- When the position offsets and scaling are not set as default, impacts on the relationship between the actual positions of master and slave axis are shown below.
- 1. When MasteOffset= 0, the impact of MasterScaling and SlaveScaling on the actual cam profile.







- Condition 1: When MasterScaling and SlaveScaling are set to 1 with no offsets, the actual cam profile would be same as preplanned.
- Condition 2: When MasterScaling=1 and SlaveScaling=2 with no offsets, the slave position would be two times more than the preplanned.
- Condition 3: When MasterScaling=1 and SlaveScaling=0.5 with no offsets, the slave position would be half of the preplanned.
- Condition 4: When MasterScaling=2 and SlaveScaling=1 with no offsets, the position of master axis is doubled compared with the preplanned position relative to the slave axis. From the angle of cam phasing, the master phasing is twice the pre-planned phasing, which the cam master cycle changes from 360 to 180 and the cam slave phasing remains unchanged.
- Condition 5: When MasterScaling=0.5 and SlaveScaling=1 with no offsets, the position of master axis would be half of the preplanned position relative to the slave axis. From the angle of cam phasing, the master phasing is half the preplanned phasing, which the cam master cycle changes from 360 to 720 and the cam slave phasing remains unchanged.
- 2. When MasteScaling = 0, the impact of MasterOffset and SlaveOffset on the actual operation of cam profile.



Condition 1: When MasterScaling=1, SlaveScaling=1, MasterOffset=0 and SlaveOffset=60, the slave position relative to the master position would be added with 60 based on the preplanned position. For example, the master position 180 corresponds to the slave position 180 in a planned cam relationship which the corresponding slave axis position should be 240(240=180+60) during the actual execution.

Condition 2: When MasterScaling=1, SlaveScaling=1, MasterOffset=90 and SlaveOffset=0, the master position relative to the slave position would be added with 90 based on the preplanned position. For example, the master position 180 corresponds to the slave position 180 in a planned cam relationship, which the master axis position 90 should correspond to the slave axis position 180(180=90+90) during the actual execution.

Period mode

- Use Periodic of MC_CamTableSelect to control the period mode. Under nonperiodic mode, EndOfProfile remains to be TRUE after executing for one period. Meanwhile, the slave axis stops moving, but still in sync. The status of slave axis stays under synchronized_motion.
- ♦ At the same time, Execute changes to False, while OutputsInSync, Busy and EndOfProfile of MC_CamIn remains to be TRUE.

Tappet table^{*}

 Use Tappet table to set tappets in Cam and read the status of tappets with SMC_GetTappetValue, which can also be modified according to the settings in Tappet table and the direction when CAM master passing the tappets.

	Track ID	Х	positive pass	negative pass
٠	1			
1		180	switch ON	switch OFF
1		360	switch OFF	none
•	3			
1		90	switch ON	none
1		270	invert	switch OFF
•				

***Note:** At the same position, a maximum of three tappets can be set on the Tappet table.

You can configure several tappets for each track ID on the Tappet table, then view the relationship between tappets and the master axis. While moving the points on Tappets page, the setting parameters on Tappet table page would be changed simultaneously.

Г		- 1		-1-								maste	r position [u]
	0	30	60	90	120	150	180	210	240	270	300	330	360
1	C TRUE						~ ~						X
3	¢ FALS	E		~						×			
2	÷	E											

TappetHysteresis

Set hysteresis intervals of tappet to avoid vibration in axes and encoders, which may lead to wrong switching actions. The specified axis position must exceeds the interval so the next action will be executed. The unit for Hysteresis is user-defined.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

- Example1: Demonstrate the execution result after cam parameters relating to MC_CamInbeing being configured. Both the master and slave axis are rotary axes in this example.
 - Cam curve planning:



	Х	Y	V	Α	J	Segment Type	min(Position)	max(Position)	max(Velocity)	max(Acceleration)
	0	0	1	0	0					
•						Poly5	0	90	1.5120000000	0.0437803772552189
1	90	90	0	0	0					
•						Poly5	90	180	1.51200000000	0.0437803772552188
1	180	180	1	0	0					
•						Poly5	90	189.8427604	2.33748148148	0.10754458161865568
1	270	90	0	0	0					
•						Poly5	-9.84276047	90	2.33748148148	0.10754458161865568
	360	0	1	0	0					



Chapter 2

Timing Diagram



• The calculation for axis position and coupling position on cam coordinate:

Position_Slave = SlaveScaling×CAM(MasterScaling×MasterPosition + MasterOffset)+SlaveOffset

Slave coupling position = $1 \times CAM(2 \times 321(master position while executing CamIn)+ 30)+ 100$

= 1 × CAM(672)+ 100 = 1 × CAM(312)+ 100 = 36 + 100 = 136 When coupling is completed, the master position would be at 321 and the slave position is at 136.

- **Example2:** The operation of tappet after configuring *TappetHysteresis* as the following example demonstrates.
 - Tappets





Timing Diagram



- 1. The tappets switch to ON when the master axis passes position 90. Master keeps moving forward until its position exceeds the hysteresis interval and the axis performs reversing. Then the master axis passes position 90 again and exceeds the hysteresis interval, which would make tappets switch to OFF.
- 2. The tappets switch to ON when the master axis passes position 90. The master axis keeps moving forward and performs reversing without exceeding the hysteresis interval. Therefore, the tappets will not switch to OFF when the master position passes 90 once again.
- Supported Products

AX-308E, AX-8, AX-364E

2.1.9 MC_CamOut

MC_CamOut deactivates the coupling between master and slave axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_CamOut	MC_CamOut 	MC_CamOut_instance (Slave :=, Execute :=, Done =>, Busy =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	TRUE when the decoupling task between master and slave is completed.	BOOL	True/False(False)
Busy	TRUE when the instruction is BOOL executed.		True/False(False)
Error	TRUE when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

***Note:** SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False		
Done	 When the instruction CamOut is completed. 	 When a falling edge is detected at input Execute. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 		
Busy	 When an instruction is being executed. 	• When a rising edge is detected at output <i>Error</i> and <i>Done</i> .		
Error	• When an error occurs in the	• When a falling edge is detected		
ErrorID	values for the instruction.	at input Execute. (Error codes are cleared.)		

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Slave	Reference to the slave axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- When the slave axis is decoupled from the master axis by MC_CamOut, it moves with the sustained velocity and the slave state is under ContinuousMotion. (irrelevant to the velocity of slave axis)
- If the synchronization between master and slave axis is not established while executing MC_CamOut. An error of SMC_AXIS_NOT_READY_FOR_MOTION(34) will be reported.
- The axis state still remains continuous_motion, even though the slave axis is desynchronized at standstill with velocity 0.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

■ The following example gives the operation result of MC_CamOut. The master and slave axis in this example are rotary axes.





	Х	Y	V	Α	J	Segment Type	min(Position)	max(Position)	max(Velocity)	max(Acceleration)
	0	0	1	0	0					
•						Poly5	0	90	1.5120000000	0.0437803772552189
1	90	90	0	0	0					
0						Poly5	90	180	1.5120000000	0.0437803772552188
1	180	180	1	0	0					
•						Poly5	90	189.8427604	2.33748148148	0.10754458161865568
1	270	90	0	0	0					
•						Poly5	-9.84276047	90	2.33748148148	0.10754458161865568
	360	0	1	0	0					



Timing Diagram



- The master-slave coupling is deactivated when MC_CamOut is executed. At the same time, MC_CamIn is aborted and a falling edge is detected at CommandAborted.
- The slave axis continues to move at the current speed after being decoupled from the master axis, while the axis state changes to continuous_motion.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.10 MC_MoveVelocity

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_MoveVelocity	MC_MoveVelocity -Axis AXIS_REF_SM3 BOOL InVelocity -Execute BOOL BOOL Busy -Velocity IREAL BOOL CommandAborted -Acceleration LREAL BOOL Error -Deceleration LREAL SMC_ERROR ErrorID -Jerk LREAL SMC_ERROR ErrorID -Direction MC_Direction MC_Direction	MC_MoveVelocity_instance (Axis :=, Execute :=, Velocity :=, Acceleration :=, Deceleration :=, Jerk :=, Direction :=, InVelocity =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
Velocity	Target velocity. (Unit: user unit/s)	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.
Acceleration	Acceleration rate. (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Jerk	Jerk value. (Unit: user unit/s³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Direction	Specifies the direction for servo motor rotation.	MC_ Direction*	3:fastest 2:current 1:positive 0:shortest -1:negative (current)	When Execute shifts to True and Busy is False.

*Note: I	МC	Direction:	Enumeration	(Enum)
	_			· /

• Outputs

Name	Function	Data Type	Output Range (Default Value)
InVelocity	When the specified target velocity is reached.	BOOL	True/False(False)
Busy	When Execute shifts to True.	BOOL	True/False(False)
CommandAborted	True when this instruction is aborted	BOOL	True/False(False)
Error	True when an error occurs	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False	
InVelocity	 True when the specified target velocity is reached. 	 When CommandAborted shifts to True When CommandAborted shifts to True and the target velocity is changed. 	
Busy	 When Execute shifts to True. 	 When Error shifts to True. When CommandAborted shifts to True. 	
CommandAborted	 When this instruction is aborted by another instruction. When this instruction is aborted because of the execution of MC_Stop instruction. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 	
Error	When an error occurs in the execution conditions or	 When Execute shifts from True to False. (Error code is cleared) 	
ErrorID	input values for the instruction.		
Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- The instruction performs speed control with specified target velocity (Velocity), acceleration rate (Acceleration), deceleration rate (Deceleration) and Jerk value (Jerk) when execute changes to True.
- Users can execute another motion instruction to abort the ongoing motion of MC_MoveVelocity.
- When aborted by other instructions, OutputsInVelocity would be False and Outputs*CommandAborted is True.*
- When Execute of MC_MoveVelocity changes to True, the axis starts to move at the target velocity. Even if Execute turns False, the execution of the function block would not be affected.
- When ExecuteInputs of MC_MoveVelocity is retriggered and a new target velocity is specified, the axis will change the velocity to the requested velocity.
- In case the Execute pin changes to False after the function block is executed, *InVelocity* of MC_MoveVelocity will turn True when the target velocity is reached. *InVelocity* will remain as True, until being aborted by other instructions.
- InVelocity remains as True when MC_MoveVelocity reaches the target velocity. Even if the velocity being changed by MC_MoveSuperimposed, the movement of InVelocity would not be affected.

Troubleshooting

■ If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

The example below describes the behavior of two MC_MoveVelocity.



Timing Diagram



- When Execute changes to True, the first MC_MoveVelocity controls the axis to reach the specified target velocity 500. When it reaches 500, InVelocity changes to True.
- If Execute of MC_MoveVelocity_1 changes to True, InVelocity will change to False and CommanAborted will change to True while MC_MoveVelocity_0 is aborted.
- MC_MoveVelocity_1 will decelerate the axis to the velocity 300. When 300 is reached, InVelocity will change to True and remain in this status as long as the velocity is not changed.
- When Execute of MC_MoveVelocity_0 changes to False, CommanAborted will change to False.
- If MC_MoveVelocity_0 is restarted by Execute, which changes to True, the axis will abort MC_MoveVelocity_1 and accelerate toward the velocity 500.
- Before the axis reaches the target velocity of MC_MoveVelocity_0, Execute of MC_MoveVelocity_1 will again turn False to True and aborts MC_MoveVelocity_0. In this case, the axis decelerates again without reaching the target velocity.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.11 MC_PositionProfile

MC_PositionProfile commands a time-position locked motion profile.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_PositionProfile	Axis MC_PositionProfile - TimePosition MC_TP_REF BOOL Busy - Execute BOOL BOOL Commandaborted - ArraySize INT BOOL Fror - PositionScale LREAL SMC_ERROR ErrorID - Offset LREAL SMC_ERROR ErrorID	MC_PositionProfile_instance (Axis:=, TimePosition:=, Execute :=, ArraySize:=, PositionScale:=, Offset:=, Done =>, Busy =>, CommandAborted =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
ArraySize	Number of motion profile arrays	INT	Positive number or 0(0)	When Execute shifts to True and Busy is False.
PositionScale	Overall scale factor in value.	LREAL	Negative number, positive number or 0(1)	When Execute shifts to True and Busy is False.
Offset	Overall profile offset in value (Unit: user unit/s)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done True when execution of path planning is finished.		BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False	
Done	 When the execution of path planning is completed. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	 When Execute changes to True. 	 When Done changes to True. When Error changes to True. When Commandaborted shifts to True. 	
CommandAborted	 When this instruction is aborted by another function block. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 	
Error	• When an error occurs in the	When Execute shifts from True	

Name	Timing for Shifting to True	Timing for Shifting to False
ErrorID	execution conditions or input values for the instruction.	to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*1	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
TimePosition	Time and position during execution.	MC_TP_REF*2	MC_TP_REF	When Execute shifts to True and Busy is False.

*Note:

- 1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.
- 2. MC_TP_REF: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
Number_of_pairs	There's no need to set this variable, which has been replaced by InputsArraySize.	INT	-
IsAbsolute	Set the mode of position.	BOOL	True: Absolute mode False: Relative mode (True)
MC_TP_Array	Time and position data during execution of	ARRAY [1100] OF SMC_TP	SMC_TP*

Name	Function	Data Type	Setting Value (Default Value)
	instruction.		

*Note: SMC_TP: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
delta_time	Period of time between position points	TIME	Positive number or 0(TIME#0ms)
position	Position of the position point	LREAL	Negative number, positive number or 0(0)

Function

- MC_PositionProfile carries out motion profile with time and position according to the user-defined data in TimePosition variables, the state is Discrete Motion during the movement.
- MC_MoveSuperimposed would not be able to function while MC_PositionProfile is being used.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

■ The example below describes the behavior of MC_PositionProfile instruction.

MC_PositionProfile_0					
TRUE	TRUE MC_PositionProfile				
	EN	ENO			
SM_Drive_Virtual 😁	Axis	Done	-		
TimePosition_0 🛁	TimePosition	Busy			
E1 —	Execute	CommandAborted	-		
5 —	ArraySize	Error	-		
2 —	PositionScale	ErrorID			
0 —	Offset				

Configure for the curve of motion profile:

```
TimePosition_0.MC_TP_Array[1].delta_time := T#1S;
TimePosition_0.MC_TP_Array[2].delta_time := T#2S;
TimePosition_0.MC_TP_Array[3].delta_time := T#3S;
TimePosition_0.MC_TP_Array[4].delta_time := T#4S;
TimePosition_0.MC_TP_Array[5].delta_time := T#5S;
TimePosition_0.MC_TP_Array[2].position :=100;
TimePosition_0.MC_TP_Array[2].position :=180;
TimePosition_0.MC_TP_Array[3].position :=50;
TimePosition_0.MC_TP_Array[4].position :=200;
TimePosition_0.MC_TP_Array[5].position :=-100;
```

Timing Diagram



- When *Execute* of MC_PositionProfile is raised, the target axis moves along the curve, which is generated by the settings of delta_time and position in TimePosition.
- The setting value of *IsAbsolute* is True, MC_PositionProfile plans motion curves in the mode of Abosolue position.
- Motion curve of MC_PositionProfile is generated according to the time-position data in TimePosition. As a result of PositionScale=2, the position will be 200 after one second of execution, position 300 after two seconds and so on. When executes after 5 second, the position should be -200.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.1.12 MC_VelocityProfile

Similar to MC_PositionProfile, MC_VelocityProfile also commands a time-position locked motion profile; however, its position points are defined by the velocity variables in MC_TV_REF.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_VelocityProfile	MC_VelocityProfile Axis XXIS_REF_SM3 BOOL Done TimeVelocity MC_TV_REF BOOL Busy Execute BOOL BOOL CommandAborted —ArraySize INT BOOL Error VelocityScale LREAL SMC_ERROR ErrorID —Offset LREAL	MC_VelocityProfile_instance (Axis:=, TimeVelocity:=, Execute :=, ArraySize:=, VelocityScale:=, Offset:=, Done =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
ArraySize	Number of motion profile arrays	INT	Positive number or 0(0)	When Execute shifts to True and Busy is False.
VelocityScale	Overall scale factor in value.	LREAL	Negative number, positive number or 0(1)	When Execute shifts to True and Busy is False.
Offset	Overall profile offset in value (Unit: user unit/s)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when execution of path planning is finished.	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When the execution of path planning is completed. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	When Execute changes to True.	 When Done changes to True. When Error changes to True. When Commandaborted shifts to True.
CommandAborted	 When this instruction is aborted by another function block. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False.
Error	 When an error occurs in the execution conditions or input values for the instruction. 	• When Execute shifts from True to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*1	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
TimeVelocity	Time and velocity during execution.	MC_TV_REF*2	MC_TV_REF	When Execute shifts to True and Busy is False.

*Note:

1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

2. MC_TV_REF: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
Number_of_pairs	There's no need to set this variable, which has been replaced by InputsArraySize.	INT	-
IsAbsolute	Set the mode of velocity.	BOOL	True: Absolute mode False: Relative mode (True)
MC_TV_Array	Time and velocity data during execution of instruction.	ARRAY [1100] OF SMC_TV	SMC_TV*

*Note: SMC_TV: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
delta_time	Period of time between position points	TIME	Positive number or 0(TIME#0ms)
velocity	Velocity of the position point	LREAL	Negative number, positive number or 0(0)

• Function

- MC_VelocityProfile carries out motion profile with time and velocity according to the user-defined data in TimeVelocity variables, the state is Continuous Motion during the movement.
- MC_VelocityProfile would not be able to function while MC_PositionProfile is being used.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

■ The example below describes the behavior of MC_VelocityProfile.



Configure for the curve of motion profile:

<pre>TimeVelocity_0.MC_TV_Array[1].delta_time := T#1:</pre>	S;
TimeVelocity_0.MC_TV_Array[2].delta_time := T#2:	S;
TimeVelocity_0.MC_TV_Array[3].delta_time := T#3:	S;
TimeVelocity_0.MC_TV_Array[4].delta_time := T#4:	S;
TimeVelocity_0.MC_TV_Array[5].delta_time := T#5:	S;
<pre>TimeVelocity_0.MC_TV_Array[1].velocity :=100; TimeVelocity_0.MC_TV_Array[2].velocity :=180; TimeVelocity_0.MC_TV_Array[3].velocity :=50; TimeVelocity_0.MC_TV_Array[4].velocity :=200; TimeVelocity_0.MC_TV_Array[5].velocity :=-100;</pre>	

Chapter 2

Timing Diagram



• When Execute of MC_VelocityProfile is raised, the target axis moves along the curve, which is generated by the settings of delta_time and velocity in TimeVelocity.

• The setting value of IsAbsolute is True, MC_VelocityProfile plans motion curves in Abosolue mode.

• Since Motion curve of MC_VelocityProfile is generated according to the timevelocity data in TimeVelocity, the velocity will be 100 after one second of execution, position 180 after two seconds and so on. When executes after 5 second, the position should be -100.

Supported Products

AX-308E, AX-8, AX-364E

2.1.13 MC_AccelerationProfile

Similar to MC_PositionProfile, MC_AccelerationProfile also commands a time-position locked motion profile; however, its position points are defined by acceleration variables in MC_TV_REF.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_AccelerationProfile	MC_AccelerationProfile BOOL Done TimeAcceleration MC_TA_REF BOOL Bool Execute BOOL BOOL CommandAborated ArcrefarionScale BOOL Error AccelerationScale REAL Offset LREAL	MC_AccelerationProfile _instance (Axis:=, TimeAcceleration:=, Execute :=, ArraySize:=, AccelerationScale:=, Offset:=, Done =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
ArraySize	Number of motion profile arrays	INT	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.
AccelerationScale	Overall scale factor in value.	LREAL	Negative number, positive number or 0(1)	When Execute shifts to True and Busy is False.
Offset	Overall profile offset in value (Unit: user unit/s)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when execution of path planning is finished.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When the execution of path planning is completed. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	 When Execute changes to True. 	 When Done changes to True. When Error changes to True. When Commandaborted shifts to True.
CommandAborted	• When this instruction is aborted by another function block.	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False.
Error	When an error occurs in the execution conditions or	When Execute shifts from True
ErrorID	input values for the	to False. (Error code is cleared)

Name	Timing for Shifting to True	Timing for Shifting to False
instruction.		

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*1	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
TimeAcceleration	Time and acceleration during execution.	MC_TA_REF*2	MC_T_REF	When Execute shifts to True and Busy is False.

*Note:

1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

2. MC_TA_REF: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
Number_of_pairs	There's no need to set this variable, which has been replaced by InputsArraySize.	INT	-
IsAbsolute	Set the mode of acceleration.	BOOL	True: Absolute mode False: Relative mode (True)

Chapter 2

Name	Function	Data Type	Setting Value (Default Value)
MC_TA_Array	Time and acceleration data during execution of instruction.	ARRAY [1100] OF SMC_TA	SMC_TA*

*Note: SMC_TA: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
delta_time	Period of time between position points	TIME	Positive number or 0(TIME#0ms)
acceleration	Acceleration of the position point	LREAL	Negative number, positive number or 0(0)

• Function

- MC_AccelerationProfile carries out motion profile with time and acceleration according to the user-defined data in TimeAcceleration variables, the state is Continuous Motion during the movement.
- MC_MoveSuperimposed cannot add a specific distance to an existing motion of MC_AccelerationProfile.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

■ The example below describes the behavior of MC_AccelerationProfile.

MC_AccelerationProfile_0				
TRUE	MC AccelerationProfile			
	EN	ENO	_	
SM_Drive_Virtual -	Axis	Done		
TimeAcceleration_0 -	TimeAcceleration	Busy	-	
E1	Execute	CommandAborted	-	
5 —	ArraySize	Error	-	
1 —	AccelerationScale	ErrorID	-	
o —	Offset			

```
TimeAcceleration_0.MC_TA_Array[1].delta_time := T#1S;
TimeAcceleration_0.MC_TA_Array[2].delta_time := T#2S;
TimeAcceleration_0.MC_TA_Array[3].delta_time := T#3S;
TimeAcceleration_0.MC_TA_Array[4].delta_time := T#4S;
TimeAcceleration_0.MC_TA_Array[5].delta_time := T#5S;
TimeAcceleration_0.MC_TA_Array[1].acceleration :=100;
TimeAcceleration_0.MC_TA_Array[2].acceleration:=180;
TimeAcceleration_0.MC_TA_Array[3].acceleration:=50;
TimeAcceleration_0.MC_TA_Array[4].acceleration:=200;
TimeAcceleration_0.MC_TA_Array[5].acceleration:=-100;
```

Timing Diagram



• When Execute of MC_AccelerationProfile is raised, the target axis moves along the curve, which is generated by the settings of delta_time and Acceleration in TimeAcceleration.

• The setting value of IsAbsolute is True, MC_AccelerationProfile plans motion curves in Abosolue mode.

◆ Since Motion curve of MC_AccelerationProfile is generated according to the timeacceleration data in TimeAcceleration, the velocity will be 100 after one second of execution, position 180 after two seconds and so on. When executes after 5 seconds, the position should be -100.

Supported Products

AX-308E, AX-8, AX-364E

2.1.14 MC_Jog

MC_Jog enables an axis to be moved forward or backward.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Jog	MC_Jog Axis AXIS_REF_SM3 BOOL Busy JogForward BOOL BOOL CommandAborted JogBackward BOOL BOOL CommandAborted Velocity LREAL SMC_Error ErrorId Acceleration LREAL Deceleration LREAL Jerk LREAL	MC_Jog_instance (Axis :=, JogForward:=, JogBackward:=, Velocity :=, Acceleration :=, Deceleration :=, Jerk :=, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
JogForward	JogForward changes from FALSE to TRUE.	BOOL	True/False (False)	-
JogBackward	JogBackward changes from FALSE to TRUE	BOOL	True/False (False)	-
Velocity	The target velocity (Unit: user unit/s)	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.
Acceleration	Acceleration rate. (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	Deceleration rate. (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Jerk	Jerk value. (Unit: user unit/s3)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Busy	True when the	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
	instruction is executed.		
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

* Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Busy	 True when JogForward or JogBackward shifts to True. 	 When Error shifts to True. When CommandAborted shifts to True. When status is standstill and there's no complementarity between the status of JogForward and JogBackward.
CommandAborted	 True when the instruction is aborted. 	 When JogForward and JogBackward shift to False.
Error	• When an error occurs in the	When JogForward and
ErrorID	values for the instruction.	False.(Error code is cleared)

In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When JogForward or JogBackward shift to True.

* **Note:** AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

MC_Jog starts a continuous movement with the specified Velocity, while JogForward and JogBackward determine on the direction of axis movement (negative or positive).

JogForward	JogBackward	Movement
False	False	Motionless
True	False	Jog in positive direction
False	True	Jog in negative direction
True	True	Motionless

When changing the direction, MC_Jog will reread the Input parameter settings to perform Jog operation.



- The following description is with reference to the above figure:
 - When JogFoward is True and JogBackward is False, the axis starts to move in positive direction, which the status is continuous_motion.
 - When JogFoward is False and JogBackward is True, the axis starts to move in negative direction, which the status is discrete_motion.
 - When decelerating to reach 0 velocity, the status will shift to Standstill, then the axis starts to accelerate in negative direction and change the status to continuous_motion; at the same time, Busy is still True.
 - When both JogForward and JogBackward are True, the axis will accelerate/ decelerate to reach 0 velocity, the status would be discrete_motion.
 - When both JogForward and JogBackward are True, the axis will stop moving and the status would be Standstill with Busy output changing from Busy to False.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.15 MC_GearIn

The function block MC_GearIn activates a linear master-slave coupling.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_GearIn	MC_GearIn Master AXIS_REF_SM3 BOOL InGear Slave AXIS_REF_SM3 BOOL Busy Execute BOOL BOOL CommandAborted RatioNumerator DINT BOOL Error RatioDenominator UDINT SMC_ERROR ErrorID Acceleration LREAL Deceleration LREAL Jerk LREAL Jerk LREAL	MC_GearIn_instance (Master :=, Slave :=, Execute :=, RatioNumerator :=, RatioDenominator :=, Acceleration :=, Deceleration :=, Jerk :=, InGear =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
RatioNumerator	Gear ratio numerator* between master and slave axis.	DINT	Negative number, positive number or 0(1)	When Execute shifts to True and Busy is False.
RatioDenominator	Gear ratio denominator* between master and slave axis [.]	UDINT	Positive number(1)	When Execute shifts to True and Busy is False.
Acceleration	Acceleration rate. (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Jerk	Jerk value. (Unit: user unit/s³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.

*Note: A negative gear ratio will make the master and slave axis move in an opposite direction.

• Outputs

Name	Function	Data Type	Output Range (Default Value)
InGear	True if the coupling was successful.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
InGear	• When the slave axis reaches the target velocity and the coupling is successful.	 When <i>Error</i> shifts to True. When CommandAborted shifts to True. When the gear ratio changes.
Busy	 When the coupling is processed. 	 When Error shifts to True. When CommandAborted shifts to True.
CommandAborted	 When MC_GearOut is executed. True when the instruction is aborted by another function block. When this instruction is aborted because of the execution of MC_Stop instruction. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False.
Error ErrorID	 When an error occurs in the execution conditions or input values for the instruction. 	 When Execute shifts from True to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Master	Specifies the master axis number.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Execute</i> shifts to True and Busy is False.
Slave	Specifies the slave axis number.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Execute</i> shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- In MC_GearIn, slave axis will follow master axis to move at the Set Position.
- When Execute is True, The target speed of slave axis is the velocity of master axis times gear ratio (Velocity * RatioNumerator / RatioDenominator)



- After the gear relation is established, slave axis will follow master axis to move at the given proportional relationship to accomplish the synchronized control of master and slave axis. Master and slave axis could be real or virtual axis or the external encoder master axis.
 - RatioNumerator, RatioDenominator

 \succ When the value of gear ratio is positive, the master and slave axis move in same direction.



> When the value of gear ratio is negative, the master and slave axis move in opposite direction.



Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Supported Products

AX-308E, AX-8, AX-364E

2.1.16 MC_GearOut

MC_GearOut disconnects the gear relation (velocity) between master and slave axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_GearOut	MC_GearOut — Slave AXIS_REF_SM3 BOOL Done — Execute BOOL Busy BOOL Error SMC_ERROR ErrorID	MC_GearOut_instance (Slave :=, Execute :=, Done =>, Busy =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when the gear disconnection is completed.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When the gear disconnection is completed. 	 When Execute changes to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. When <i>Error</i> shifts to True.
Busy	• When Execute changes to True.	 When <i>Done</i> shifts to True. When <i>Error</i> shifts to True.
Error	• When an error occurs in the	
ErrorID	for the instruction.(Error code is recorded)	• When Execute shifts from True to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Slave	Slave axis number	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

After the gear relationship is disconnected, the slave axis will keep moving at the speed where the gear relationship is disconnected. The axis will be in ContinuousMotion (it has nothing to do with the axis velocity)

MC_GearOut			1
Execute			
Done			
Busy			
Error			
Slave State Machine	Synchronized motion(6)	Continuous motion(5)	

- When the slave axis is out of sync and the velocity is zero, the status will be continuous_motion and remain unchanged.
- The sequence for execution of the instructions related to electronic gear.



Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

The following example describes the corresponding motion state throughout the gear operation via gear-related instructions.

Chapter 2



Chapter 2

Timing Diagram



- When Execute of MC_MoveVelocity changes to True, master axis starts to move.
 - When M1 Execute of MC_GearIn changes to True, the slave axis starts to catch the master axis.
 - If the velocity of salve axis reaches doubled master axis' velocity (RatioNumerator: RatioDenominator = 2:1), *InGear* of MC_GearIn will change to True. After the master axis is synchronized with slave axis, the state of slave axis shifts to Synchronized Motion.
 - When Execute of MC_Stop changes to True, the master axis starts to decelerate. At the same time, the slave axis also decelerates based on the gear ratio.
 - In the process of the MC_Stop execution, when Execute of MC_GearOut changes to True, master and slave axis will be under asynchronous status and slave axis will keep moving at the speed (Continuous Motion state) when the gear relation is decoupled.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.17 MC_GearInPos

MC_GearInPos commands position synchronization which is achieved over a defined region of travel for both master and slave axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_GearInPos	MC_GearInPos Master AXIS_REF_SM3 BOOL StartSync – Slave AXIS_REF_SM3 BOOL InSync – Execute BOOL BOOL BUSY – RatioNumerator DINT BOOL CommandAborted – RatioDenominator DINT BOOL CommandAborted – MasterSyncPosition LREAL SMC_ERROR ErrorID – SlaveSyncPosition LREAL MasterStartDistance LREAL AvoidReversal BOOL	MC_GearInPos_instance (Master :=, Slave :=, Execute :=, RatioNumerator :=, RatioDenominator :=, MasterSyncPosition :=, SlaveSyncPosition :=, MasterStartDistance :=, AvoidReversal :=, StartSync =>, InSync =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
RatioNumerator	Gear ratio numerator* between master and slave axis.	DINT	Negative number, positive number or 0(1)	When Execute shifts to True and Busy is False.
RatioDenominator	Gear ratio denominato* between master and slave axis [.]	UDINT	Positive number or 0(1)	When Execute shifts to True and Busy is False.
MasterSyncPosition	Master Position at which the axes are synchronized.	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.
SlaveSyncPosition	Slave Position at which the axes are synchronized.	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.
MasterStartDistance	Master Distance for synchronization procedure.	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.
AvoidReversal	Reversal is not allowed.	BOOL	True/False(False)	When Execute shifts to True and Busy is False.

*Note: A negative gear ratio will make the master and slave axis move in an opposite direction.

• Outputs

Name Function		Data Type	Output Range (Default Value)
StartSync	True when the synchronization starts.	BOOL	True/False(False)
InSync	True when the synchronization is ongoing.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)	
	aborted.			
Error	True when an error occurs.	BOOL	True/False(False)	
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)	

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False		
StartSync	• When master axis travels to the start position.	 When <i>InSync</i> shifts to True. When <i>Error</i> shifts to True. 		
InSync	• When the synchronization between master and slave axis is completed.	 When <i>CommandAborted</i> shifts to True. When <i>Error</i> shifts to True. 		
Busy	 After the synchronization begins. 	 When <i>CommandAborted</i> shifts to True. When <i>Error</i> shifts to True. 		
CommandAborted	 When MC_GearOut is executed. True when the instruction is aborted by another function block. When this instruction is aborted because of the execution of MC_Stop instruction. 	 When Execute changes to False. If Execute is False and CommandAborted shifts to True, it will be True for only one period and immediately shift to False. 		
Error	• When an error occurs in the execution conditions or input values for the instruction.	• When Execute shifts from True to False. (Error code is cleared)		

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Master	Specifies the master axis number.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Execute</i> shifts to True and Busy is False.
Slave	Specifies the slave axis number.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Execute</i> shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- Position where the master axis executes StartSync = MasterSyncPosition MasterStartDistance.
- It's a must to ensure an appropriate parameter settings of sync position if both master and slave axis are working under Finite mode. Supposed the master and slave axis moving in the positive direction, if the master axis position missed the StartSync position, the gear would not be able to run normally. Therefore, it is suggested to set the master and slave axis operating under Modulo mode.
- During the progress of synchronization between the master and slave axis, MC_GearInPos begins to plan the motion path of slave axis automatically with gear ratio based on parameters of the position where master axis executes StartSync, MasterSyncPosition and SlaveSyncPosition. After synchronizing complete, slave axis will start to move by following master axis.
- When MasterStartDistance = 0 or being negative, CAM motion will be completed immediately.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You

can refer to ErrorID (Error Code) to address the problem.

• Example

■ The following example describes the corresponding motion state throughout the gear operation via MC_GearInPos-related instructions.

1	MC_MoveVelocity_0			MC_GearIn	Pos_0		
TRUE MC MoveVelocity				MC GearInPos			
	EN	eno —		EN	ENO		
SM_Drive_Virtual_X	Axis InVeloc	ity —	SM_Drive_Virtual_X - 🖽	Master	StartSync -		
	Execute B	usy —	SM_Drive_Virtual_Y 🖴	Slave	InSync -		
300 —	Velocity CommandAbor	ted -		Execute	Busy-		
2000 —	Acceleration Er	ror –	1 —	RatioNumerator	CommandAborted -		
2000 —	Deceleration Erro	rID —	1 —	RatioDenominator	Error -		
0 —	Jerk		180 —	MasterSyncPosition	ErrorID-		
1 —	Direction		90 —	SlaveSyncPosition			
			50 —	MasterStartDistance			
			FALSE -	AvoidReversal			
	MC GearOut 0						
TRUE	MC GearOut						
	EN ENO						
SM Drive Virtual Y	Slave Done -						
	Execute Busy-						
	Error -						
ErrorID-							

Timing Diagram

Position			_			-
¹⁸⁰ Master 0						
Slave ₉₀						
ں MC_MoveVelocity						
Execute						
InVelocity						
Busy						
CommandAborted						
Error						
MC_GearInPos						
Execute						
StartSync						
InSync						
Busy						
CommandAborted						
Error						
MC_GearOut						
Execute						
Done						
Busy						
Error						
		continuous motio	n(5)			
Master_StateMachine	<u>standstilk(3)</u>					
Slave_StateMachine		standstill(3)		Sy	nchranized motion(6)	continuous motion(5)

- When *Execute of* MC_MoveVelocity shifts to True, the master axis starts to move.
- When *Execute of* MC_GearInPos shifts to True, it's waiting for master axis to reach StartSync position.
- When StartSync position is reached, OutputsStartSync of MC_GearInPos shifts to True. At the same time, a motion curve is planned for slave axis to move, which the axis would enter Synchronized Motion state.
- When both master and slave axis reach the synchronization position, Outputs*InSync* of MC_GearInPos shifts to True and Outputs*StartSync* changes to False.
- When *Execute* of MC_GearOut shifts to True, the master and slave axis move asynchronously, entering Continuous Motion state.

• Supported Products

AX-308E, AX-8, AX-364E

2.1.18 MC_Phasing

MC_Phasing specifies the phase shift value between the master and slave axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Phasing	MC_Phasing Master AXIS_REF_SM3 BOOL Done Slave AXIS_REF_SM3 BOOL Busy Execute BOOL BOOL CommandAborted PhaseShift LREAL BOOL Error Velocity LREAL SMC_ERROR ErrorID Acceleration LREAL Jerk LREAL	MC_Phasing_instance (Master :=, Slave :=, Execute :=, PhaseShift :=, Velocity :=, Acceleration :=, Deceleration :=, Jerk :=, Done =>, Busy =>, CommandAborted =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
PhaseShift	Phase shift amount between master and slave axis [*]	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Velocity	The max velocity of the phase shift amount (Unit: user unit/s)	LREAL	Positive number or 0(0)	When Execute shifts to True and Busy is False.
Acceleration	The max acceleration of the phase shift amount (Unit: user unit/s²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Deceleration	The max deceleration of the phase shift amount (Unit: user unit/s ²)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.
Jerk	The max Jerk value of the phase shift amount (Unit: user unit/s ³)	LREAL	Positive number(0)	When Execute shifts to True and Busy is False.

* **Note:** In case of positive values, the slave axis is behind the master axis. Conversely, the slave axis is ahead of the master axis when the value is negative.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when phasing operation is completed.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
CommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

* Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	o True Timing for Shifting to False	
Done	 When the phasing operation is completed. 	 When Execute changes to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	• When the phasing operation is executed.	 When <i>Error</i> shifts to True. When <i>CommandAborted</i> shifts to True. 	
CommandAborted	 When this instruction is aborted by another instruction with the Buffer Mode set to Aborting. When this instruction is aborted because of the execution of MC_Stop instruction. 	 When <i>Execute</i> changes to False. If <i>Execute</i> is False and <i>CommandAborted</i> shifts to True, it will be True for only one period and immediately shift to False. 	
Error	When an error occurs in the execution conditions or input	• When <i>Execute</i> shifts from True to False. (Error code is	
ErrorID	values for the instruction.	cleared)	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Master	Specifies the master axis number.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
Slave	Specifies the slave axis	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
	number.			

* **Note:** AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- When Execute shifts to True and the master-slave axis relation is established, the slave axis will shift the phase by planning a smooth curve. In case of a positive PhaseShift value, the slave axis is behind the master axis. Conversely, the slave axis is ahead of the master axis when the value is negative.
- The position of master axis remains unchanged while MC_Phasing acts on the slave axis



- MC_Phasing can be used when the state is not under Synchronized motion.
 - When MC_Phasing is executed, the state of slave axis will remain as Synchronized motion.
 - When executes MC_Phasing before establishing gear relationship between the master and slave axis, the slave axis will be directly synchronized with the master axis and both move based on the gear ratio which is 1:1.
 - When the slave axis executes MC_Phasing, it can be aborted by other single-axis function blocks and the synchronous relationship will be disconnected.

• Troubleshooting

- If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.
- Example
 - The following example describes the corresponding motion state and path throughout

the gear operation.



Timing Diagram



- Execute MC_MoveVelocity to make the master axis run at a constant speed, then execute MC_GearIn to establish gear relationship between the master and slave axis.
- When Execute of MC_Phasing shifts to True, the relationship between the two axes will be disconnected. MC_Phasing shifts the phase of the slave axis by the specified PhaseShift value.
- When the slave axis reaches the specified value, Done of MC_Phasing shifts to True and the Busy output is reset.

Supported Products

AX-308E, AX-8, AX-364E

2.2 Administrative Motion Control Instructions

Administrative motion control instructions refer to the actions of configuring corresponding setting and retrieving relating information made for drivers, which would not cause actual displacement of motors. The function blocks used in this chapter are from the library "SM3_Basic" and able to operate synchronously with drives. As a result, synchronous axis type should be selected in axis settings. For more details about configuration related to synchronous axes, please refer to section 7.4 in AX-3 Series Operational Manual.

2.2.1 MC_Power

MC_Power enables or disables the specific axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Power	MC_Power Axis AXIS_REF_SM3 BOOL Status Enable BOOL BOOL BOOL bRegulatorRealState bRegulatorOn BOOL BOOL BOOL BUOL Buoy bDriveStart BOOL Error BOOL Error SMC_ERROR ErrorID	MC_Power_instance (Axis :=, Enable :=, bRegulatorOn:=, bDriveStart :=, Status =>, bRegulatorRealState =>, bDriveStartRealState =>, Busy =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
bRegulatorOn	Enables the power	BOOL	True/False(False)	Only when <i>Enable</i> =True.
bDriveStart	Controls the QuickStop mechanism.	BOOL	True/False(False)	Only when <i>Enable</i> =True.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Status	The specific axis is ready	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
	to be moved by the function blocks.		
bRegulatorRealState	The power is turned ON.	BOOL	True/False(False)
bDriveStartRealState	Quick stop function is applicable on the device.	BOOL	True/False(False)
Busy	Function block is operating.	BOOL	True/False(False)
Error	Errors occur in function block.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Status	 When Enable is true upon detection of rising edge for both bRegulatorRealState and bDriveStartRealState. 	 When Enable is true, as well as bRegulatorRealState or bDriveStartRealState shifting to False. When Error shifts to True.
bRegulatorRealState	 When Enable is true upon detection of rising edge for bRegulatorRealState. 	 When Enable is true, as well as bRegulatorRealState being falling edge. When Error shifts to True.
bDriveStartRealState	 When Enable is true, as well as both bRegulatorRealState and bDriveStartRealState being True. 	 When Enable is true, as well as bRegulatorRealState or bDriveStartRealState shifting to False.
		 When Error shifts to True.

Chapter 2

Name	Timing for Shifting to True	Timing for Shifting to False
Busy	When Enable shifts to true	 When Enable shifts to False. When Error shifts to True.
Error	When errors occur in the executing conditions or the input	When errors are moved
ErrorID	values.	

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Enable</i> shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- When Enable is True, bRegulatorOn and bDriveStart are effective.
- When Enable, bRegulatorOn and bDriveStart are True, Status shifts to True and nAxisState shifts to standstill.
- When Enable and bRegulatorOn are True, set DriveStart to be False which nAxisState(axis status) shifts to Stopping.
- When Enable and bDriveStart are True, set RegulatorOn to be False which nAxisState(axis status) directly shifts to Disabled.
- Timing Diagram

nAxisState	power off(0)	standstill(3)	stopping(2)		
Enable					
bRegulatorOn					
bDriveStart					
Busy					
Status					
bRegulatorRealStatus					
bDriverStartStatus					

Troubleshooting

If an error occurs while executing the instruction or the axis is in Errorstop state, Error shifts to True and the axis will be decelerated to a stop. You can refer to ErrorID (Error Code) to address the problem.

Example:

Example1: The following example explains the movement of a moving axis when bRegulatorOn of MC_Power shifts to False.



Timing Diagram

Position			
Velocity ₀			
Acceleration 0			
MC_Power			
Enable			
bRegulatorOn	 		
bDriveStart			
Status	 		
bRegulatorRealState			
bDriveStartRealState			
MC_MoveVelocity			
Execute			
InVelocity			
Busy			
Command Aborted			
Error	 		
		continuous motion(5)	
State Machine	 standstill(3)		errorstop(1)

- Shift bRegulatorOn of MC_Power from True to False while the axis is moving so as to stop the axis immediately.
- At the same time an error of SMC_REGULATOR_OR_START_NOT_SET(20) occurs in MC_MoveVelocity and the axis state directly switches from continuous_motion to errorstop.
- Example2: Continue with the example 1, the following example explains the movement of a moving axis when *bDriveStart* of MC_Powers shifts to False.

Timing Diagram

Position _o			
Velocity _o			
MC_Power			
Enable			
bRegulatorOn			
bDriveStart	 		
Status			
bRegulatorRealState			
bDriveStartRealState			
MC_MoveVelocity			
Execute			
InVelocity			
Busy			
Command Aborted			
Error			
		continuous motion(5)	
State Machine	 standstill(3)		stopping(2)

- Shift *bDriveStart* of MC_Power from True to False while the axis is moving. Such action would stop the axis immediately.
- CommandAbort shifts to True and aborts MC_MoveVelocity, while the axis state swiches from continuous_motion to stopping.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.2 MC_SetPosition

MC_SetPositionn changes the current position by shifting the coordinates of an axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_SetPosition	MC_SetPosition Axis XXIS_REF_SM3 BOOL Done Execute BOOL BUSY Position LREAL BOOL Error Mode BOOL SMC_ERROR ErrorID	MC_SetPosition_instance(Axis :=, Execute :=, Position :=, Mode :=, Done =>, Busy =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (True)	-
Position	Axis position (User-defined unit)	LREAL	Positive number, negative number or 0(0)	When Execute shifts to True and Busy is False.
Mode	Specify relative position (True) or absolute position(False)	BOOL	True/False (False)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when finishes coordinate modification.	BOOL	True/False(False)
Busy	True when the instruction is executing.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

Name	Function	Data Type	Output Range (Default Value)
	Refer to Appendices for error code descriptions.		

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When the modification to coordinate is completed. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	• When <i>Execute</i> is rising edge triggered.	When <i>Done</i> shifts to True.When <i>Error</i> shifts to True.
Error	When an error occurs in the execution conditions or input	When Execute shifts from True
ErrorID	values for the instruction.	to False.(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- When configure the parameters of axis position via MC_Position, there's no displacement made by axis itself but instead only the coordinate system moves.
- To avoid possible position jumps occur to the slave axis, you should avoid executing

MC_SetPosition to the synchronized master axis, or discontinuous jumps in velocity would exists in the slave axis.

The value of Position would be added directly to the current position under relative mode, which would be the new location coordinate. For the absolute position, the value of Position would be set to the current location coordinate.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

Example1: Demonstrate the condition of executing MC_MoveAbsolute while using MC_SetPosition to change the coordinate system under relative mode.



Timing Diagram



- After MC_MoveAbsolute is executed, use MC_SetPosition to define a new coordinate system under relative mode.
- When detect a rising edge of Execute of MC_SetPosition, the new location of the axis would be 3135 after adjusting the coordinate system, which the axis was originally located at 2135.
- Done is rising edge when the execution of MC_MoveAbsolute is completed and the current position would be at 6000. At this time, MC_MoveAbsolute still moves to 5000 on the old coordinate system, which would become 6000 after the coordinate adjustment.
- Example2: Demonstrate the condition of executing MC_MoveAbsolute while using MC_SetPosition to change the coordinate system under absolute mode.



Timing Diagram



- After MC_MoveAbsolute is executed, use MC_SetPosition to define a new coordinate system under absolute mode.
- When detect a rising edge of Execute of MC_SetPosition, the new location of the axis would be 1000 after adjusting the coordinate system by moving a distance of 1123, which the axis was originally located at 2123.
- Done is rising edge when the execution of MC_MoveAbsolute is completed and the current position would be at 3877(5000 - 1123). At this time, MC_MoveAbsolute

still moves to 5000 on the old coordinate system, which would become 3877 after the coordinate adjustment.

Example3: Demonstrate the condition of executing MC_MoveRelative while using MC_SetPosition to change the coordinate system under relative mode.



Timing Diagram



- After MC_MoveRelative is executed, use MC_SetPosition to define a new coordinate system under relative mode.
- When detect a rising edge of Execute of MC_SetPosition, the new location of the axis would be 3175 after adjusting the coordinate system, which the axis was originally located at 2175.
- Done is rising edge when the execution of MC_MoveAbsolute is completed and the current position would be at 6000. At this time, MC_MoveAbsolute still moves to 5000 on the old coordinate system, which would become 6000 after the coordinate adjustment.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.3 MC_ReadParameter

MC_ReadParameter reads a value of a specific axis parameter.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadParameter	MC_ReadParameter — Axis AXIS_REF_SM3 BOOL Valid — Enable BOOL Busy — ParameterNumber DJNT BOOL Error SMC_ERROR ErrorID 	MC_ReadParameter_instance (Axis :=, Enable :=, ParameterNumber :=, Valid =>, Busy =>, Error =>, ErrorID =>, Value =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False (False)	-
ParameterNumber	Number of the parameter to be read.	DINT	Positive number, negative number or 0(0)	When <i>Enable</i> is detected to be rising edge.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Error codes.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)
Value	Value of the parameter to read.	LREAL*2	Positive number, negative number or 0(0)

*Note: SMC_ERROR: Enumeration(Enum)

Name	Timing for Shifting to True	Timing for Shifting to False
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Busy	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Error	When an error occurs in executing conditions or input	When Execute shifts from True to
ErrorID	values.	False.(Error code is cleared)
Value	 When Valid is True and there're ongoing updates. 	 When Valid is False and stop updating.

Output Updating Time

• Timing Diagram



*Note: Data = parameter's value. 1 cycle = one task period

• In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Enable</i> is rising edge.

***Note:** AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- How to use MC_ReadParameter to read the parameter values of desired object with its parameter number in EtherCAT Object Dictionary:
 - Use SHL instruction to move the data length of desired object to the left for 24 bits.

- Use SHL instruction to move the index of desired object to the left for 8 bits.
- The input ParameterNumber must contains the data length the index and the subindex. Please refer to the following formula:

ParameterNumber := - DWORD_TO_DINT(SHL(TO_DWORD(data length of object dictionary), 24) + SHL(TO_DWORD(index of object dictionary), 8) + object sub-index);

To read axis parameters, you'll need to enter the parameter number of AXIS_REF_SM3(FB) to ParameterNumber input.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

This example demonstrates how to use MC_ReadParameter to read the value of object 0x6064(current position returned by motor) in the drive.

MC_ReadParameter_0	
TRUE MC_ReadParameter	
EN ENO	
SM_Drive_ETC_Delta_ASDA_A2 - Axis Valid - TRUE	
E2 TRUE Enable Busy TRUE	
ParameterNumber -73425920 ParameterNumber Error - FA652	
ErrorID - SMC_NO_ERR	
Value - 1.26E+05 >	
TRUE EXECUTE	
	ENO
//usiDataLength : Number of bytes (1,2,4) to be written.	
ParameterNumber := - DWORD_TO_DINT(SHL(TO_DWORD(4), 24)+ SHL(TO_DWORD(16#6064), 8) +	+ 0);

- Input the data length, index, and subindex of the object to the above formula and you'll get the ParameterNumber, which should be entered to the ParameterNumber input. After that, every time when the FB MC_ReadParameter is executed, it will visit the object dictionary specified by the drive and return the values.
- The following figure shows the information related to the parameters of object 0x6064.

Object 6064 _h : Position actual value			
INDE	х	6064 _h	
Name)	Position actual value	
Objec	t Code	VAR	
Data	Туре	INTEGER32	
Access PDO Mapping		RO	
		Yes	
Value	Range	INTEGER32	
Defau	ılt Value	0	
Comr	ment	單位:PUU	

• Supported Products

AX-308E, AX-8, AX-364E

2.2.4 MC_WriteParameter

MC_WriteParameter writes a value to a specific parameter.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_WriteParameter	MC_WriteParameter — Axis AXIS_REF_SM3 BOOL Done — — Execute BOOL Busy — ParameterNumber DINT BOOL Error — Value LREAL SMC_ERROR ErrorID —	MC_WriteParameter_instance(Axis :=, Execute :=, ParameterNumber :=, Value :=, Done =>, Busy =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	Execute the function block.	BOOL	True/False (False)	-
ParameterNumber	Number of the parameter to be written.	DINT	Positive number, negative number or 0(0)	When Execute shifts to True and Busy is False.
Value	Value to be written to the parameter.	LREAL	Positive number, negative number or 0(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True if the value is written successfully.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	• When the value is written successfully.	• When <i>Execute</i> shifts from True to False.
Busy	 When <i>Execute</i> is rising edge triggered. When the value is being written to the parameter. 	 When <i>Done</i> shifts to True. When <i>Error</i> shifts to True.
Error	When an error occurs in the execution conditions or input values for the	When Execute shifts from True
ErrorID	instruction.	to False.(Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- How to use MC_ReadParameter to read the parameter values of desired object with its parameter number in EtherCAT Object Dictionary:
 - Use SHL instruction to move the data length of desired object to the left for 24 bits.
 - Use SHL instruction to move the index of desired object to the left for 8 bits.
 - The input ParameterNumber must contains the data length the index and the subindex. Please refer to the following formula:

ParameterNumber := - DWORD_TO_DINT(SHL(TO_DWORD(data length of object dictionary), 24) + SHL(TO_DWORD(index of object dictionary), 8) + object sub-index);

- To write the value to the parameter, you'll need to input the parameter number of AXIS_REF_SM3(FB) to ParameterNumber.
- Write parameter values to the input fSetPosition by using MC_WriteParameter while the axis is moving. The value of fSetPosition is changed for only one task cycle time in EtherCAT, then fSetPosition resumes its original planned motion curve to move.
- Troubleshooting
 - If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

This example demonstrates how to use MC_WriteParameter to write the value to the object 0x6060(operation mode) in the drive.

TRUE EN I //u Par	EXECUTE siDataLength : Number of bytes (1,2,4) to be written. ameterNumber := - DWORD_TO_DINT(SHL(TO_DWORD(1), 24)+ SHL(TO_DWORD(16#6060), 8)	ENO + 0);
TRUE	MC_WriteParameter_0 MC_WriteParameter	
SM_Drive_ETC_Delta	ASDA_A2 - Axis Done TRUE E2 TRUE Execute Busy FALSE -23093248 ParameterNumber Error FALSE 6 Value ErrorID SMC_NO_ERR	

- Input the data length, index, and subindex of the object to the above formula and you'll get the ParameterNumber, which should be entered to the ParameterNumber input. After the value is written to MC_WriteParameter successfully, the control mode of the drive will change to 6.
- The following figure shows the information related to the parameters of object 0x6060

Object 6060h: Modes of operation

6060 _h
Modes of operation
VAR
INTEGER8
RW
Yes
INTEGER8
0
0: Reserved

• Supported Products

■ AX-308E, AX-8, AX-364E

2.2.5 MC_ReadBoolParameter

MC_ReadBoolParameter reads the value of a specific Boolean parameter.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadBoolParameter	MC, ReadBoolParameter Axis AVS.REE.SKG Enable ROOL ParameterNumber DRVT ROOL Fror- BOOL Value-	MC_ReadBoolParameter_instance(Axis :=, Enable :=, ParameterNumber :=, Valid =>, Busy =>, Error =>, ErrorID =>, Value =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False(False)	-
ParameterNumber	Number of the specific Boolean parameter	DINT	Positive number, negative number or 0(0)	When <i>Enable</i> shifts from False to True.

• Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Error codes.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)
Value	Value of the parameter to read.	BOOL	True/False(False)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Busy	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Error	When an error occurs in executing conditions or input	When Execute shifts from True
ErrorID	values.	to False.(Error code is cleared)
Value	 When Valid is True and there're ongoing updates. 	 When Valid is False and stop updating.

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Enable</i> shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

- How to use MC_ReadBoolParameter to read the parameter values of desired object with its parameter number in EtherCAT Object Dictionary:
 - Use SHL instruction to move the data length of desired object to the left for 24 bits.
 - Use SHL instruction to move the index of desired object to the left for 8 bits.
 - The input ParameterNumber must contains the data length the index and the subindex. Please refer to the following formula: ParameterNumber: = - DWORD_TO_DINT (SHL (TO_DWORD(data length of object dictionary), 24) + SHL(TO_DWORD(index of object dictionary), 8) + object sub-index);
- For operation example, please refer to the example in MC_ReadParameter.
- To read axis parameters, you will need to enter the parameter number of AXIS_REF_SM3 (FB) to ParameterNumber input.

• Troubleshooting

- If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.2.6 MC_WriteBoolParameter

MC_WriteBoolParameter writes a Boolean value to a specific parameter.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_WriteBool Parameter	MC_WriteBoolParameter Axis AXIS_REF_SMB BOOL Done Execute BOOL Busy ParameterNumber DINT BOOL Error Value BOOL SMC_ERROR ErrorID	MC_WriteBoolParameter_instance(Axis :=, Execute :=, ParameterNumber :=, Value :=, Done =>, Busy =>, Error =>, Error =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	Execute the function block.	BOOL	True/False (False)	-
ParameterNumber	Number of the parameter to be written.	DINT	Positive number, negative number or 0(0)	When Execute shifts to True and Busy is False.
Value	Boolean value to be written to the parameter.	BOOL	True/False (False)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True if the Boolean value is written successfully.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

Name	Function	Data Type	Output Range (Default Value)
	Refer to Appendices for error code descriptions.		

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When the value is written successfully. 	• When <i>Execute</i> shifts from True to False.
Busy	 When <i>Execute</i> is rising edge triggered. When the value is being written to the parameter. 	 When <i>Done</i> shifts to True. When <i>Error</i> shifts to True.
Error	When an error occurs in the execution conditions or input	When Execute shifts from True
ErrorID	values for the instruction.	to False.(Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- How to use MC_WriteBoolParameter to write the parameter value to the desired object with its parameter number in EtherCAT Object Dictionary:
 - Use SHL instruction to move the data length of desired object to the left for 24 bits.

• Use SHL instruction to move the index of desired object to the left for 8 bits.

The input ParameterNumber must contains the data length the index and the subindex. Please refer to the following formula:

ParameterNumber := - DWORD_TO_DINT(SHL(TO_DWORD(data length of object dictionary), 24) + SHL(TO_DWORD(index of object dictionary), 8) + object sub-index);

- To write the value to the parameter, you'll need to enter the parameter number of AXIS_REF_SM3(FB) to ParameterNumber input.
- For operation example, please refer to the example in MC_WriteParameter.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.7 MC_ReadActualPosition

MC_ReadActualPosition reads the current axis position.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadActualPosition	MC_ReadActualPosition — Axis AXIS.REF_SN3 BOOL Valid — Enable BOOL Busy BOOL Error — SMC_ERROR ErrorID — LAEAL Position —	MC_ReadActualPosition_instance(Axis :=, Enable :=, Valid =>, Busy =>, Error =>, ErrorID =>, Position =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False (False)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)
Position	The current position of axis	LREAL	Positive number, negative number or 0(0)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name Timing for Shifting to True		Timing for Shifting to False
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Busy	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Error	When an error occurs in executing conditions or input	When Execute shifts from True
ErrorID	values.	to False.(Error code is cleared)
Position	 When Valid is True and there're ongoing updates. 	 When Valid is False and stop updating.

• Timing Diagram

Enable			
Valid			
Busy			
Error		-	

• In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Enable shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

The value read from Position of MC_ReadActualPosition is value of fActPosition in AXIS_REF_SM3.

Enable		
Valid		
Busy		
Error		
Position	0	
fActPosition	0	

While using MC_ReadActualPosition, OD 0x6064(Actual position) must be mapping to TxPDO so as to read the actual position of the servo. If not, the values read by the function block would be 0.

16#1A01 2nd TxPDO Mapping					
Status Word	UINT	16#6041:00			
Position actual value	DINT	16#6064:00			

Troubleshooting

■ If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.8 MC_ReadActualVelocity

MC_ReadActualVelocity reads the actual axis velocity value.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadActual Velocity	MC_ReadActualVelocity Axis AXIS_REF_SM3 BOOL Valid Enable BOOL Busy BOOL Error SMC_ERROR ErrorID LREAL Velocity	MC_ReadActualVelocity_instance(Axis :=, Enable :=, Valid =>, Busy =>, Error =>, ErrorID =>, Velocity =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False (False)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)	
Error	True when an error occurs.	BOOL	True/False(False)	
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)	
Velocity	The current velocity of axis.	LREAL	Positive number, negative number or 0(0)	

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False		
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge. 		
Busy	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge. 		
Error	When an error occurs in executing conditions or input	When Execute shifts from True		
ErrorID	values.	to False.(Error code is cleared)		
Velocity	When <i>Valid</i> is True and there're ongoing updates.	 When Valid is False and stop updating. 		

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Enable shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

The velocity value read by MC_ReadActualVelocity is the value of fActVelocity in AXIS_REF_SM3.



While using MC_ReadActualVelocity, OD 0x606C (Actual velocity) must be mapping to TxPDO so as to read the actual velocity of the servo.

16#1A02 3rd TxPDO Mapping		
Status Word	UINT	16#6041:00
Position actual value	DINT	16#6064:00
Velocity actual value	DINT	16#606C:00

■ If 0x606C is not mapping to TxPDO, the actual velocity of the servo would be calculated based on OD 0x6064(Actual position).

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Supported Products

AX-308E, AX-8, AX-364E
2.2.9 MC_ReadActualTorque

MC_ReadActualTorque reads the actual torque value of axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadActualTorque	MC_ReadActualTorque —Axis AXIS.REF_SN3 BOOL Busy —Enable BOOL Busy BOOL Error SMC_ERROR ErrorID LREAL Torque	MC_ReadActualTorque_instance (Axis :=, Enable :=, Valid =>, Busy =>, Error =>, ErrorID =>, Torque =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False (False)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)
Torque	The actual torque of axis.	LREAL	Positive number or 0(0)

*Note: SMC_ERROR: Enumeration(Enum)

Name	Timing for Shifting to True	Timing for Shifting to False
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Busy	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Error	When an error occurs in executing conditions or input	When Execute shifts from True
ErrorID	values.	to False.(Error code is cleared)
Torque	• When <i>Valid</i> is True and there're ongoing updates.	 When Valid is False and stop updating.

Output Updating Time

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Enable</i> shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- The torque value read by MC_ReadActualTorque is the value of fActTorque in AXIS_REF_SM3.
- While using MC_ReadActualTorque, OD 0x6077 (Torque actual value) must be mapping to TxPDO so as to read the actual torque of the servo.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.10 MC_Reset

MC_Reset clears axis-related errors so that the error memory is available for new error messages.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_Reset	MC_Reset — Axis AXIS_REF_SM3 BOOL Done — Execute BOOL Busy — BOOL Error — SMC_ERROR ErrorID —	MC_Reset_instance (Axis :=, Execute :=, Done =>, Busy =>, Error =>, ErrorID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	Errors are cleared and the status changes to Standstill or Disabled.	BOOL	True/False(False)
Busy	True when the instruction is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

Name	Function	Data Type	Output Range (Default Value)
	Refer to Appendices for error code descriptions.		

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When complete clearing axis- related errors. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	• When <i>Execute</i> is rising edge triggered.	When <i>Done</i> shifts to True.When <i>Error</i> shifts to True.
Error	• When an error occurs in the execution conditions or input	When Execute shifts from True
ErrorID	values for the instruction.	to False.(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When Execute shifts to True and Busy is False.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

• Function

The function block MC_Reset can change the error status of axis back to normal. When Enable of MC_Power is True, the axis status changes from Errorstop to Standstill. When Enable of MC_Power is False, the axis status changes from Errorstop to Disabled.

MC_Reset			
Execute			
Done			
Busy			
Error			
State Machine	ErrorStop(1)	stands	till(3)

- After errors being reported by the servo controller, users can use MC_Reset to clear them and then the axis state will return to Standstill.
- If not able to use MC_Reset to clear the axis errors, such as communication error, SMC_R_ERROR_NOT_RESETTABLE 122 (Error could not be reset.) will be reported by MC_Reset.

Troubleshooting

- If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.2.11 MC_ReadStatus

MC_ReadStatus reads the status of the specified axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadStatus	MC_ReadStatus Axis AXIS_REF_SM3 BOOL Valid Enable BOOL Busy BOOL Error SMC_ERROR ErrorID BOOL Disabled BOOL StandStill BOOL StandStill BOOL ContinuousMotion BOOL ContinuousMotion BOOL ContinuousMotion BOOL ContantVelocity BOOL Accelerating BOOL Accelerating BOOL Decelerating BOOL FBErrorOccured	MC_ReadStatus_instance (Axis :=, Enable :=, Valid =>, Busy =>, Error =>, ErrorID =>, Disabled=>, Errorstop=>, Stopping=>, StandStill=>, DiscreteMotion=>, ContinuousMotion=>, SynchronizedMotion=>, Homing=>, ConstantVelocity=>, Accelerating=>, PBErrorOccured=>);

• Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False (False)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR *1	SMC_ERROR(SMC_NO_ERR OR)
Disabled	Please refer to	BOOL	True/False(False)
Errorstop	* ² for axis state descriptions.	BOOL	True/False(False)
Stopping		BOOL	True/False(False)
StandStill		BOOL	True/False(False)
DiscreteMotion	Please refer to	BOOL	True/False(False)
ContinuousMotion	^{*2} for axis state	BOOL	True/False(False)
SynchronizedMoti on	descriptions.	BOOL	True/False(False)
Homing		BOOL	True/False(False)
ConstantVelocity	True when the axis moves at a constant speed.	BOOL	True/False(False)
Accelerating	True when the axis accelerates.	BOOL	True/False(False)
Decelerating	True when the axis decelerates.	BOOL	True/False(False)
FBErrorOccured	True when an error occurs.	BOOL	True/False(False)

*Note:

1. SMC_ERROR: Enumeration(Enum)

2. SMC_AXIS_STATE: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Busy	 When <i>Enable</i> is rising edge triggered. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.

Name	Timing for Shifting to True	Timing for Shifting to False
Error	When an error occurs in executing conditions or	When Execute shifts from True
ErrorID	input values.	to False.(Error code is cleared)
Disabled	• When the axis is in Disabled state.	 When the axis is not in Disabled state.
Errorstop	 When the axis is in Errorstop state. 	 When the axis is not in Errorstop state.
Stopping	 When the axis is in Stopping state. 	 When the axis is not in Stopping state.
StandStill	 When the axis is in StandStill state. 	 When the axis is not in StandStill state.
DiscreteMotion	• When the axis is in Discrete Motion state.	When the axis is not in Discrete Motion state.
ContinuousMotion	 When the axis is in Continuous Motion state. 	 When the axis is not in Continuous Motion state.
SynchronizedMotion	 When the axis is in Synchronized Motion state. 	 When the axis is not in Synchronized Motion state.
Homing	• When the axis is in Homing state.	• When the axis is not in Homing state.
ConstantVelocity	• When the axis moves at a constant speed.	 When the axis moves at a non- constant speed.
Accelerating	• When the axis moves with acceleration.	When the axis moves without acceleration.
Decelerating	When the axis moves with deceleration.	When the axis moves without deceleration.
FBErrorOccured	When errors exist.	• When errors are cleared.

In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Enable</i> shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

Example

This example demonstrates using MC_ReadStatus to read axis status while executing MC_MoveAbsolute.



Timing Diagram



- After MC_MoveAbsolute being executed, axis state shifts from Standstill to Discrete_motion. At the same time, the axis begins to accelerate and OutputsAccelerating shifts to True.
- When axis velocity reaches the setting in MC_MoveAbsolute, the axis moves at constant speed. Meanwhile, the output of ConstantVelocity shifts to True and OutputsAccelerating shifts to False. Upon moving close to the target position, the axis starts decelerating, which Decelerating shifts to True and ConstantVelocity shifts to False.
- Done of MC_MoveAbsolute shifts to True when the target position is reached. Output status shifts from *Discretemotion* to *Standstill*.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.12 MC_ReadAxisError

MC_ReadAxisError reads the error information of axis.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_ReadAxisError	MC_ReadAxisError Axis AXIS_REF_SM3 BOOL Valid Enable BOOL BOOL BOOL Error SMC_ERROR ErrorID BOOL AxisErrorID BOOL AxisErrorID BOOL SWEndSwitchActive	MC_ReadAxisError_instance (Axis :=, Enable :=, Valid =>, Busy =>, Error =>, ErrorID =>, AxisErrorID =>, SWEndSwitchActive =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	Execute the function block.	BOOL	True/False (False)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Valid	True when the parameter to read exists and can be further processed.	BOOL	True/False(False)
Busy	True when the function block is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

Name	Function	Data Type	Output Range (Default Value)
	Refer to Appendices for error code descriptions.		
AxisError	True if an error occurs in the axis.	BOOL	True/False(False)
AxisErrorID	Error codes specified by the vender.	DWORD	Positive number or 0(0)
SWEndSwitchActive	True when the axis exceeds the software limit.	BOOL	True/False(False)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Valid	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Busy	 When <i>Enable</i> is rising edge triggered. When the parameter to read exists. 	 When <i>Enable</i> shifts from True to False. When <i>Error</i> is rising edge.
Error	When an error occurs in executing conditions or	When Execute shifts from True
ErrorID	input values.	to False.(Error code is cleared)
AxisError	• When an error occurs in	 When the error is removed
AxisErrorID	the axis.	
SWEndSwitchActive	When the axis exceeds the software limit.	When executes MC_Reset.

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>Enable</i> shifts to True.

*Note: AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

Function

- Outputs*SWEndSwitchActive* will shift to True once the axis reaches the software limit.
- AxisErrorID displays the error codes of the servo motor itself. Take ASDA-A2-E for example, when error codes appear in the display on the servo panel, MC_ReadAxisError requests the servo for its error code by giving Error Code(0x603F) and the servo's error code would be displayed on the monitoring screen of axis.

Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

The following example gives the status read by MC_ReadAxisError when the servo reaches hardware limit.



Errors	
Axis Error:	
21570 [16#00005442]	
FB Error:	
SMC_ERROR.SMC_DI_AXIS_ERROR	

When ASDA-A2-E servo touches the positive hardware limit, "AL015" would be displayed on the servo panel. Meanwhile, use MC_ReadAxisError to read the corresponding error code. The error code for AL015 is 0x5442(Please refer to ASDA-A2-E user manual.) AxisErrorID is used to display the error code, which would also be displayed simultaneously on the monitoring screen of axis.

• Supported Products

AX-308E, AX-8, AX-364E

2.2.13 MC_CamTableSelect

MC_CamTableSelect selects the cam table for use with MC_CamIn.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_CamTableSelect	MC_CamTableSelect Master AXIS_REF_SNB BOOL Dure Stave AXIS_REF_SNB BOOL Bury CamTable M_CAM_REF BOOL For Execute BOOL SMC_ERROR ErrorID Periodic BOOL MC_CAM_ID CamTableID MasterAbsolute BOOL MC_CAM_ID CamTableID SlaveAbsolute BOOL SlaveAbsolute BOOL	MC_CamTableSelect_instance (Master :=, Slave :=, CamTable :=, Execute :=, Periodic :=, MasterAbsolute :=, SlaveAbsoulte :=, Done =>, Busy =>, Error =>, ErrorID =>, CamTableID =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input <i>Execute</i> starts the function block.	BOOL	True/False (False)	-
Periodic	Periodic mode	BOOL	True/False	When Execute shifts to

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
			(True)	True and Busy is False.
MasterAbsolute	MasterAbsolute mode	BOOL	True/False (True)	When Execute shifts to True and Busy is False.
SlaveAbsoulte	SlaveAbsoulte mode	BOOL	True/False (True)	When Execute shifts to True and Busy is False.

• Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when the instruction is completed.	BOOL	True/False(False)
Busy	True when the instruction is being BOOL executed.		True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*1	SMC_ERROR(SMC_NO_ERROR)
CamTableID	Create CAM_ID for use by CamTableID of MC_CamIn.	MC_CAM_ID*2	MC_CAM_ID

* Note:

- 1. SMC_ERROR: Enumeration (Enum)
- 2. MC_CAM_ID: Structure (Struct)

Name	Function	Data Type	Output Range (Default Value)
рСТ	The internal information described by the cam table.	POINTER TO BYTE	Positive number or 0(0)
Periodic Periodic mode		BOOL	True/False(True)
MasterAbsolute	MasterAbsolute mode	BOOL	True/False(True)

Name	Function	Data Type	Output Range (Default Value)
SlaveAbsolute	SlaveAbsolute mode	BOOL	True/False(True)
StartMaster	ster position of the LREAL cam table.		Positive number, negative number or 0(0)
EndMaster	The master endEndMasterposition of the camLREALtable.		Positive number, negative number or 0(0)
The slave start StartSlave position of the cam table.		LREAL	Positive number, negative number or 0(0)
EndSlave EndSlave EndSlave The slave end position of the cam table.		LREAL	Positive number, negative number or 0(0)
byCompatibilityMode	Compatibility Mode	BYTE	Positive number or 0(0)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	 When CamTableSelect is completed. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False.
Busy	• When the instruction is being executed.	 When <i>Done</i> shifts to True. When <i>Error</i> shifts to True.
Error	When an error occurs in the execution conditions or input	When Execute shifts from True
ErrorID	values for the instruction.	to False.(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Master	Reference to master axis	AXIS_REF_SM3*1	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
Slave	Reference to slave axis	AXIS_REF_SM3*1	AXIS_REF_SM3	When Execute shifts to True and Busy is False.
CamTable	Specified cam table	MC_CAM_REF*2	MC_CAM_REF	When Execute shifts to True and Busy is False.

*Note:

1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

2. MC_CAM_REF(FB): This data structure is used as reference to a cam table specified by users.

• Function

- Use MC_CamTableSelect to select the cam table for operation.
- Set Execute to be True so as to execute the specified or refreshed cam table. When Done shifts to True, CamTableID is effective.
- After the master-slave synchronization is completed, the modification of MC_CamTableSelect parameters can cause changes in the cam behavior.
 - After changes the variables of CamTable, the mode of cam behavior will be effective immediately.
 - The function block must be reboot after changing Periodic mode.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

- The following example explains the impact on cam after changing Periodic mode.
- Timing Diagram



- To change the periodic mode, *Periodic* of MC_CamTable would be pulled down and shift to False, while the slave axis remains its periodicity.
- After rebooting MC_CamTable, the slave axis enters non-periodic mode. As soon the last period movement performed by the slave axis is completed, *EndOfProfile* will shift to True and remain unchanged.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.2.14 MC_TouchProbe

MC	TouchProbe	records an	axis positior	h at the time	when a trigger	event occurs.
	-					

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_TouchProbe	MC_TouchProbe Axis Axis_REF_SM3 BOOL Done TriggerInput TRIGGER_REF BOOL BOOL WindowOnly BOOL FirstPosition LREAL LastPosition LREAL BOOL CommandAborted	MC_TouchProbe_instance (Axis:=, TriggerInput:=, Execute :=, WindowOnly:=, FirstPosition:=, LastPosition:=, Done =>, Busy =>, Error =>, ErrorID =>, RecordedPosition =>, CommandAborted =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (False)	-
WindowOnly	Activate the scope setting of Window.	BOOL	True/False(False)	When Execute shifts to True and Busy is False.
FirstPosition	Define the start position of the Window mask. (User-defined unit)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.
LastPosition	Define the last position of the Window mask. (User-defined unit)	LREAL	Negative number, positive number or 0(0)	When Execute shifts to True and Busy is False.

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	If the trigger signal is True and the	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
	axis position has been recorded.		
Busy	True when the instruction is being executed.	BOOL	True/False(False)
Error	True when an error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR	SMC_ERROR(SMC_NO_ERROR)
RecordedPosition	Display the axis position recorded at the time of trigger signal being True.	LREAL	LREAL(0)
CommandAborte d	True when the instruction is aborted by MC_AbortTrigger	BOOL	True/False(False)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False	
Done	 When the trigger signal is True and the axis position has been recorded. 	 When Execute shifts from True to False. If Execute is False and Done shifts to True, Done will be True for only one period and immediately shift to False. 	
Busy	 When <i>Execute</i> is rising edge triggered. 	 When <i>Done</i> shifts to True. When <i>Error</i> shifts to True. When <i>CommandAborted</i> shifts to True. 	
Error	When an error occurs in the execution conditions or input	When Execute shifts from True to False (Error code is	
ErrorID	values for the instruction.	cleared)	
CommandAborted	 When the function block is aborted by MC_AbortTrigger. 	 When Execute shifts from True to False. If Execute is False and 	

Name	Timing for Shifting to True	Timing for Shifting to False
		CommandAborted shifts to True, CommandAborted will be True for only one period and immediately shift to False.

In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*1	AXIS_REF_SM3	-
TriggerInput	Trigger signal	TRIGGER_REF*2	TRIGGER_REF(- 1)	When Execute shifts to True and Busy is False.

*Note:

1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.

2. TRIGGER_REF: Structure (STRUCT)

Name	Function	Data Type	Setting range (Default value)
iTriggerNumber	Trigger channel	INT	0:Touch Probe 1, rising edge 1:Touch Probe 1, falling edge 2:Touch Probe 2, rising edge 3:Touch Probe 2, falling edge (-1)
bFastLatching	Trigger signal	BOOL	True: Latching is done in drive False: Latching is done in motion controller (True)
bInput	Trigger signal when bFastLatching=FALSE	BOOL	Trigger signal
bActive	Validity of trigger signal	BOOL	True: Valid (False)

• Function

- Drive mode
 - While using real axes, bFastLatching must be set to True (latching in drive) and configure iTriggerNumber. (The setting value cannot be set as default "-1" or there will be an error in the function block.)

When *Execute* is True, the function block writes values to 0x60B8(Touch Probe Function) based on the setting of *iTriggerNumber* to open the corresponding Trigger channel.

• If Inputs*Execute* of MC_TouchProbe is True, only the first position value of trigger

signal would be captured and the following signal would be ignored, even when bit1 of 0x60B8 is set to 1 to create multiple triggers.

- Under drive mode, RecordedPosition reads the values in 0x60BA(Position value positive edge) and then convert with the gear ratio.
- Controller mode
 - bFastLatching must be set to False and the trigger signal changes to be controlled by blnput.
 - RecordedPosition records the command position and the current command position when blnput triggers signals successfully.



■ The operation of MC_TouhcProbe with window mask function is demonstrated as below:

- At the first activation of the trigger input signal, the signal is not accepted because the axis position hasn't reach the specified window mask section.
- When the axis position enters the window mask section, the second activation of the trigger input signal is accepted, and after a period Done changes to True.
- Time is needed until the touch probe operation is actually activated. The touch probe operation is not possibly to be activated immediately after WindowOnly shifts to True.
- If the window mask is too small, the touch probe operation is not possible. The
 effective range for the window mask depends on EtherCAT communications and
 the performance of encoder input or the servo drive.
- In case that the servo drive does not support the window mask function, an error of SMC_TP_COULDNT_SET_WINDOW(401) will be reported by the function block. (Delta ASDA-A2-E has not yet supported *WindowsOnly* function.)
- Window Mask setting
 - You can observe the results of different window mask settings when the instruction is used for rotary/modulo axes as below. The difference is resulted from the set values between FirstPosition and LastPosition.



- Troubleshooting
 - If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.
- Example
 - Example1: demonstrate the operation result of using MC_TouchProbe under controller mode.

	MC_TouchProbe_0			
TRUE	MC TouchProbe			
[]	EN	ENO		
SM_Drive_Virtual 🛥	Axis	Done —		
TRIGGER_test	TriggerInput	Busy-		
-	Execute	Error -		
TRUE	WindowOnly	ErrorID -		
90 —	FirstPosition	RecordedPosition -		
180 —	LastPosition	CommandAborted -		

TRIGGER_test.bFastLatching := FALSE;

Timing Diagram



- When Execute of MC_TouchProbe changes to True, it starts to capture the signal. Under controller mode, blnput would be the trigger signal.
- At the first activation of the trigger input signal, the axis position is not recorded because the axis position hasn't reached the specified window mask section. The axis has entered window mask section when trigger for the second time, therefore the position would be recorded in the output RecordedPosition.
- Example2: Explain how MC_TouchProbe takes the drive as the trigger signal, which demonstrates with ASDA-A2-E as the drive.



TRIGGER_test.iTriggerNumber := 0;

Wiring diagram



- Trigger signal is from DI13 of CNY extension DI connector. You can start the configuration with the diagram above.
- Trigger channel must be specified by the function block. The following example demonstrates with rising edge trigger.

MC_TouchProbe_0	Expression MC TouchProbe 0.RecordedPosition
TRUE MC TouchProbe	
EN ENO	Type LREAL
SM_Drive_ETC_Delta_ASDA_A2 Axis Done TR	
TRIGGER_test → TriggerInput Busy - 54	Current value 21.0726318359375
TRUE Execute Error FA	ISE What do warman has do?
FALSE WindowOnly ErrorID SMC	NO_ERR What do you want to do?
0 - FirstPosition RecordedPosition -	21.1 → O Prepare a new value for the next write or force operation
0 LastPosition CommandAborted FA	21.0726318359375

🏘 aCaptDesc	ARRAY [07] OF SMC3_CaptureDescription	
WacaptDesc[0]	SMC3_CaptureDescription	
fCaptPosition	LREAL	21.0726318359375
bCaptureOccured	BOOL	FALSE
bStartCapturing	BOOL	FALSE
ø bAbortTrigger	BOOL	FALSE
fFirstCapturePosition	LREAL	0
fLastCapturePosition	LREAL	0
DCaptureWindowActive	BOOL	FALSE
bLatchInController	BOOL	FALSE

When the signal on DI13 of the servo is triggered, MC_TouchProbeOutputsDone would be True. At the same time, MC_TouchProbe reads the value stored in the object 0x60BA(Touch Probe Pos1 Pos Value). After being converted with the gear ratio, the value would be stored in the axis parameter fCaptPosition, which would be output by RecordedPosition.



-Scaling Invert dire	ection	
16#20000	increments <=> motor turns	1
1	motor turns <=> gear output turns	1
1	gear output turns $\langle = \rangle$ units in application	1

- As a result of the gear ratio being set to 0x20000:1, when the drive is rising edge triggered, the value in 0x60BA must be divided with 0x20000. The signal is triggered by the 2762032 index pulses; therefore, the position is recorded at 21.0726318359375(2762032 / 131072).
- Supported Products
 - AX-308E, AX-8, AX-364E

2.2.15 MC_AbortTrigger

MC_AbortTrigger aborts the instruction MC_TouchProbe which are intended to capture trigger events.

FB/FC	Instruction	Graphic Expression	ST language
FB	MC_AbortTrigger	MC_AbortTrigger -Axis AXIS_REF_SM3 BOOL Done -TriggerInput TRIGGER_REF BOOL Busy -Execute BOOL Error SMC_ERROR ErrorID	MC_AbortTrigger_instance (Axis :=, TriggerInput :=, Execute:=, Done =>, Busy =>, Error =>, Error =>,

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Execute	A rising edge of the input Execute starts the function block.	BOOL	True/False (True)	-

Outputs

Name	Function	Data Type	Output Range (Default Value)
Done	True when trigger event is aborted	BOOL	True/False(False)
Busy	True when the instruction	BOOL	True/False(False)

Name	Function	Data Type	Output Range (Default Value)
	is executed.		
Error	True if an error occurs	BOOL	True/False(False)
ErrorID	Indicates the error code when the error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False
Done	• When the capture operation is stopped.	 When Execute shifts from True to False. If Execute is False and Done shifts to True it will be True for only one
		period and immediately shift to False.
Busy	• When <i>Execute</i> shifts to True.	• When <i>Done</i> shifts to True.
		• When <i>Error</i> shifts to True.
Error	• When an error occurs in the execution conditions or input	When Execute
ErrorID	values for the instruction.(Error code is recorded)	shifts from True to False.
		(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3*1	AXIS_REF_SM3	When <i>Execute</i> shifts to True and <i>Busy</i> is False.
TriggerInput	Specifies the reference to the source of the trigger signal.	TRIGGER_REF*2	TRIGGER_REF	When <i>Execute</i> shifts to True and <i>Busy</i> is False.

*Note:

- 1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.
- 2. TRIGGER_REF: Structure(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
iTriggerNumber	Trigger channel	INT	0:Touch Probe 1, rising edge 1:Touch Probe 1, falling edge 2:Touch Probe 2, rising edge 3:Touch Probe 2, falling edge (-1)
bFastLatching	Trigger signal	BOOL	True: Latching is done in drive False: Latching is done in motion controller (True)
bInput	Trigger signal when bFastLatching=FALSE	BOOL	Trigger signal
bActive	Validity of trigger signal	BOOL	True: Valid (False)

• Function

- You can cancel the touch probe operation by using MC_AbortTrigger.
- By setting Axis and TriggerInput for this instruction you can define the touch probe operation to abort.

• Troubleshooting

If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.

• Example

■ This example demonstrates the relating operation of the combination of MC_AbortTrigger and MC_TouchProbe.



TRIGGER_test.bFastLatching := FALSE;

Timing Diagram

MC_TouchProbe	
Execute	
Trigger.Signal	
Done	
CommandAborted	
Busy	
MC_AbortTrigger	
Execute	
Done	
Busy	

- When a rising edge is detected on *Execute* of MC_AbortTrigger, *CommandAborted* of MC_TouchProbe shifts to True.
- If a rising edge is detected on *Execute* of MC_AbortTrigger when *Done* of MC_TouchProbe shifts to True, an error of SMC_AT_TRIGGERNOTOCCUPIED(410) will be reported by MC_AbortTrigger.
- Supported Products
 - AX-308E, AX-8, AX-364E

2.2.16 MC_DigitalCamSwitch

MC	DigitalCamSwitch	uses the avia	position to	control a	switch of a	digital output
		uses life axis	position to	o contior a	SWITCH OF a	ulgital output.

FB/FC	Instruction	Graphic Expression		ST language
FB	MC_DigitalCam Switch	MC_DigitalCamSwitch - Axis AXDS.REF_SAD - Switches MC_CAMSWITCH.REF - Outputs MC_OUTPUT_REF - Tradobions MC_TRACK_REF - Enable BXXX - EnableMaak DWORD - TappetMode MC_TAPPETMODE	BOOL InOperation — BOOL Busy — BOOL Error — SWC_FRRR Errol D — JWT_SwitchCorrupted —	MC_DigitalCamSwitch_instance(Axis :=, Switches :=, Outputs:=, TrackOptions:=, Enable:=, EnableMask:=, TappetMode:=, InOperation =>, Busy =>, Error =>, ErrorID =>, SwitchCorrupted =>);

Inputs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Enable	A rising edge of the input Execute starts the function block.	BOOL	True/False(False)	-
EnableMask	Enable the different tracks.	DWORD	Positive number or 0(16#FFFFFFF)	When <i>Enable</i> shifts to True.
TappetMode	Define the positions for the position- defined calculation of the tappets.	MC_TAPPETMODE*	0:tp_mode_auto 1:tp_mode_demandposition 2:tp_mode_actualposition (tp_mode_auto)	When <i>Enable</i> shifts to True.

*Note: MC_TAPPETMODE: Enumeration(ENUM)

• Outputs

Name	Function	Data Type	Output Range (Default Value)
InOperation	True when the track and instruction is activated.	BOOL	True/False(False)
Busy	True when the instruction is executed.	BOOL	True/False(False)
Error	True if an error occurs	BOOL	True/False(False)
ErrorID	Indicates the error code when the error occurs. Refer to Appendices for error code descriptions.	SMC_ERROR*	SMC_ERROR(SMC_NO_ERROR)
SwitchCorrupted	When the switch action is operated abnormally, the output value will not be -1.	INT	Positive number, negative number or 0 (-1)

*Note: SMC_ERROR: Enumeration(Enum)

Output Updating Time

Name	Timing for Shifting to True	Timing for Shifting to False	
InOperation	• When the track and instruction is activated.	• When <i>Enable</i> shifts to False.	
Busy	• When <i>Execute</i> shifts to True.	When <i>Enable</i> shifts to False.When <i>Errorv</i> shifts to True.	
Error	When an error occurs in the execution conditions or	• When	
ErrorID	input values for the instruction.(Error code is recorded)	<i>Execute</i> shifts from True to False.	
		(Error code is cleared)	

Timing Diagram

Enable			
InOperation			
Busy			
Error			

• In-Outs

Name	Function	Data Type	Setting Value (Default Value)	Timing for Updating
Axis	Reference to axis.	AXIS_REF_SM3 ^{*1}	AXIS_REF_SM3	When Enable shifts to True.
Switches	Switch- related parameters.	MC_CAMSWITCH_REF*	MC_CAMSWITCH_RE F	When Enable shifts to True.
Outputs	Output signals of track	MC_OUTPUT_REF	ARRAY [132] OF BOOL(False)	When Enable shifts to True.
TrackOption s	Compensatio n and Hysteresis parameters for the cam track.	MC_TRACK_REF	ARRAY [132] OF MC_TRACK_TR ^{*3}	When Enable shifts to True.

*Note:

- 1. AXIS_REF_SM3(FB): Each function block has this in-out pin for the activation of function block.
- 2. MC_CAMSWITCH_REF: Structure(STRUCT)

Name	Function	Data Type	Setting Value (Default Value)
NoOfSwitche s	Specify the number of switches.	BYTE	Positive number or 0(0)
CamSwitchPt r	Point to an array of the type MC_CAMSWITCH_T	POINTER TO MC_CAMSWITCH_TR	POINTER TO MC_CAMSWITCH_TR(0

Chapter 2

Name	Function	Data Type	Setting Value (Default Value)
	R	*)

*Note: MC_CAMSWITCH_TR: Structure (STRUCT)

Name	Function	Data Type	Setting Value (Default Value)
TrackNumber	Specify the track for the operation of tappets.	INT	Positive number, negative number or 0(0)
FirstOnPosition	Switch ON when the axis passes.	LREAL	POINTER TO MC_CAMSWITCH_TR(0)
LastOnPosition	Switch OFF when the axis passes.	LREAL	Positive number, negative number or 0(0)
AxisDirection	The switch is active only when the axis is moving in the specified direction.	INT	Positive number, negative number or 0(0)
CamSwitchMode	Switch mode	INT	Positive number, negative number or 0(0)
Duration	How long the switch is on.	TIME	Positive number or 0(0)
bOn	Internal variables	BOOL	True/False(False)
CounterOff	Internal variables	INT	Positive number or 0(0)

3. MC_TRACK_TR: Stucture(STRUCT).

Name	Function	Data Type	Setting Value (Default Value)
OnCompensation	Compensation time with which the switch is turned on. (Unit: Sec.)	LREAL	Positive number, negative number or 0(0)
OffCompensation	Compensation time with which the switch is turned off. (Unit: Sec.)	LREAL	Positive number, negative number or 0(0)
Hysteresis	Hysteresis interval	LREAL	Positive number, negative number or 0(0)

Function

- EnableMask is a 32 bits of bool type parameter, used to enable different tracks. With the concept of the least significant bit representing the first track, the input value would be 16#FFFFFFB to disable the third track.
- MC_CAMSWITCH_REF defines switches for digital cam. NoOfSwitches calculates the number of switching positions. CamSwitchPtr is a pointer on an array of type MC_CAMSWITCH_TR.

- MC_CAMSWITCH_TR specifies the positions of tappets.
 - TrackNumber specifies the output number.
 - FirstOnPosition specifies the switch-on position of the output.
 - LastOnPosition specifies the switch-off position of the output (when CamSwitchMode = 0).
 - AxisDirection = 0: Output is switched in both directions. AxisDirection = 1: Only positive direction. AxisDirection = 2: Only negative direction.
 - Switch is OFF at LastOnPosition when CamSwitchMode = 0. Switch remains ON for a time set (Duration) and then changes to OFF when CamSwitchMode = 1.
 - Duration: Period of time for which the tappet output stays TRUE in case of CamSwitchMode = 1.
- MC_TRACK_REF is the Structure for managing the tracks, which contains OnCompensation, OffCompensation and Hysteresis.
 - OnCompensation is set for the delay of switch-on. If the input value is positive, switching to ON would be delayed, while an early switch-on can be set with a negative input value. The time is given in seconds. For example, if OnCompensation is set to 0.01, switching to ON would be delayed for 0.1 second.
 - OffCompensation is set for the delay of switch-off. If the input value is positive, switching to OFF would be delayed, while an early switch-off can be set with a negative input value.



- The interval for Hysteresis is set to avoid switching errors and the specified axis position must exceeds the interval, so the switch would continue with the next action. The unit of Hysteresis is user-defined.
- Output would be switched to ON with all AxisDirection settings as long as the axis position is inside of the range.
- Multiple switch modes are allowed to be set in a single Track.

• Troubleshooting

- If an error occurs during the execution of the instruction, Error will change to True. You can refer to ErrorID (Error Code) to address the problem.
- Example
 - Example1: Demonstrates using 2 switches in the same Track in the following example.

Chapter 2

Parameter	Туре	Switch1	Switch2
TrackNumber	INT	1	1
FirstOnPosition [u]	REAL	200	400
LastOnPosition [u]	REAL	300	-
AxisDirection	INT	0=Both	0=Both
CamSwitchMode	INT	0=Position	1=TIME
Duration	TIME	-	2500ms

MC_DigitalCamSwitch_0				
TRUE	MC_Digita	lCamSwitch		
	EN	ENO	_	
SM_Drive_Virtual_X -	Axis	InOperation -	-	
MC_CAMSWITCH_REF_0	Switches	Busy-	-	
MC_OUTPUT_REF_0	Outputs	Error-	-	
MC_TRACK_REF_0 -	TrackOptions	ErrorID	-	
E1	Enable	SwitchCorrupted	-	
16#FFFFFFFF —	EnableMask			
1 —	TappetMode			

Timing Diagram

Position 400 200	
MC_DigitalCamSwitch Enable	
Track1	2.5sec

- When the axis reaches the position 200, Switch1 on Track1 would be turned ON till the axis reaches the position 300, then changes to OFF.
- Switch1 would be turned ON again when the position 400 is reached, and lasting for 2.5 seconds, then changes to OFF.
- Example2: The operation result of OnCompensation/OffCompensation is given in the following example.

Parameter	Туре	Switch1	Switch2
TrackNumber	INT	1	2
FirstOnPosition [u]	REAL	100	100
LastOnPosition [u]	REAL	200	200
AxisDirection	INT	0=Both	0=Both

Chapter 2

Parameter	Туре	Switch1	Switch2
CamSwitchMode	INT	0=Position	0=Position
Duration	TIME	-	-
OnCompensation	LREAL	- 0.1	0
OffCompensation	LREAL	0.2	0

MC_DigitalCamSwitch_0			
TRUE	MC_DigitalCamSwitch		
	EN	ENO	_
SM_Drive_Virtual_X	Axis	InOperation	
MC_CAMSWITCH_REF_0 -	Switches	Busy	-
MC_OUTPUT_REF_0	Outputs	Error	
MC_TRACK_REF_0	TrackOptions	ErrorID	
E1	Enable	SwitchCorrupted	-
16#FFFFFFFFFFFFF	EnableMask		
1	TappetMode		

Timing Diagram



- Once the position 100 is reached, Switch1 on Track1 and Switch2 on Track2 are both turned ON and would be turned OFF when position 200 is reached. The switch-on of Switch 1 is advanced for 0.1 second while OnCompensation = -0.1. By setting 0.2 to OffCompensation, Switch 1 is delayed for 0.2 second.
- Example3: The operation result of *Hysteresis* is given in the following example.

Parameter	Туре	Switch1
TrackNumber	INT	1
FirstOnPosition [u]	REAL	90
LastOnPosition [u]	REAL	95
Chapter 2

Parameter	Туре	Switch1
AxisDirection	INT	0=Both
CamSwitchMode	INT	0=Position
Duration	TIME	-
Hysteresis	LREAL	10

MC_DigitalCamSwitch_0						
TRUE MC_DigitalCamSwitch						
	EN	ENO				
SM_Drive_Virtual_X -	Axis	InOperation	-			
MC_CAMSWITCH_REF_0 -	Switches	Busy	-			
MC_OUTPUT_REF_0	Outputs	Error	-			
MC_TRACK_REF_0 -	TrackOptions	ErrorID	-			
E1	Enable	SwitchCorrupted	-			
16#FFFFFFFFFFFFFFFFFFF	EnableMask					
1	TappetMode					

Timing Diagram



- The FirstOnPosition and LastOnPosition of Switch 1 on Track1 are set to 90 and 95 respectively with Hysteresis set to 10, which means the switch would be turned off after the axis position passing the interval (80~100).
- Track 1 is switched to ON when the axis reaches position 90 and not able to be switched to OFF at position 95 until the axis passes the hysteresis interval.
- When the axis moves reversely to position 95, the switch would be turned ON again and remains, for the reason that the axis position stays within the hysteresis interval (105~85).
- Supported Products
 - AX-308E, AX-8, AX-364E

2.3 Delta Motion Control Instructions

2.3.1 Motion Control Instructions

2.3.1.1DMC_Torq ueControl

DMC_TorqueControl controls the torque according to the torque control mode of the servo drive.

FB/FC	Instruction	Graphic expression					
FB	DMC_TorqueControl	DMC_TorqueControl Axis AXIS_REF_MAPPING_SM3 BOOL bInTorque bEnable BOOL BOOL BOOL bBusy bContinuousUpdate BOOL BOOL bContinuousUpdate IrTorque LREAL BOOL bError dwTorqueRamp DWORD DMC_ERROR ErrorId IrVelocity LREAL Inforceleration LREAL IrDeceleration LREAL Inforceleration LREAL Direction BOOL Direction BOOL					
		ST expression					
DMC_	TorqueControl_instan	ce(
Axis :=	,						
bEnab	le :=,						
bConti	inuousUpdate :=,						
Ir Iorqu	Je :=,						
	queRamp :=,						
	loration :=						
	leration :=,						
Ir lork	:=						
Directi	Direction :-						
blaction .=,							
bBusy =>							
bCom	bCommandAborted =>						
bError	=>,						
ErrorI	D =>);						

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>bEnable</i> changes from False to True.	BOOL	True/False (False)	-
bContinuousUpdate	The target torque can be updated continuously when <i>bContinuousUpdate</i> is True.	BOOL	True/False (False)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
IrTorque	Specify the target torque. (Unit: N.m)	LREAL	Negative number, positive number, 0 (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
dwTorqueRamp	Specify the change rate of the torque (Unit: ms) [*]	DWORD	Positive number (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
IrVelocity Specify the maximum velocity.		LREAL	Positive number (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
IrAcceleration	Reserved	LREAL	-	-
IrDeceleration	Reserved	LREAL	-	-
lrJerk	Reserved	LREAL	-	-
Direction	Reserved	BOOL	-	-

*Note:

Take ASDA-A2 for example here with the unit: μ s (microsecond). For other models, refer to 0x6087 in their object dictionaries.

Outputs

Name	Function	Data type	Output range (Default value)
bInTorque	True when the target torque is reached.	BOOL	True/False (False)
bBusy	True when the instruction is	BOOL	True/False (False)

Name Function		Data type	Output range (Default value)
	executed.		
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note:

DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bInTorque	• When the <i>bEnable</i> is True and the axis motion state can be read.	 When bEnable shifts to False. When bError shifts to True.
bBusy	• When <i>bEnable</i> shifts to True.	 When bEnable shifts to False. When bError shifts to True.
bCommandAborted	• When this instruction is aborted by another instruction.	• When bEnable shifts to False.
bError	• When	• When <i>bEnable</i> shifts to
ErrorID	conditions or input values for the instruction.	False. (The value in <i>ErrorID</i> is cleared.)

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_SM3 [*]	AXIS_REF_SM3	When <i>bEnable</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_SM3 (FB): All function blocks contain this variable, which works as the starting program for function blocks.

• Function

- When bEnable shifts to True, the values of *IrTorque*, *dwTorqueRamp* and *IrVelocity* of the DMC_TorqueControl instruction are sent to the serve for torque control.
- When bEnable is False, set the target torque *IrTorque* to 0 to make the axis decelerate to a stop. The instruction execution is completed when the axis decelerates to a stop and bBusy shifts to False.
- Ensure that the axis is in Standstill state before instruction execution.
- The servo will perform an immediate stop if SMC_SetControllerMode interrupts DMC_TorqueControl during instruction execution. Please DO NOT do so.
- Only one DMC_TorqueControl instruction is allowed to execute at a time. If the second DMC_TorqueControl instruction is also executed at the same moment, an error will occur.
- When the DMC_TorqueControl instruction is executed, 0x6071 (Target Torque), 0x6077 (Torque actual value), 0x6060 (ModeOfOperation) and 0x6061 (ModeOfOperationDisplay) OD must be included in the slave PDO mapping data. Otherwise, an error will occur.

Chapter 2

neral	Select the Outputs		
seneral.	Name	Type	Index
Expert Process Data	✓ 16#1600 1st RxPDO Mapping		
	Control Word	UINT	16#6040:00
Process Data	TargetPosition	DINT	16#607A:00
Startun Parametere	TargetVelocity	DINT	16#60FF:00
Startap Farameters	TargetTorque	INT	16#6071:00
EtherCAT Parameters	ModeOfOperation	SINT	16#6060:00
	16#1601 2nd RxPDO Mapping (ex	cclu	
CoE Online	Control Word	UINT	16#6040:00
	TargetPosition	DINT	16#607A:00
EtherCAT I/O Mapping	🗌 16#1602 3rd RxPDO Mapping (ex	clu	
	Control Word	UINT	16#6040:00
EtherCAT IEC Objects	TargetVelocity	DINT	16#60FF:00
	16#1603 4th RxPDO Mapping (ex	clu	
Status	Control Word	UINT	16#6040:00
Information	TargetTorque	INT	16#6071:00
Information			

Troubleshooting

■ If an error occurs during the execution of the instruction, *bError will* change to True. You can refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

■ This example shows the motion behavior performed by DMC_TorqueControl.



Timing Diagram



- After DMC_TorqueControl is started, the servo starts to run according to the input settings of the instruction for the target torque *IrTorque*, change rate of the torque *dwTorqueRamp* and maximum velocity *IrVelocity*.
- After bEnable of DMC_TorqueControl shifts to False, the axis starts to decelerate till it stops. When the axis decelerates to a stop, bBusy shifts to False.
- An error occurs on the axis while DMC_TorqueControl has been executed for a period of time after being started one more time. At the moment, the axis performs an immediate stop for the error and then the instruction will report an error.

• Supported Products

AX-308E, AX-364E

2.3.1.2 DMC_VelocityControl

DMC_VelocityControl performs a velocity control on a specified axis in the CSV speed mode with the specified behavior and an average velocity.

FB/FC	Instruction	Graphic expression			
FB	DMC_VelocityControl	DMC_VelocityControl Axis AXIS_REF_SM3 BOOL bInVelocity — bEnable BOOL BOOL bBOUL — bEnable BOOL BOOL bBoul — bContinuousUpdate BOOL BOOL bCommandAborted — IrVelocity LREAL BOOL bError — IrAcceleration LREAL SM3_ERROR.SMC_ERROR ErrorId — IrDeceleration LREAL Jirection MC_Direction			
ST expression					

FB/FC	Instruction	Graphic expression					
DMC_	DMC_VelocityControl(
Axis :=	;,						
bEnab	le :=,						
bConti	nuousUpdate :=,						
IrVeloc	sity :=,						
IrAcce	leration :=,						
IrDece	leration :=,						
IrJerk	:=,						
Directi	Direction :=,						
blnVel	ocity =>,						
bBusy	=>,						
bCom	bCommandAborted =>,						
bError	bError =>,						
ErrorI	D =>) ;						

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>bEnable</i> changes from FALSE to TRUE.	BOOL	True/False (False)	-
bContinuousUpdate	The target velocity can be updated continuously when <i>bContinuousUpdate</i> is True.	BOOL	True/False (False)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
IrVelocity	Target velocity. (Unit: user unit/s)	LREAL	Positive number (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
IrAcceleration	Acceleration rate. (Unit: user unit/s²)	LREAL	Positive number (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
IrDeceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.
lrJerk	Jerk value. (Unit: user unit/s³)	LREAL	Positive number (0)	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.

Name	Function	Data type	Setting value (Default value)	Timing for updating
Direction	Specifies the motion direction of the servo motor.	MC_ DIRECTION ^{*1}	 3 : fastest 2 : current 1 : positive 0 : shortest -1 :negative (current) *2 	When <i>bEnable</i> shifts to True and <i>Busy</i> is False.

*Note:

- 1. MC_DIRECTION: Enumeration (ENUM)
- 2. The options fastest, current and shortest are only for the rotary axis.

Outputs

Name	Function	Data type	Output range (Default value)
blnVelocity	True when the specified target velocity is reached.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note:

DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bInVelocity	• When the specified target velocity is reached.	 When bCommandAborted

Name	Timing for shifting to True	Timing for shifting to False
		 shifts to True. When bContinuousUpdate is True. and IrVelocity value is changed. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bBusy	• When bEnable shifts to True.	 When <i>bCommandAborted</i> shifts to True. When the axis decelerates to a stop after <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bCommandAborted	 When this instruction is aborted by another instruction. When this instruction is aborted via MC_Stop instruction. 	• When <i>bEnable</i> shifts to False.
bError	• When an error occurs in the execution	When bEnable shifts
ErrorID	conditions or input values for the instruction. (Error code is recorded)	from True to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bEnable</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_SM3 (FB): All function blocks contain this variable, which works as the starting program for function blocks.

• Function

- The instruction performs speed control with specified target velocity (*IrVelocity*), acceleration rate (*IrAcceleration*), deceleration rate (*IrDeceleration*) and Jerk value (*IrJerk*) when *bEnable* changes to True.
 - You can execute another motion instruction to abort the ongoing motion of MC_VelocityControl. But the servo is in CSV mode and the control mode will not be switched to CSP control mode.
 - When the instruction is aborted by another instruction, the output *blnVelocity* shifts to False and *bCommandAborted* shifts to True.
 - When the input bContinuousUpdate of the instruction shifts to True and the target velocity is given a new value, the axis velocity will update to the new speed.
 - When bEnable shifts to False, the instruction makes the axis decelerate to a stop and the mode is switched to CSP control mode.
 - When the instruction is executed, 0x60FF (Target Velocity), 0x606C (Velocity actual value), 0x6060 (ModeOfOperation) and 0x6061 (ModeOfOperationDisplay) OD must be included in the slave PDO mapping data. Otherwise, the servo will not be able to work.

Chapter 2

ral	Select the outputs		
	Name	Type	Index
Process Data	✓ 16#1600 1st RxPDO Mapping		
	Control Word	UINT	16#6040:00
Startup parameters	TargetPosition	DINT	16#607A:00
EtherCAT Parameters	TargetVelocity	DINT	16#60FF:00
concrete relation of the	TargetTorque	INT	16#6071:00
EtherCAT I/O Mapping	ModeOfOperation	SINT	16#6060:00
	16#1601 2nd RxPDO Mapping (e	exclu	
EtherCAT IEC Objects	Control Word	UINT	16#6040:00
	TargetPosition	DINT	16#607A:00
Status	16#1602 3rd RxPDO Mapping (ex	exclu	
	Control Word	UINT	16#6040:00
Information	TargetVelocity	DINT	16#60FF:00
	16#1603 4th RxPDO Mapping (example 16#1603 4th RxPDO Mapping)	exclu	
	Control Word	UINT	16#6040:00
	TargetTorque	INT	16#6071:00

Troubleshooting

■ If an error occurs during the execution of the instruction, *bError will change to True.* You can refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

■ The example shows the motion behavior performed by DMC_VelocityControl.



Timing Diagram

Velocity 300									
0									
DMC_VelocityControl_0	_								
bEnable									
-									
hln\/elocity			1						
–									
	Г		1		F				
bBusy									
bCommandAborte d									
-			1						
bError									
-									
DMC_VelocityControl_1						_		-	
bEnable									
-			1						
bInVelocity									
-]	L				
bBusy					j				
-					L			L	
h O a marca a d A h a sta a d					Г	-i			
pCommandAported									
bError									
-		continuou	s motion(5)						
Axis State Machine sta	andstill(3)		. /				diacont		
							aiscret	e motion(4) 🖵 standstil	((3)

- When bEnable of DMC_VelocityControl_0 changes to True, the instruction controls the axis to reach the specified target velocity 500. When it reaches 500, blnVelocity of DMC_VelocityControl_0 changes to True.
- When bEnable of DMC_VelocityControl_1 changes to True, DMC_VelocityControl_0 is interrupted and bInVelocity of the instruction changes to False and bCommandAborted changes to True.
- The DMC_VelocityControl_1 instruction decelerates the axis to the velocity 300. When 300 is reached, *bInVelocity* of DMC_VelocityControl_1 will change to True and remain in this status as long as the velocity is not changed.
- When *bEnable* of DMC_VelocityControl_0 changes to False, *bCommanAborted* changes to False.
- When DMC_VelocityControl_0 is started again through changing bEnable of DMC_VelocityControl_0 to True, DMC_VelocityControl_0 will be aborted and the axis will accelerate to 500.
- If bEnable of DMC_VelocityControl_1 changes from False to True again when the target velocity of DMC_VelocityControl_0 has not been reached yet, DMC_VelocityControl_0 will be aborted. In this case, the axis will decelerate again without reaching the target velocity 500 of DMC_VelocityControl_0.
- bInVelocity of DMC_VelocityControl_1 changes to True when the target velocity of DMC_VelocityControl_1 is reached.

 When *bEnable* of DMC_VelocityControl_1 changes to True in the next cycle, the axis starts to decelerate to a stop and then *bBusy* of DMC_VelocityControl_1 changes to False.

• Supported Products

AX-308E, AX-364E

2.3.1.3 DMC_MoveLinearAbsolute

DMC_MoveLinearAbsolute controls a specified axis group to perform the absolute linear interpolation for a specified absolute position.

FB/FC	Instruction	Graphic expression			
FB	DMC_MoveLinearAbsolute	DMC_MOVeLinearAbsolute BOOL bDone - AxisGroup DMC_AXIS_GROUP_REF BOOL bBusy - bExecute BOOL BOOL bBusy - Position ARRAY [0.5] OF LREAL BOOL bActive - IrVelocity LREAL BOOL bCommandAborted - IrAcceleration LREAL BOOL bCommandAborted - IrAcceleration LREAL BOOL bForm - IrDeceleration LREAL DMC_ERROR ErrorID - Irlark LREAL DMC_ERROR ErrorID - BufferMode DMC_BUFFER_MODE - - TransitionMode DMC_GROUP_TRANSITION_MODE -			
		ST expression			
DMC_	MoveLinearAbsolute_instan	ce (
AxisG	roup:= ,				
bExec	ute:= ,				
Positio	on:= ,				
Irveloc	city:= ,				
	leration:= ,				
In Jork:	eleration:= , -				
Rufforl	- , Mode:=				
Transi	TransitionMode:=				
bDone=>.					
bBusy=>,					
bActive=>,					
bCommandAborted=> ,					
bError	=> ,				
ErrorI	D=>);				

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from	BOOL	True/False (False)	-

Name	Function	Data type	Setting value (Default value)	Timing for updating
	False to True.			
Position	Specify the absolute target position for each axis in the specified axis group. (Unit: user unit)	LREAL[6]	[_, _, _, _, _, _] Positive number or negative number ([0, 0, 0, 0, 0, 0, 0])	When <i>bExecute</i> shifts to True.
IrVelocity	Specify the target velocity for the specified axis group. (Unit: user unit/s)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
IrAcceleration	Specify the acceleration rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
IrDeceleration	Specify the deceleration rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
lrJerk	Specify the jerk. (Unit: user unit/s ³)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
BufferMode	Specify a buffer mode for the instruction ^{*1}	DMC_ BUFFER_ MODE	0: Aborting 1: Buffered 2: BlendingLow 3: BlendingPrevious 4: BlendingNext 5: BlendingHigh (0)	When <i>bExecute</i> shifts to True.
TransitionMode	Specify a transition mode for the instruction ^{*2} .	DMC_ GROUP_ TRANSITION_ MODE	0: None 10: Overlap (0)	When <i>bExecute</i> shifts to True.

*Note:

- 1. Refer to AX-3 Series Operation Manual for details on *BufferMode*.
- 2. Refer to AX-3 Series Operation Manual for details on *TransitionMode*.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the absolute positioning is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bActive	True when the instruction is controlling axes.	BOOL	True/False (False)
bCommand Aborted	True when the instruction execution is aborted.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the absolute positioning is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	 When <i>bExecute</i> changes to True. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bActive	 When axes start being controlled by the instruction. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. <i>bActive</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> is False but <i>bActive</i> changes to True.

Name	Timing for shifting to True	Timing for shifting to False		
bCommand Aborted	 When the instruction is aborted by another instruction <i>BufferMode</i> of which is set to Aborting. When the instruction is aborted by MC_Stop. When the instruction is aborted by DMC_GroupStop. 	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to True. 		
bError/ErrorID	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded).	• When <i>bExecute</i> shifts from True to False. (Error code is cleared)		

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Specify the axis group.	DMC_AXIS_GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- The instruction supports the absolute linear interpolation of maximum six axes, where the six axes can simultaneously start, stop as well as reach the specified absolute target position.
- At least one axis is needed for the linear interpolation. An error will occur if there is a travel distance for the axis which is not set.

• Troubleshooting

- When an error occurs in the instruction execution or the axis group enters GroupErrorstop state, *bError* changes to True and axes stops running. To confirm current error state, see the error code in *ErrorID*.
- For error codes and corresponding trouble shootings, refer to **Appendices** for error code descriptions.

• Programming Example

In this example, the path for the six-axis absolute linear interpolation is planned and the six axes simultaneously reach the target position through traveling an absolute distance from current positon.

Axis group	Target position
Axis1	1000
Axis2	2000
Axis3	3000
Axis4	4000
Axis5	5000
Axis6	6000

```
DMC_MoveLinearAbsolute_0: DMC_MoveLinearAbsolute;
movabs_exe: BOOL;
movabs_pos: ARRAY [0..5] OF LREAL := [1000, 2000, 3000, 4000, 5000, 6000];
movabs_vel: LREAL := 100;
movabs_acc: LREAL := 100;
movabs_dec: LREAL := 100;
movabs_jerk: LREAL := 0;
movabs_buffmode: DMC_BUFFER_MODE;
movabs_transmode: DMC_GROUP_TRANSITION_MODE;
movabs_done: BOOL;
movabs_done: BOOL;
movabs_active: BOOL;
movabs_abort: BOOL;
movabs_error: BOOL;
movabs_error: BOOL;
movabs_error: BOOL;
movabs_errorID: DMC_ERROR;
```

DMC_GroupEnable_0			
	DMC GroupEnable		
	EN	ENO	
DMC_Axis_Group —↔	AxisGroup	bDone	-group_done
group_exe	bExecute	bBusy	— group_busy
		bError	-group_error
		ErrorID	-group_errorID

DMC_MoveLinearAbsolute_0			
	DMC_MoveLin	DMC MoveLinearAbsolute	
	EN	ENO	
DMC_Axis_Group —↔	AxisGroup	bDone	-movabs_done
movabs_exe —	bExecute	bBusy	-movabs_busy
movabs_pos —	Position	bActive	-movabs_active
movabs_vel —	lrVelocity	bCommandAborted	-movabs_abort
movabs_acc —	lrAcceleration	bError	-movabs_error
movabs_dec —	lrDeceleration	ErrorID	-movabs_errorID
movabs_jerk —	lrJerk		
movabs_buffmode —	BufferMode		
movabs_transmode —	TransitionMode		

- When moveabs_exe (*bExecute*) changes to True, DMC_MoveLinearAbsolute starts to perform the absolute linear interpolation for six axes.
- When moveabs_done (bDone) changes to True, moveabs_busy (bBusy) changes to False, which means the specified absolute positioning (1000, 2000, 3000, 4000, 5000, 6000) is completed.
- moveabs_exe (*bExecute*) is switched to False after the absolute linear interpolation is completed. Then moveabs_done (*bDone*) will change to False automatically.
- If moveabs_exe (*bExecute*) is set to True again for the absolute linear interpolation, then no axes will move for positioning.

• Supported Products

AX-308E, AX-364E

2.3.1.4 DMC_MoveLinearRelative

DMC_MoveLinearRelative controls a specified axis group to perform the relative linear interpolation.

FB/FC	Instruction	Graphic expression	
FB	DMC_MoveLinearRelative	DMC_MoveLinearRelative BOOL bDne - AxisGroup DMC_AXIS_GROUP_REF BOOL BOOL BUOL BUOL	
ST expression			

FB/FC	Instruction	Graphic expression			
DMC_		ice (
AxisGr	oup: =,				
bExec	ute: =,				
Distan	ce: =,				
IrVeloc	ity: =,				
IrAcce	eration: =,				
IrDece	leration: =,				
IrJerk:	=,				
Buffer	√lode: =,				
Transit	ionMode: =,				
bDone	=>,				
bBusy	bBusy=>,				
bActive	bActive=>,				
bComr	bCommandAborted=>,				
bError	=>,				

• Inputs

ErrorID=>) ;

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
Distance	Specify the travel distance for each axis in the specified axis group. (Unit: user unit)	LREAL[6]	[_, _, _, _, _, _, _] Positive number, negative number or 0 ([0, 0, 0, 0, 0, 0, 0])	When <i>bExecute</i> shifts to True.
IrVelocity	Specify the target velocity for the axis group. (Unit: user unit/s)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
IrAcceleration	Specify the acceleration	LREAL	Positive number (0)	When <i>bExecute</i> shifts

Name	Function	Data type	Setting value (Default value)	Timing for updating
	rate. (Unit: user unit/s²)			to True.
IrDeceleration	Specify the deceleration rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
lrJerk	Specify the jerk. (Unit: user unit/s ³)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
BufferMode	Specify a buffer mode for the instruction.*1	DMC_ BUFFER_ MODE	0: Aborting 1: Buffered 2: BlendingLow 3: BlendingPrevious 4: BlendingNext 5: BlendingHigh (0)	When <i>bExecute</i> shifts to True.
TransitionMode	Specify a transition mode for the instruction ^{*2}	DMC_ GROUP_ TRANSITION_MODE	0: None 10: Overlap (0)	When <i>bExecute</i> shifts to True.

*Note:

- 1. Refer to AX-3 Series Operation Manual for details on BufferMode.
- 2. Refer to AX-3 Series Operation Manual for details on TransitionMode.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the relative positioning is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bActive	True when the instruction is controlling axes.	BOOL	True/False (False)
bCommand Aborted	True when the instruction execution is aborted.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)

Chapter 2

Name	Function	Data type	Output range (Default value)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the relative positioning is completed. 	 When <i>bExecute</i> shifts to False. When <i>bExecute</i> is False but <i>bDone</i> shifts to True, <i>bDone</i> will remain True for one cycle and then change to False.
bBusy	• When <i>bExecute</i> changes to TRUE.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bActive	 When axes start being controlled by the instruction. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. <i>bActive</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> is False but <i>bActive</i> changes to True.
bCommand Aborted	 When the instruction is aborted by another instruction whose <i>BufferMode</i> is set to Aborting. When the instruction is aborted by MC_Stop. When the instruction is aborted by DMC_GroupStop. 	 When bExecute shifts to False. bCommandAborted will change to False after remaining True for at least one cycle when bExecute is False but bCommandAborted changes to True.
bError/ErrorID	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded in <i>ErrorID</i>)	• When bExecute shifts from True to False. (Error code is cleared)

Timing Diagram



• In-Outs

Name	Functio n	Data type	Output range	Name
AxisGrou p	Specify the axis group.	DMC_AXIS_GROUP_REF	DMC_AXIS_GROUP_RE F	When bExecut e shifts to True and bBusy is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- The instruction supports the relative linear interpolation of maximum six axes, where the six axes can simultaneously start, stop as well as reach the specified target relative position.
- At least one axis is needed for the linear interpolation. An error will occur if there is a travel distance for the axis which is not set.

• Troubleshooting

- When an error occurs in the instruction execution or the axis group enters GroupErrorstop state, *bError* changes to True and axes stops running. To confirm current error state, see the error code in *ErrorID*.
- For error codes and corresponding trouble shootings, refer to **Appendices** for error code descriptions.

• Programming Example

In this example, the path for the six-axis relative linear interpolation is planned and six axes simultaneously reach the target relative position through traveling a relative distance from current positon.

The number of each axis in the axis group	Current position	Relative distance	Target position
Axis 1	1000	1000	2000
Axis 2	1000	2000	3000
Axis 3	1000	3000	4000
Axis 4	1000	4000	5000
Axis 5	1000	5000	6000
Axis 6	1000	0	1000

```
DMC_MoveLinearRelative_0: DMC_MoveLinearRelative;
movrel_exe: BOOL;
movrel_dist: ARRAY [0..5] OF LREAL := [1000, 2000, 3000, 4000, 5000, 0];
movrel_vel: LREAL := 1000;
movrel_acc: LREAL := 100;
movrel_dec: LREAL := 100;
movrel_jerk: LREAL := 0;
movrel_buffmode: DMC_BUFFER_MODE;
movrel_buffmode: DMC_GROUP_TRANSITION_MODE;
movrel_transmode: DMC_GROUP_TRANSITION_MODE;
movrel_done: BOOL;
movrel_busy: BOOL;
movrel_active: BOOL;
movrel_abort: BOOL;
movrel_error: BOOL;
movrel_errorID; DMC_ERROR;
```

DMC_GroupEnable_0			
	DMC_Grou	pEnable	
	EN	ENO	
DMC_Axis_Group ─↔	AxisGroup	bDone	-group_done
group_exe —	bExecute	bBusy	group_busy
		bError	-group_error
		ErrorID	-group_errorID

DMC_MoveLinearRelative_0					
	DMC_MoveLin	earRelative			
	EN	ENO			
DMC_Axis_Group	AxisGroup	bDone	-movrel_done		
movrel_exe	bExecute	bBusy	-movrel_busy		
movrel_dist	Distance	bActive	-movrel_active		
movrel_vel	lrVelocity	bCommandAborted	-movrel_abort		
movrel_acc	lrAcceleration	bError	-movrel_error		
movrel_dec	lrDeceleration	ErrorID	-movrel_errorID		
movrel_jerk	lrJerk				
movrel_buffmode	BufferMode				
movrel_transmode	TransitionMode				

- When movrel_exe (*bExecute*) changes to True, DMC_GroupRelLinear starts to perform the relative linear interpolation for six axes.
- When movrel_done (*bDone*) changes to True, movrel_busy (*bBusy*) and movrel_abort

(*bAborted*) change to False, which means the specified relative positioning (1000, 2000, 3000, 4000, 5000, 0) is completed.

- movrel_exe (bExecute) is switched to False after the relative linear interpolation is completed. Then movrel_done (bDone) will change to False automatically.
- If movrel_exe (*bExecute*) is set to True again, axes will perform the relative linear interpolation one more time to reach the target position (3000, 5000, 7000, 9000, 11000, 1000).
- When the target positioning is completed, movrel_done (*bDone*) changes to True again.
- Supported Products
 - AX-308E, AX-364E

2.3.1.5 DMC_MoveCircularAbsolute

DMC_MoveCircularAbsolute controls the axis group to perform circular or helical interpolation for a specified absolute target position.

FB/FC	Instruction	Graphic expression		
FB	DMC_MoveCircularAbsolute	DMC_MoveCircularAbsolute BOOL bDone AxisGroup DMC_AXIS_GROUP_REF BOOL bDusy bExecute BOOL BOOL bBusy CircPlane DMC_CRC_PLANE BOOL bActive CircMode DMC_MORE BOOL bCommandAborted AxisPoint ARRAY (D3) OF LREAL BOOL bError PathChoice DMC_ERROR ErrorID DMC_ERROR ErrorID Veryloity LREAL DMC_ERROR ErrorID Hirderition LREAL DMC_ERROR ErrorID Hirderity LREAL Indexity Hirderition LREAL ErrorID Hirderity LREAL ErrorID BufferMode DMC_ERR		
ST expression				

FB/FC	Instruction	Graphic expression				
DMC_	MoveCircularAbsolute_instar	ice (
AxisG	roup: = ,					
bExec	ute: = ,					
CircPla	ane: = ,					
CircMo	ode: = ,					
AuxPo	pint: = ,					
EndPo	pint: = ,					
PathC	hoice: = ,					
dwSpi	ralTurns: = ,					
IrVeloc	city: = ,					
IrAcce	leration: = ,					
IrDece	leration: = ,					
IrJerk:	= ,					
Buffer	Mode: = ,					
Transi	tionMode: = ,					
bDone	bDone=> ,					
bBusy	bBusy=> ,					
bActiv	bActive=> ,					
bCom	bCommandAborted=> ,					
bError	=> ,					
Errorl)=> ;					

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
CircPlane	Specify the circular or helical plane. *1	DMC_CIRC_ PLANE	0: XY_plane 1: YZ_plane 2: ZX_plane (0)	When <i>bExecut</i> <i>e</i> shifts to True.
CircMode	Specify the method for circular or helical interpolatio n. *1	DMC_CIRC_ MODE	0: Border 1: Center 2: Radius (0)	When <i>bExecut</i> e shifts to True.

Name	Function	Data type	Setting value (Default value)	Timing for updating
AuxPoint	Specify the auxiliary point data.	LREAL[3]	[_, _, _] Positive number, negative number or 0 ([0, 0, 0])	When <i>bExecut</i> <i>e</i> shifts to True.
EndPoint	Specify the target position for each axis in the axis group. (Unit: user unit)	LREAL[6]	[_, _, _, _, _, _, _] Positive number, negative number or 0 ([0, 0, 0, 0, 0, 0, 0])	When <i>bExecut</i> e shifts to True.
PathChoice	Specify the circular or helical interpolatio n direction.	DMC_CIRC_ PATHCHOICE	0: Clockwise 1: CounterClockwi se (0)	When <i>bExecut</i> e shifts to True.
dwSpiralTurn s	Specify the number of spiral turns.	DWORD	0~65535 (0)	When <i>bExecut</i> <i>e</i> shifts to True.
IrVelocity	Specify the target velocity for the axis group. (Unit: user unit/s)	LREAL	Positive number (0)	When <i>bExecut</i> e shifts to True.
IrAcceleration	Specify the acceleratio n rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecut</i> e shifts to True.
IrDeceleratio n	Specify the deceleratio n rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecut</i> <i>e</i> shifts to True.
lrJerk	Specify the jerk. (Unit: user unit/s ³)	LREAL	Positive number (0)	When <i>bExecut</i> <i>e</i> shifts to True.
BufferMode	Specify a buffer	DMC_BUFFER_MODE	0: Aborting	When <i>bExecut</i>

Name	Function	Data type	Setting value (Default value)	Timing for updating
	mode for the instruction.* 2		1: Buffered 2: BlendingLow 3: BlendingPrevio us 4: BlendingNext 5: BlendingHigh (0)	e shifts to True.
TransitionMo de	Specify a transition mode for the instruction.	DMC_GROUP_TRANSITION_M ODE	0: None 10: Overlap (0)	When <i>bExecut</i> e shifts to True.

*Note:

1. Setting parameters *CircPlane*, *CircMode* and *AuxPoint*.

		CircPlane		
CircMode	Definition <i>CircMode – AuxPoint</i>	XY_Plane	YZ_Plane	ZX_Plane
setting		Actual input for <i>AuxPoint</i> [_, _, _]		
0	Three points – Absolute coordinate values for the border point (X _A , Y _A , Z _A)	Start point, end point and border point [X _A , Y _A Z _A]		
1	A center point – Absolute coordinate values for the center point (C _X , C _Y)	[Cx, Cy, N/A]	[N/A, Cx, Cy]	[C _Y , N/A, C _X]
2	Radius – Radius (R)	[R, N/A, N/A]		

2. Refer to AX-3 Series Operation Manual for details on BufferMode.

3. Refer to AX-3 Series Operation Manual for details on TransitionMode.

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the absolute positioning is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bActive	True when the instruction is controlling axes.	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
bCommand Aborted	True when the instruction execution is aborted.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the absolute positioning is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	• When <i>bExecute</i> changes to TRUE.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bActive	 When axes start being controlled by the instruction. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. <i>bActive</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> is False but <i>bActive</i> changes to True.
bCommand Aborted	 When the instruction is aborted by another instruction <i>BufferMode</i> of which is set to Aborting. When the instruction is aborted 	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to

Name	Timing for shifting to True	Timing for shifting to False
	by MC_Stop.When the instruction is aborted by DMC_GroupStop.	True.
bError/ErrorID	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded)	• When <i>bExecute</i> shifts from True to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Functio n	Data type	Setting value	Timing for updating
AxisGrou p	Specify the axis group.	DMC_AXIS_GROUP_REF	DMC_AXIS_GROUP_RE F	When <i>bExecut</i> <i>e</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- The instruction supports the absolute helical interpolation of maximum three axes, where the three axes can simultaneously start, stop as well as reach the specified absolute target position.
- The instruction can be used to specify the circle drawing on the plane parallel to XY / YZ / ZX and set the height of the helix on Z / X / Y axis.
- If the start point and end point for circular interpolation are set to the same

point, use the center point mode (CircMode = Center) for the interpolation.

- At least two axes are needed for circular interpolation. An error will occur if there is a travel distance for an axis which is not set.
- When the start point and end point for circular interpolation are set as the same point, the instruction will perform the rotation for one complete circle.

• Troubleshooting

- When an error occurs in the instruction execution or the axis group enters GroupErrorstop state, *bError* changes to True and axes stops running. To confirm current error state, see the error code in *ErrorID*.
- For error codes and corresponding trouble shootings, refer to Appendices for error code descriptions.

• Programming Example

In this example, the instruction performs the circular interpolation from current positon (1000, 3000) until the absolute target position (4000, 2000) in the clockwise direction.

```
DMC_MoveCircularAbsolute_0: DMC_MoveCircularAbsolute;
cirabs_exe: BOOL;
cirabs_circplane: DMC_CIRC_PLANE := DMC_CIRC_PLANE.XY_plane;
cirabs_circmode: DMC_CIRC_MODE := DMC_CIRC_MODE.center;
cirabs auxpoint: ARRAY [0..2] OF LREAL := [2000, 1000];
cirabs endpoint: ARRAY [0..5] OF LREAL := [4000, 2000];
cirabs_pathchoice: DMC_CIRC_PATHCHOICE := DMC_CIRC_PATHCHOICE.CLOCKWISE;
cirabs spiralturns: WORD := 0;
cirabs vel: LREAL := 200;
cirabs_acc: LREAL := 100;
cirabs dec: LREAL := 100;
cirabs jerk: LREAL := 0;
cirabs_buffmode: DMC_BUFFER_MODE;
cirabs transmode: DMC GROUP TRANSITION MODE;
cirabs done: BOOL;
cirabs busy: BOOL;
cirabs active: BOOL;
cirabs aborted: BOOL;
cirabs error: BOOL;
cirabs_errorID: DMC_ERROR;
```

DMC_GroupEnable_0				
	DMC GroupEnable			
	EN	ENO		
DMC_Axis_Group ─↔	AxisGroup	bDone	- group_done	
group_exe —	bExecute	bBusy	group_busy	
		bError	group_error	
		ErrorID	-group_errorID	

Chapter 2

DMC_MoveCircularAbsolute_0					
	DMC_MoveCircularAbsolute				
	EN	ENO			
DMC_Axis_Group —	AxisGroup	bDone	-cirabs_done		
cirabs_exe —	bExecute	bBusy	-cirabs_busy		
cirabs_circplane —	CircPlane	bActive	— cirabs_active		
cirabs_circmode —	CircMode	bCommandAborted	-cirabs_aborted		
cirabs_auxpoint —	AuxPoint	bError	— cirabs_error		
cirabs_endpoint —	EndPoint	ErrorID	-cirabs_errorID		
cirabs_pathchoice —	PathChoice				
cirabs_spiralturns —	dwSpiralTurns				
cirabs_vel —	lrVelocity				
cirabs_acc —	lrAcceleration				
cirabs_dec —	lrDeceleration				
cirabs_jerk —	lrJerk				
cirabs_buffmode —	BufferMode				
cirabs_transmode —	TransitionMode				





When cirabs_exe (bExecute) changes to True, DMC_MoveCircularAbsolute performs the absolute positioning toward the terminal point (4000, 2000) from

the start point (1000, 3000) in the clockwise direction.

- When cirabs_done (bDone) is True and cirabs_busy (bBusy) changes to False, which means the absolute target positioning (4000, 2000) is completed. When cirabs_exe (bExecute) is switched to False, cirabs_done (bDone) will change to False automatically.
- If cirabs_exe (*bExecute*) is set to True again, there will be no positioning motion any longer since the absolute target position has been reached.

• Supported Products

AX-308E, AX-364E

2.3.1.6 DMC_MoveCircularRelative

DMC_MoveCircularRelative controls the axis group to perform circular or helical interpolation for a specified relative target position.

FB/FC	Instruction	Graphic expression
FB	DMC_MoveCircular Relative	DMC_MoveCircularRelative AxisGroup DMC_AXIS_GROUP_REF BOOL BOOL bExecute BOOL CircPlane DMC_CIRC_PLANE CircPlane BOOL DCC_CIRC_PLANE BOOL BOOL BOOL DAtxive BOOL CircPlane DMC_CIRC_MODE BOOL BOOL DAtxPoint ARRAY [0.2] PathChoice DMC_CIRC_PATHCHOICE dwSpiralTums DWORD IrVelocity LREAL BufferMode DMC_BUFFER_MODE TransitionMode DMC_GROUP_TRANSITION_MODE
		ST expression
DMC_ AxisG bExec CircPl CircM AuxPc EndPc PathC dwSpi IrVeloc IrVeloc IrVeloc IrJerk: Buffer Transi bDone bBusy bActiv bCom bError	MoveCircularRelative_in roup: = , ute: = , ane: = , ode: = , oint: = , bint: = , hoice: = , ralTurns: = , city: = , leration: = , eleration: = , eleration: = , eleration: = , eleration: = , eleration: = , eleration: = , city: = , leration: = , eleration: = , eleration: = , city: = , leration: = , eleration: = , eleration: = , city: = , city: = , city: = , leration: = , city: = , city	stance (

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
CircPlane	Specify the circular or helical plane. ^{*1}	DMC_CIRC_ PLANE	0: XY_plane 1: YZ_plane 2: ZX_plane (0)	When <i>bExecut</i> e shifts to True.
CircMode	Specify the method for circular or helical interpolatio n. *1	DMC_CIRC_ MODE	0: Border 1: Center 2: Radius (0)	When <i>bExecut</i> e shifts to True.
AuxPoint	Specify the auxiliary point data. *1	LREAL[3]	[_, _, _] Positive number, negative number or 0 ([0, 0, 0])	When <i>bExecut</i> e shifts to True.
EndPoint	Specify the target position for each axis in the axis group. (Unit: user unit)	LREAL[6]	[_, _, _, _, _, _, _] Positive number, negative number or 0 ([0, 0, 0, 0, 0, 0, 0])	When <i>bExecut</i> e shifts to True.
PathChoice	Specify the circular or helical interpolatio n direction.	DMC_CIRC_ PATHCHOICE	0: Clockwise 1: CounterClockwi se (0)	When <i>bExecut</i> e shifts to True.
dwSpiralTurn s	Specify the number of spiral turns.	DWORD	0~65535 (0)	When <i>bExecut</i> <i>e</i> shifts to True.
IrVelocity	Specify the target	LREAL	Positive number (0)	When <i>bExecut</i>

Name	Function	Data type	Setting value (Default value)	Timing for updating
	velocity for the axis group. (Unit: user unit/s)			e shifts to True.
IrAcceleration	Specify the acceleratio n rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecut</i> e shifts to True.
IrDeceleratio n	Specify the deceleratio n rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecut</i> e shifts to True.
lrJerk	Specify the jerk. (Unit: user unit/s ³)	LREAL	Positive number (0)	When <i>bExecut</i> e shifts to True.
BufferMode	Specify a buffer mode for the instruction.* 2	DMC_BUFFER_MODE	0: Aborting 1: Buffered 2: BlendingLow 3: BlendingPrevio us 4: BlendingNext 5: BlendingHigh (0)	When <i>bExecut</i> <i>e</i> shifts to True.
TransitionMo de	Specify a transition mode for the instruction.*	DMC_GROUP_TRANSITION_M ODE	0: None 10: Overlap (0)	When bExecut e shifts to True.

*Note:

1. Setting parameters *CircPlane*, *CircMode* and *AuxPoint*.

		CircPlane		
CircMode	Definition CircMode – AuxPoint	XY_Plane	YZ_Plane	ZX_Plane
setting		Actual input for <i>AuxPoint</i> [_, _, _]		
0	Three points – Relative coordinate values for the border point (X _A , Y _A , Z _A)	Start point, end	d point and border	r point [X _A , Y _A , Z _A]

		CircPlane		
CircMode	Definition CircMode – AuxPoint	XY_Plane	YZ_Plane	ZX_Plane
setting		Actual input for <i>AuxPoint</i> [_, _, _]		
1	A center point – Relative coordinate values for the center point (Cx, Cy)	[Cx, C _Y , N/A]	[N/A, Cx, Cy]	[C _Y , N/A, C _X]
2	Radius – Radius (R)		[R, N/A, N/A]	

2. Refer to AX-3 Series Operation Manual for details on BufferMode.

3. Refer to AX-3 Series Operation Manual for details on TransitionMode.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the relative positioning is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bActive	True when the instruction is controlling axes.	BOOL	True/False (False)
bCommand Aborted	True when the instruction execution is aborted.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the relative positioning is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	• When <i>bExecute</i> changes to TRUE.	• When <i>bDone</i> shifts to True.
Name	Timing for shifting to True	Timing for shifting to False
---------------------	--	---
		 When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bActive	 When axes start being controlled by the instruction. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. <i>bActive</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> is False but <i>bActive</i> changes to True.
bCommand Aborted	 When the instruction is aborted by another instruction <i>BufferMode</i> of which is set to <i>Aborting</i>. When the instruction is aborted by MC_Stop. When the instruction is aborted by DMC_GroupStop. 	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to True.
bError/ErrorID	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded).	• When <i>bExecute</i> shifts from True to False. (Error code is cleared)

Timing Diagram



• In-Outs

Name	Functio n	Data type	Setting value	Timing for updating
AxisGrou	Specify	DMC_AXIS_GROUP_REF	DMC_AXIS_GROUP_RE	When

p	the axis group.	*	F	<i>bExecut</i> <i>e</i> shifts to True and <i>bBusy</i> is False.
---	--------------------	---	---	--

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- The instruction supports the relative helical interpolation of maximum three axes, where the three axes can simultaneously start, stop as well as reach the specified relative target position.
- The instruction can be used to specify the circle drawing on the plane parallel to XY / YZ / ZX and set the height of the helix on Z / X / Y axis.
- If the start point and end point for circular interpolation are set to the same point, use the center point mode (*CircMode* = Center) for the interpolation.
- At least two axes are needed for circular interpolation. An error will occur if there is a travel distance for an axis which is not set.
- When the start point and end point for circular interpolation are set to the same point, the instruction will perform the rotation for one complete circle.

Troubleshooting

- When an error occurs in the instruction execution or the axis group enters GroupErrorstop state, *bError* changes to True and axes stops running. To confirm current error state, see the error code in *ErrorID*.
- For error codes and corresponding trouble shootings, refer to **Appendices** for error code descriptions.

• Programming Example

In this example, the instruction performs the circular interpolation from current positon (1000, 3000) until the target position (4000, 2000) in the clockwise direction.

```
DMC_MoveCircularRelative_0: DMC_MoveCircularRelative;
cirrel_exe: BOOL;
cirrel_circmode: DMC_CIRC_MODE := DMC_CIRC_MODE.center;
cirrel_auxpoint: ARRAY [0..2] OF LREAL := [1000, -2000];
cirrel endpoint: ARRAY [0..5] OF LREAL := [3000, -1000];
cirrel pathchoice: DMC CIRC PATHCHOICE := DMC CIRC PATHCHOICE.CLOCKWISE;
cirrel spiralturns: WORD := 0;
cirrel_vel: LREAL := 200;
cirrel_acc: LREAL := 100;
cirrel dec: LREAL := 100;
cirrel jerk: LREAL := 0;
cirrel_buffmode: DMC_BUFFER_MODE;
cirrel_transmode: DMC_GROUP_TRANSITION_MODE;
cirrel_done: BOOL;
cirrel_busy: BOOL;
cirrel active: BOOL;
cirrel_aborted: BOOL;
cirrel error: BOOL;
cirrel_errorID: DMC_ERROR;
```

DMC_GroupEnable_0					
	DMC_Grou	pEnable			
	EN	ENO			
DMC_Axis_Group	AxisGroup	bDone	group_done		
group_exe —	bExecute	bBusy	group_busy		
		bError	group_error		
		ErrorID	group_errorID		

DMC_MoveCircularRelative_0					
	DMC MoveCircularRelative				
	EN	ENO			
DMC_Axis_Group —↔	AxisGroup	bDone	-cirrel_done		
cirrel_exe	bExecute	bBusy	-cirrel_busy		
cirrel_circplane —	CircPlane	bActive	- cirrel_active		
cirrel_circmode —	CircMode	bCommandAborted	-cirrel_aborted		
cirrel_auxpoint —	AuxPoint	bError	-cirrel_error		
cirrel_endpoint —	EndPoint	ErrorID	-cirrel_errorID		
cirrel_pathchoice —	PathChoice				
cirrel_spiralturns —	dwSpiralTurns				
cirrel_vel	lrVelocity				
cirrel_acc —	lrAcceleration				
cirrel_dec	lrDeceleration				
cirrel_jerk —	lrJerk				
cirrel_buffmode —	BufferMode				
cirrel_transmode —	TransitionMode				





- When cirrel_exe (bExecute) changes to True, DMC_MoveCircularRelative performs the relative positioning toward the terminal point (4000, 2000) from the start point (1000, 3000) in the clockwise direction.
- When cirrel_done (bDone) is True and cirrel_busy (bBusy) changes to False, which means the relative target positioning (4000, 2000) is completed. When cirrel_exe (bExecute) is switched to False, cirrel_done (bDone) will change to False automatically.
- If cirrel_exe (*bExecute*) is set to True again, the instruction will perform the circular interpolation regarding current positon (4000, 2000) as the reference point.
- Supported Products
 - AX-308E, AX-364E

2.3.1.7 DMC_GroupStop

DMC_GroupStop decelerates the group axes to a stop.

FB/FC	Instruction	Graphic expression	ST expression
FB	DMC_GroupStop	— AxisGroup DMC_AXIS_GROUP_REF BOOL bDone — DExecute ROOL — IDeceleration LREAL BOOL bBusy — IDeceleration LREAL BOOL bCommandAborted — IDerk LREAL BOOL bCrons — DMC_ERROR ErrorID — DMC_ERROR ErrorID	DMC_GroupStop_instance (AxisGroup : =, bExecute : =, IrDeceleration : =, IrJerk : =, bDone =>, bBusy =>, bActive =>, bCommandAborted =>, bError =>, ErrorID =>) ;

• Inputs

Name	Name Function		Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
IrDeceleration	Specify the deceleration rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
lrJerk	Specify the jerk. (Unit: user unit/s³)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when all axes stop with the velocity 0.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
bActive	True when the instruction is controlling axes.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the axis group decelerates to a stop. 	 When <i>bExecute</i> shifts to False. <i>bExecute</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	 When <i>bExecute</i> shifts to True. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bActive	 When axes start being controlled by the instruction. 	 When <i>bExecute</i> shifts to False. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. <i>bActive</i> will change to False after remaining True for at least one cycle if <i>bExecute</i> changes to False but <i>bActive</i> changes to True.
bCommandAborted	 When the instruction is aborted by another instruction. 	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to True.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts from

Name	Timing for shifting to True	Timing for shifting to False
ErrorID	execution conditions or input values for the instruction. (Error code is recorded).	True to False. (Error code is cleared)

Timing Diagram



• In-Outs

Name	Functio n	Data type	Setting value	Timing for updating
AxisGrou p	Specify the axis group.	DMC_AXIS_GROUP_REF	DMC_AXIS_GROUP_RE F	When bExecut e shifts to True and bBusy is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- The instruction decelerates the group axes in motion to a stop.
- The axis group state is switched to GroupStopping via the instruction.
- The axis group state GroupStopping will continue until bExecute changes to False. bDone changes to True when the velocity 0 is reached.

Troubleshooting

■ *bError* changes to True when an error occurs. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- This example shows the motion behavior which is performed by DMC_GroupStop during the execution of DMC_MoveLinearRelative.
- When the execution of DMC_GroupStop is completed, the axis group enters GroupStandby state.





Timing Diagram

- When bExecute of DMC_GroupStop changes to True, bCommandAboted of MoveLinearRelative changes to True and axes start to decelerate to a stop. Meanwhile the axis group stays in GroupStopping state.
- When the velocities of axes reach 0, *bDone* of DMC_GroupStop changes to True and the axis group holds GroupStopping state.
- When *bExecute* of DMC_GroupStop changes to False, the state of axes changes from GroupStopping into StandBy.
- Supported Products
 - AX-308E, AX-364E

2.3.1.8 DMC_GroupHalt

Divid_Orouphan debelorates the axis group in motion to a pade	use.
---	------

FB/FC	Instruction	Graphic expression	ST expression
FB	DMC_GroupHalt	AddsGroup DMC_AXIS_GROUP_REF BOOL bDone 	DMC_GroupHalt_instance (AxisGroup : =, bExecute : =, IrDeceleration : =, IrJerk : =, BufferMode : =, bDone =>, bBusy =>, bActive =>, bCommandAborted =>, bError =>, ErrorID =>) ;

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
IrDeceleration	Specify the deceleration rate. (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
IrJerk Specify the jerk. (Unit: user unit/s ³)		LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
BufferMode	Specify a buffer mode for the instruction. [*]	DMC_BUFFER_MODE	0: Aborting 1: Buffered (0)	When <i>bExecute</i> shifts to True.

*Note: Refer to AX-3 Series Operation Manual for details on BufferMode.

• Outputs

Name Function		Data type	Output range (Default value)
bDone	True when all axes stop with the velocity 0.	BOOL	True/False (False)
bBusy True when the instruction is being executed.		BOOL	True/False (False)
bActive	True when the instruction is controlling axes.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Function	Data type
bDone	 When the axis group decelerates to a stop. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> changes to False but <i>bDone</i> changes to True.
bBusy	• When <i>bExecute</i> shifts to True.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bActive	 When axes start being controlled by the instruction. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. <i>bActive</i> will change to False after remaining True for at least one cycle when <i>bExecute</i> changes to False but <i>bActive</i> changes to True.
bCommandAborted	• When the instruction is aborted by another instruction.	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to True.

Name	Function	Data type	
bError	When an error occurs in the execution conditions		
ErrorID	or input values for the instruction. (Error code is recorded).	• When <i>bExecute</i> shifts from True to False. (Error code is cleared.)	

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGrou p	Specify the axis group.	DMC_AXIS_GROUP_REF	DMC_AXIS_GROUP_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AxisGroup_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- The instruction decelerates the group axes in motion to a pause.
- The axis group enters the state of GroupMoving via the instruction.
- When the velocity 0 is reached, *bDone* changes to True and the axis group changes to StandBy state.
- BufferMode of DMC_GroupHalt only supports 0: Aborting and 1: Buffered. An error will occur with DMC_ERROR.DMC_GM_INVALID_BUFFER_MODE if other BufferMode is used.

• Troubleshooting

When an error occurs in the instruction execution or the axis group enters Errorstop state, *bError* changes to True and axes stops running. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- This example shows the motion behavior which is performed by DMC_GroupHalt after DMC_MoveLinearRelative is executed.
- The axes will enter Standby state after deceleration is completed if no other motion instruction is executed during the period when DMC_MoveLinearRelative is paused via DMC_GroupHalt.
- When DMC_MoveLinearRelative is executed again during deceleration, DMC_GroupHalt will be aborted immediately and the axis group will accelerate again without staying in Standby state any more. The re-execution action described above is allowed for DMC_GroupHalt.



AxisX.Velocity				
DMC_MoveLinear	Relative			
bExecute				
bDone				
bBusy				
bActive				
bAborted		$\Box =$		
bError				
DMC_GroupHalt				
bExecute				
bDone				
bBusy				
bActive				
bAborted				
bError				
State Machine	GroupMoving Standby]	

Timing Diagram

- When bExecute of DMC_GroupHalt changes to True, bCommandAboted of DMC_MoveLinearRelative changes to True and the axes start to decelerate to a stop. And the axis group stays in GroupMoving state.
- When the velocity 0 is reached, bDone of DMC_GroupHalt changes to True and the axis group changes to Standby state.
- When the velocity has not been reduced to 0 yet and bExecute of DMC_GroupHalt changes to True during the instruction execution, DMC_GroupHalt will be aborted by changing bExecute of DMC_MoveLinearRelative to True again and then its bCommandAboted will change to True.
- Supported Products
 - AX-308E, AX-364E

2.3.1.9 DMC_Home_P

DMC_Home_P, an application function block of pulse output, drives the pulse axis to perform the homing in the set mode.

FB/FC	Instruction	Graphic expression	ST expression
FB	DMC_Home_P	Axis DMC_PULSE_AXIS_REF BOOL bDone bExecute BOOL IrPosiotion LREAL BOOL bCommandAborted BOOL bError DFB_HSIO_ERROR ErrorID	DMC_Home_P_instance (Axis : =, bExecute : =, IrPosition : =, bDone =>, bBusy =>, bCommandAborted =>, bError =>, ErrorID =>) ;

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
IrPosition	Specify the position after the homing is completed.	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the homing is completed.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted by another	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
	instruction.		
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DFB_HSIO_ERROR*	DFB_HSIO_ERROR (DFB_HSIO_NO_ERR)

*Note: DFB_HSIO_ERROR: Enumeration (ENUM)

• Output Update Timing

Name	Function	Data type
bDone	 When the homing is completed. 	 When <i>bExecute</i> shifts to False. When <i>bError</i> shifts to True.
bBusy	When <i>bExecute</i> changes to TRUE.	 When <i>bExecute</i> shifts to False. When <i>bError</i> shifts to True.
bCommandAborted	 When the instruction is aborted by MC_Stop. 	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to True.
bError	When an error occurs in the execution conditions	
ErrorID	or input values for the instruction. (Error code is recorded).	 When <i>bExecute</i> shifts from True to False. (Error code is cleared.)

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the source of pulse output axis	DMC_PULSE_AXIS_ REF (FB) *	DMC_PULSE_ AXIS_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_PULSE_AXIS_REF (FB): The function block serves as the drive interface for the pulse output axis, which contains the axis parameter call and the drive program.

• Function

- The pulse output axis specified by the instruction must be selected in Hardware IO Configuration so that the axis can output pulses and perform the homing action according to the pulse axis settings i.e. homing mode, acceleration rate and velocity.
- The instruction can be used only when the pulse output axis is in Standstill state. An error will occur if the instruction is executed in other axis state.
- DMC_Home_P supports homing modes defined in CiA 402 protocol. For details on homing modes, refer to appendices.
- Library of this function block: DL_BuiltInIO_AX3.library.

Troubleshooting

■ When an error occurs in the instruction execution, *bError* of the instruction changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- In this example, the pulse output axis performs the homing motion via DMC_Home_P after the axis is configured in the IO configuration interface.
- Select the first pulse output axis (Pulse Output Axis 0) in Hardware IO Configuration of BuiltIn_IO as below. Then you can see corresponding output points (e.g. OUT0, OUT1) and signal trigger points for pulse output (e.g. IN0, IN1, IN2 and IN3) from the software. The homing motion cannot be performed until the signal trigger points for the homing mode have been configured to corresponding input signal sources.

Chapter 2



After the configuration of the pulse output axis, the variable Pulse_Output_Axis_0 configured in IEC Objects can be taken out as a data type to any function block, as shown below.

Hardware IO Configuration	Variable	Type	Logical Function
PoAxis Configuration	Pulse_Output_Axis_0	PuiseAxis_REF	Puise Output Axis 0
IEC Objects			
Status			
Information			

Pulse_Output_Axis_0 is connected to the input Axis of MC_Power and DMC_ Home_P as shown in the figure below. When the axis is in Standstill state, the instruction is started to perform the homing motion according to the set homing mode. At the moment, the state machine will switch the state from Standstill to Homing.



- After DMC_Home_P is started, the pulse axis Pulse_Output_Axis_0 will perform the homing motion according to the set Home Mode in PoAxis Configuration below. After the function block is executed, the homing motion will be conducted according to different external signals and cases.
- ♦ Homing Mode: Mode 23;
- Homing speed during search for switch: 1000 (Unit: user unit /s);
- Homing speed during search for z phase pulse: 500 (Unit: user unit /s);
- Homing Acceleration: 2000 (Unit: user unit /s²).



- Supported Products
 - AX-308E, AX-364E

2.3.1.10 DMC_ImmediateStop_P

DMC_ImmediateStop_P can stop the PO axis motion immediately and stop the pulse output.

FB/FC	Instruction	Graphic Expression			
FB	DMC_ImmediateStop_P	DMC_ImmediateStop_P Axis DMC_PULSE_AXIS_REF BOOL bDone bExecute BOOL BBUSY BOOL bError DMC_ERROR ErrorId			
	ST Expression				
DMC_	ImmediateStop_P(
Axis :=	,				
bExec	bExecute :=,				
bDone	bDone =>,				
bBusy	bBusy =>,				
bError	bError =>,				
Errorlo	Errorld =>);				

Input

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is enabled when <i>bExecute</i> changes from False to True.	BOOL	True/False(False)	-

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction execution is complete.	BOOL	True/False(False)
bBusy	True when the instruction is triggered to execute.	BOOL	True/False(False)
bError	True when an instruction error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code	DMC_ERROR*	DMC_ERROR(DMC_NO_ERR)

Name	Function	Data type	Output range (Default value)
	descriptions.		

*Note: DMC_ERROR: Enumeration(Enum)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False		
bDone	When the instruction execution is complete.	 When <i>bEexcute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one period when <i>bExecute</i> is False but <i>bDone</i> changes to True. 		
bBusy	• When <i>bExecute</i> shifts to True.	 When <i>bDone</i> shifts to Ture. When <i>bError</i> shifts to Ture. 		
bError	When an error occurs in the execution conditions or input	When <i>bExecute</i> shifts from True to False (Error code is cleared)		
ErrorID	values for the instruction (Error code is recorded in <i>ErrorID</i>).			

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	The axis that is mapped to.	DMC_PULSE_AXIS_REF	DMC_PULSE_AXIS_REF	When <i>bExecute</i> shifts to True, and <i>bBusy</i> is False.

***Note:** DMC_PULSE_AXIS_REF (FB): The function block serves as the drive interface for the pulse output axis, which contains the axis parameter call and the drive program.

• Function

■ When bExecute shifts to True, PO axis motion will be stopped immediately, and pulse output will be stopped immediately without deceleration.

■ Library of this function block is DL_BuiltInIO_AX3.library.

• Troubleshooting

- If an error occurs during instruction execution and output pin bError changes to True, refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to Appendices of this manual.

• Supported Products

AX-308E, AX-364E

2.3.1.11 DMC_MoveVelocityStopByPos

DMC_MoveVelocityStopByPos controls an axis to stop at a specified position after a period of motion.

FB/FC	Instruction	Graphic expression			
FB	DMC_MoveVelocityStopByPos	DMC_MoveVelocityStopByPos Axis AXIS_REF_SM3 BOOL bInVelocity bExecute BOOL BOOL bDone bTriggerStop BOOL BOOL bCommandAborted IrVelocity LREAL BOOL BOOL bExecute IrVelocity LREAL BOOL bError IrAcceleration LREAL DMC_ERROR dwErrorID IrJerk LREAL DMC_ERROR dwErrorID IrRoundPhase LREAL IrStopPhase LREAL			
		ST expression			
DMC_	MoveVelocityStopByPos_instan	ce(
Axis :=	=,				
bExec	ute :=,				
bTrigg	erStop :=,				
IrVeloc	city :=,				
IrAcce	leration :=,				
IrDece	leration :=,				
IrJerk	:=,				
Directi	on :=,				
IrRoun	idPhase:=,				
IrStopl	IrStopPhase:=,				
bInVelocity =>,					
bDone =>,					
bCommandAborted =>,					
bBusy =>,					
bError	=>,				
dwErro	orID =>)				

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
bTriggerStop	The stop command is executed when <i>bExecute</i> is True.	BOOL	True/False (False)	When <i>bExecute</i> is True and the output <i>bBusy</i> is True.
IrVelocity	Specify the target velocity. (Unit: User unit/s)	LREAL	Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrAcceleration	Specify the acceleration rate when the motion starts. (Unit: User unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrDeceleration	Specify the deceleration rate when the motion ends. (Unit: User unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
lrJerk	Specify the jerk. (Unit: User unit/s ³)	LREAL	Positive number (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
Direction	Specify the motion direction.	MC_DIRECTION*	-1: negative 1: positive (positive)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrRoundPhase	Set the modulo.	LREAL	Positive number (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrStopPhase	Specify a position or a phase in the modulo.	LREAL	Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.

*Note: MC_DIRECTION: Enumeration (Enum)

• Outputs

Name	Function	Data type	Output range (Default value)
bInVelocity	True when reaching the target velocity	BOOL	True/False(False)
bDone	If the trigger signal is True and the axis position has been recorded.	BOOL	True/False(False)
bCommandAborted	True when the instruction is aborted by another instruction.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
dwErrorID	rrorID Contains error codes.		DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
bInVelocity	 When axis velocity reaches the target speed. 	 When bCommandAborted shifts to True. When bExecute is re-triggered, and Velocity is given a new value.
bDone	 When the trigger signal is True, and the axis position has been recorded. 	 When bExecute shifts to False. bDone will change to False after remaining True for one period when bExecute is False but <i>bDone</i> changes to True.
bCommandAborted	 When the instruction is aborted by another instruction. 	• When <i>bExecute</i> shifts to False.
bBusy	 When <i>bExecute</i> shifts to True. 	 When bDone shifts to True. When bError shifts to True. When bCommandAborted shifts to True.
bError	When an error occurs in the execution conditions or	When <i>bExecute</i> shifts from True
dwErrorID	input values for the instruction.	to False. (Error code is cleared.)

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bExecute</i> shifts to True.

*Note: AXIS_REF_SM3 (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

■ After *bExecute* of DMC_MoveVelocityStopByPos changes to True, the axis will move with the velocity specified by *IrVelocity* and acceleration specified by *IrAcceleration* until *bTriggerStop* changes to True. Then the axis positioning will start according to *IrDeceleration* and the target position converted from the values of *RoundPhase* and*StopPhase*.



- RoundPhase & StopPhase
 - RoundPhase specifies a modulo. StopPhase is a position in the modulo. The value of StopPhase should be less than that of RoundPhase.
 - When the axis specified by the function block is a linear axis, RoundPhase is the length of the specified modulo. And StopPhase is a point in the specified modulo. When bTriggerStop changes to True, the axis will stop at the position specified by StopPhase, and the final stop position equals an integral multiple of RoundPhase value + StopPhase value.

StopPhase	StopPhase	9	StopF	Phase I	
Round	IPhase	Round	Phase	Round	Phase

When the axis specified by the function block is a rotary axis, RoundPhase specifies the entire phase of the modulo and StopPhase is a phase in the specified modulo. When bTriggerStop changes to True, the axis will stop at the phase specified by StopPhase, and the final stop position is (StopPhase value/RoundPhase value) × Modulo value of the rotary axis.



- Special Case
 - When the stop command is performed, the axis may not be able to complete the stop action with the deceleration rate specified by *Irdeceleration* if the position of the specified axis is too close to the target stop position. Therefore, the axis positioning will end in the next modulo. In that case, it is suggested to adjust the value of *IrDeceleration* or the position where the stop command is triggered so as to satisfy the path planned in the deceleration motion.

Troubleshooting

- When an error occurs in the instruction execution or the axis enters Errorstop state, *bError* changes to True and the axis stops running. To confirm current error state, see the error code in *ErrorID*.
- Programming Examples
 - Programming Example 1:
 - This example illustrates how to use DMC_MoveVelocityStopByPos for phase positioning after the rotary axis motion starts.

	DMC_MoveVeloc	cityStopByPos_0		
TRUE	DMC MoveVeld	DMC MoveVelocityStopByPos		
	EN	ENO	-	
SM_Drive_Virtual	Axis	bInVelocity	Н	
	- bExecute	bDone	Н	
	-bTriggerStop	bCommandAborted	Н	
1000		bBusy	H	
5000		bError	H	
3000		dwErrorID	Н	
50000	-lrJerk		Ľ	
MC_DIRECTION.positive	Direction			
360				
180				

Rotary axis setting

1	Axis type and limits			
	🗸 Virtual mode	Modulo settings		
	Modulo	Modulo value [u]:	3600.0	
	○ Finite			

Timing Diagram

3000		-	1 1 1 1
Position			1
1000			1 1 1
Velocity 0		\backslash	
5000			- - - - - - -
Acceleration 0	/ \		
-3000		\square	
50000	·····	r	
Jerk ⁰	J_L_	<u> </u>	
DMC_MoveVel	ocityStopByPos	b d	
bExecute			
bTriggerStop			
bDriveStart			
	continuous motion(5)	1	1 1 1 1
State Machine	standstill(3)	discrete motion(4)	standstill(3)

- 1. After *bExecute* changes to True, the axis starts to move at a constant speed in the set direction until *bTriggerStop* changes to True to start the positioning motion.
- 2. The *RoundPhase* and *StopPhase* of DMC_MoveVelocityStopByPos are set to 360 and 180, and the Modulo value of the rotary axis is 3600. Therefore, the rotary axis finally stops at 1800.
- 3. Since the axis position exceeds the position specified by *StopPhase* as

bTriggerStop shifts to True, the axis will stop at the next StopPhase position.

- Programming Example 2:
 - This example illustrates how to use DMC_MoveVelocityStopByPos for position locating after the linear axis motion starts.

	DMC_MoveVeloc	ityStopByPos_0		
TRUE	DMC_MoveVelocityStopByPos			
	EN	ENO		
SM_Drive_Virtual -	Axis	bInVelocity		
	bExecute	bDone		
	bTriggerStop	bCommandAborted		
1000	lrVelocity	bBusy		
5000 -	lrAcceleration	bError		
3000 -	lrDeceleration	dwErrorID		
50000	lrJerk			
MC_DIRECTION.negative -	Direction			
5000	lrRoundPhase			
2000 -	lrStopPhase			

Timing Diagram

Position ⁰			
-7000			
0			
Velocity -1000			
3000		·····/////////////////////////////////	
Acceleration ⁰		/ \	
-5000			
50000			
Jerk ⁰	[] [
-50000		L	
DINC_MOVEVER			
bExecute			
bTriggerStop			
bDriveStart			
	continuous motion(5)		
State Machine		discrete motion(4)	
	standstill(3)		standstill(3)

- 1. After *bExecute* changes to True, the axis starts to move at a constant speed in the set direction until *bTriggerStop* changes to True to start the positioning motion.
- 2. The *RoundPhase* and *StopPhase* of DMC_MoveVelocityStopByPos are set to 5000 and 2000 respectively. Therefore, the linear axis finally stops at the position of an integral multiple of 5000 plus 2000.
- 3. Since the axis position exceeds 2000 as *bTriggerStop* shifts to True, the axis will stop at the next 7000.

• Supported Products

AX-308E, AX-364E

2.3.1.12 DMC_GroupInterrupt

DMC_GroupInterrupt makes the current motion pause, and it can be used with DMC_GroupContinue to restore the motion.

FB/FC	Instruction	Graphic Expression				
FB	DMC_GroupInterrupt	DMC_GroupInterrupt AxisGroup DMC_AXIS_GROUP_REF BOOL bDone bExecute BOOL BOOL bBusy IrDeceleration LREAL BOOL bError IrJerk LREAL BOOL bError DMC_ERROR ErrorID				
		ST Expression				
DMC_	GroupInterrupt_instan	ce(
AxisG	roup:= ,					
bExec	ute:= ,					
IrDece	leration:= ,					
IrJerk:	IrJerk:= ,					
bDone=> ,						
bBusy=> ,						
bCom	bCommandAborted=> ,					
bError	bError=> ,					
ErrorI	D=>);					

• Inputs

Name	Function	Data Type	Setting Value (Default value)	Timing for Updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False(False)	-
IrDeceleration	Deceleration (user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.
lrJerk	Jerk ; Jump (Unit: user unit/s³)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.

• Outputs

Name	Function	Data Type	Output Range (Default Value)
bDone	True when all axes stop with the velocity 0.	BOOL	True/False(False)
bBusy	True when the instruction is being executed.	BOOL	True/False(False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
bError	True when an instruction error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendix for error code descriptions.	DMC_ERROR*	DMC_ERROR(DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration(Enum)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	When decelerating to stop.	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	• When <i>bExecute</i> shifts to True.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	• When the instruction is aborted by another instruction.	 When <i>bExecute</i> shifts to False. <i>bCommandAborted</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bCommandAborted</i> changes to True.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts from

Name	Timing for shifting to True	Timing for shifting to False
ErrorID	execution conditions or input values for the instruction. (Error code is recorded).	True to False (Error code is cleared).

• Timing Diagram



In-Outs

Name	Function	Data Type	Setting Value	Timing for Updating
AxisGroup	Axis group that is mapped to.	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

***Note:** DMC_AXIS_GROUP_REF(FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- This instruction can decelerate and stop the motion of axis groups other than DMC_GroupStop.
- During deceleration, the status of the axis groups remains GroupMoving.
- When the speed reaches 0, the output pin bDone will immediately changes to True, and the status of the axis groups will switch to StandBy.
- If Group state machine is GroupMoving during execution, after the instruction execution, the following Continue data will be recorded for subsequent DMC_GroupContinue to resume the motion.
- The instructions that have not finished execution (including the instructions that have not finished execution in the instruction buffer area).
- Position after motion stops (AxisGroup.ContinuePos).

After recording the dada, AxisGroup.bContinueDataWriten will be set to TRUE.

The execution will not be recorded if it is not completed.

- When there is currently Continue data, re-execute DMC_GroupInterrupt. The current Continue data will firstly be cleared. Whether to record new Continue for follow-up depends on if the execution is successful.
- During the execution of DMC_GroupInterrupt, users might encounter the following situation:

- During DMC_GroupInterrupt execution, DMC_GroupInterrupt will be interrupted when triggering DMC_GroupStop.
- During DMC_GroupInterrupt execution, when the second function block DMC_GroupInterrupt is re-triggered, it will be interrupted.
- During DMC_GroupInterrupt execution, DMC_GroupInterrupt continues running when axis groups motion instructions are carried out. Motion instructions are at the Busy state until DMC_GroupInterrupt execution is completed, and the instructions will be added into instruction buffer to start execution.

Troubleshooting

- If an error occurs during instruction execution, or the status of the axis groups is "GroupErrorstop", *bError* is changed to True, and the axis motion will stop. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to Appendices of this manual.

• Programming Example

This example shows that the DMC_GroupInterrupt function block is executed when the axis group is running. After the axis group stops running, the DMC_GroupContinue function block is used again to restore the axis group motion.



Timing Diagram

AxisX.Velocity				
DMC_MoveLinearR	elative			
bExecute				
bDone				
bBusy .				
bActive				
bCommandAborte d				
bError				
DMC_GroupInterrup	pt		_	
bExecute				
bDone .				
bBusy				
bCommandAborted				
bError				
DMC_GroupContinu	e		F	
bExecute				
bDone				
bBusy				
bCommandAborted				
bError		• -		
	GroupMoving			
State Machine	Standby	Ĺ		

- When bExecute of DMC_MoveLinearRelative changes to True, the axis group starts to run.
- When bExecute of DMC_GroupInterrupt changes to True, the axis group will decelerate until the speed reaches 0 and stops. The status of DMC_GroupInterrupt will be changed from Busy to Done.
- At this time, bExecute of DMC_GroupContinue changes to True, and the

unfinished motion path of previous DMC_MoveLinearRelative of the axis group will be completed.

• Supported Products

AX-308E, AX-364E

2.3.1.13 DMC_GroupContinue

DMC_GroupContinue restores the interrupted motion of DMC_GroupInterrupt.

FB/FC	Instruction	Graphic expression			
FB	DMC_GroupContinue	DMC_GroupContinue AxisGroup DMC_AXIS_GROUP_REF BOOL bDone bExecute BOOL BBOOL bBusy BOOL bCommandAborted BOOL bError BOOL bError BOOL bError DMC_ERROR ErrorID BOOL BOOL			
	ST expression				
DMC_ AxisGi bExec	DMC_GroupContinue_instance(AxisGroup:= , bExecute:= ,				
bDone	bDone=>,				
bBusy bComi bError	bCommandAborted=> , bError=> ,				
ErrorI	ErrorID=>);				

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False(False)	-

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when motion is resumed.	BOOL	True/False(False)

Name	Function	Data type	Output range (Default value)
bBusy	True when the instruction is triggered to execute.	BOOL	True/False(False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False(False)
bError	True when an instruction error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR(DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration(Enum)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	When motion is resumed.	 When bExecute shifts to False. bDone will change to False after remaining True for one cycle when bExecute is False but bDone changes to True.
bBusy	• When <i>bExecute</i> changes to TRUE.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When the instruction is aborted by another function block. 	 When bExecute shifts to False. bCommandAborted will change to False after remaining True for one cycle when bExecute is False but bCommandAborted changes to True.
bError	When an error occurs in the execution conditions	When <i>bExecute</i> shifts from True to False (Error code is cleared)
ErrorID	or input values for the instruction. (Error code is recorded).	
• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Axis group that is mapped to	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

***Note:** DMC_AXIS_GROUP_REF(FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- This instruction can resume the axis group motion that is stopped by DMC_GroupInterrupt.
- Three conditions for successfully execute this instruction:
 - The current status of the axis group is GroupStandby.
 - There is recorded Continue data (the axis group variable AxisGroup.bContinueDataWriten is True).
 - The current position is at AxisGroup.ContinuePos.
- Output pin bDone will immediately change to True after the execution is successful, and clear the Continue data that is recorded.

• Troubleshooting

- When an error occurs during the instruction execution or the axis group enters GroupErrorstop state, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to **Appendices** of this manual.

• Programming Example

■ Refer to <u>DMC_GroupInterrupt</u> programming example.

Supported Products

AX-308E, AX-364E

2.3.2 Administrative Instructions

2.3.2.1 DMC_GroupEnable

DMC_GroupEnable switches the axis group state from GroupDisable to GroupStandby.

FB/FC	Instruction	Graphic expression				
FB	DMC_GroupEnable	DMC_GroupEnable —AxisGroup DMC_AXIS_GROUP_REF BOOL bDone —bExecute BOOL BOOL bError DMC_ERROR ErrorID				
		ST expression				
DMC_	GroupEnable_instan	ce (
AxisG	roup: = ,					
bExec	bExecute: = ,					
bDone=> ,						
bBusy	bBusy=> ,					
bError	bError=> ,					
ErrorI	ErrorID=>) ;					

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False		
bDone	 When the instruction is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True. 		
bBusy	• When <i>bExecute</i> changes to TRUE.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. 		
bError (ErrorID)	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded).	• When <i>bExecute</i> shifts from True to False. (Error code is cleared)		

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Specify	DMC_AXIS_	DMC_AXIS_	When <i>bExecute</i> shifts to True

Name	Function	Data type	Setting value	Timing for updating
	the axis group	GROUP_REF*	GROUP_REF	and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

■ First, add axes to SoftMotion General Axis Pool in the project. In this example, six virtual axes have been established, i.e. AxisX, AxisY, AxisZ, AxisA, AxisB and AxisC.

Devices 👻 🔻	×
DMC_MoveCircularAbsolute	-
🖮 🔟 Device	
🖹 🗐 PLC Logic	
🖻 🧔 Application	
🖮 🍐 SoftMotion General Axis Pool	
🔗 AxisX (SM_Drive_Virtual)	
AxisY (SM_Drive_Virtual)	
AxisZ (SM_Drive_Virtual)	
AxisA (SM_Drive_Virtual)	
AxisB (SM_Drive_Virtual)	
AxisC (SM_Drive_Virtual)	

■ Right-click on **Device** in the project and then choose "Add Device".



After right-clicking on Device and selecting Add device, find DMC_Axis_Group and then click Add Device button.

🗂 Add Device					×
Name DMC_Axis_Group Action Append device Insert device	rice () Plug d	evice O	Update devi	ice	
String for a fulltext search		Vendor	<all td="" vende<=""><td>ors></td><td>~</td></all>	ors>	~
Name = 🗊 Miscellaneous	Vendor		Version	Description	
DMC_Axis_Group	Delta Electronic	s, Inc.	0.2.2.0	Axis Group Module that	support PLC open pi
 ✓ Group by category □ Displa 	y all versions (f	or experts	only) 🗌 D	isplay outdated versions	>
Name: DMC_Axis_Group Vendor: Delta Electronics, Categories: Version: 0.2.2.0 Order Number: N/A	Inc.			-	×
Append selected device as las Device (You can select another targ	t child of get node in the r	navigator	while this wi	ndow is open.)	
				Add Device	Close

Once DMC_Axis_Group (DMC_Axis_Group) appears in Device, it indicates that adding the axis group is successful.



Click DMC_Axis_Group setting page and then select AxisGroup Parameters item. In the Parameter column, AxisX~AxisC represent axes 1 ~ 6 in the axis group. Fill in the value field of the Axis X ~ Axis C with the names of the previously created virtual axes "AxisX" ~ "AxisC", as shown in the red box below. The axis group in this example uses 6 axes, AxisX, AxisY, AxisZ, AxisA, AxisB and AxisC.

MC_Axis_Group X						
Axis Group Parameters	Parameter	Туре	Value	Default	Unit	Description
No. Come Montenation	🗇 🗇 Axis X	STRING	"AxisX"			The name of X-coordinate Axis in Axis Group
AxisGroup I/O Mapping	- 🛷 Axis Y	STRING	"AxisY"			The name of Y-coordinate Axis in Axis Group
AvisGroup IEC Objects	- 🛷 Axis Z	STRING	"AxisZ"			The name of Z-coordinate Axis in Axis Group
Austroup incooperis	- 🗇 Axis A	STRING	'AxisA'			The name of the 1st following Axis in Axis Group
Status	Axis B	STRING	'AxisB'	1.1.1		The name of the 2nd following Axis in Axis Group
	- 🗇 Axis C	STRING	'AxisC'			The name of the 3rd following Axis in Axis Group
Information	🖉 🖗 Ramp Type	Enumeration of BYTE	S Curve	S Curve		The Ramp Type of the Axis Group
	 Max Velocity Limit 	LREAL	1000000	1000000		The Max Velocity Limit of the Axis Group. (Zero means no limit)
	Max Acceleration Limit	LREAL	2000000	2000000		The Max Acceleration Limit of the Axis Group. (Zero means no limit)
	 Max Deceleration Limit 	LREAL	2000000	2000000		The Max Deceleration Limit of the Axis Group. (Zero means no limit)
	Max Jerk Limit (Reserved)	LREAL	0	0		The Max Jerk Limit of the Axis Group. (Zero means no limit)

- AxisX ~ AxisC in the AxisGroup Parameters represent the axes 1 ~ 6 in the axis group respectively, which denotes a 6D space, i.e. coordinate axes X, Y, Z, A, B and C. No value is required for the coordinate axis which is not set.
- If the Value field for axes in the AxisGroup Parameters is not filled in with the names of axes, no error will occur when DMC_GroupEnable is started. However, the axis group will report an error if it starts to move the axis the name of which is not entered in the Value field.
- If there are same axis names or invalid axis names in the Value field for axes in the AxisGroup Parameters, an error will occur when DMC_GroupEnable is executed.
- At least one axis is specified in the Value field for axes in the AxisGroup Parameters. Otherwise, an error will occur when DMC_GroupEnable is executed.
- Whether the specified single axis is in Standstill state or not will not be judged when DMC_GroupEnable is executed. After the axis group is created, the state of the axis group will be switched from GroupDisable to GroupStandby and the axes in the axis group will maintain the current state.
- If axes in the group are in ErrorSTOP state, the axis group state will change from GroupDisable->GroupStandby->GroupErrorStop.
- For more details on axis states, please refer to Axis State Transitions in AX-3 Series Operation Manual.

• Troubleshooting

- When an error occurs during the instruction execution or the axis group enters GroupErrorstop state, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to Appendices of this manual.

• Programming Example

Based on the limitation of the number of axes for simultaneous motion and the actual demand of axes, DMC_GroupEnable switches the axis group state from GroupDisable to GroupStandby for the upcoming axis group motion.

Devices 👻 🕈 🗙
DMC_GroupEnable
🖻 💮 Device
PLC Logic
Application
DMC_Axis_Group (DMC_Axis_Group)
🖮 🍐 SoftMotion General Axis Pool
Axis1 (SM_Drive_Virtual)
Axis2 (SM_Drive_Virtual)
Axis3 (SM_Drive_Virtual)
Axis4 (SM_Drive_Virtual)
Axis5 (SM_Drive_Virtual)
Axis6 (SM_Drive_Virtual)

DMC_Axis_Group X						
AxisGroup Parameters	Parameter	Туре	Value	Defaul	Unit	Description
	Axis X	STRING	'Axis1'			The name of X-coordinate Axis in Axis Group
AxisGroup I/O Mapping	🖤 🚸 Axis Y	STRING	'Axis2'	1.1		The name of Y-coordinate Axis in Axis Group
AvisGroup IEC Objects	🖤 🛷 Axis Z	STRING	'Axis3'	1.1		The name of Z-coordinate Axis in Axis Group
Axis Group Ice Objects	🖤 🛷 Axis A	STRING	'Axis4'	1.1		The name of the 1st following Axis in Axis Group
Status	🖤 🛷 Axis B	STRING		1.1		The name of the 2nd following Axis in Axis Group
	🖤 🚸 Axis C	STRING		1.1		The name of the 3rd following Axis in Axis Group
Information	Ramp Type	Enumeration of BYTE	S Curve	S Curve		The Ramp Type of the Axis Group
	🖤 🕸 Max Velocity Limit	LREAL	1000000	1000000		The Max Velocity Limit of the Axis Group. (Zero means no limit)
	Max Acceleration Limit	LREAL	2000000	2000000		The Max Acceleration Limit of the Axis Group. (Zero means no limit)
	Max Deceleration Limit	LREAL	2000000	2000000		The Max Deceleration Limit of the Axis Group. (Zero means no limit)
	Max Jerk Limit (Reserved)	LREAL	0	0		The Max Jerk Limit of the Axis Group. (Zero means no limit)

	DMC_GroupEnable_0	_
	DMC_GroupEnable	
	EN ENO	
DMC_Axis_Group -↔	AxisGroup bDone	-group_done
group_exe —	bExecute bBusy	- group_busy
	bError	group_error
	ErrorID	group_errorID

- 1. Before the absolute interpolation motion of Axis1~ Axis4 is performed, create Axis1~Axis4 first, add them to the axis group DMC_Axis_Group and then input Axis1~Axis4 in the Value field for Parameter AxisX~AxisA in the setting page.
- 2. Use DMC_GroupEnable to create the axis group first before Axis 1 ~ Axis 4 perform the absolute interpolation of simultaneous motion of four axes.
- 3. DMC_GroupEnable is triggered by changing group_exe (bExecute) to True. When group_done (bDone) changes to True, the axis group DMC_Axis_Group switches its state from GroupDisable to GroupStandby. The specified axes in the axis group maintain current state.
- 4. When DMC_GroupEnable is executed after the axis group is created, no error occurs and the axes enter Standstill state. Then the axis group DMC_Axis_Group can be used for the interpolation of simultaneous motion.
- Supported Products
 - AX-308E, AX-364E

2.3.2.2 DMC_GroupDisable

DMC_GroupDisable sets the state of an axis group to GroupDisable.

FB/FC	Instruction	Graphic expression				
FB	DMC_GroupDisable	DMC_GroupDisable — AxisGroup DMC_AXIS_GROUP_REF BOOL bDone — bExecute BOOL BOOL bError DMC_ERROR ErrorID				
	ST expression					
DMC_	GroupDisable_instan	ce (
AxisG	roup: = ,					
bExec	bExecute: = ,					
bDone	bDone=> ,					
bBusy	bBusy=> ,					
bError	bError=> ,					
ErrorI	ErrorID=>) ;					

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the instruction is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	• When <i>bExecute</i> changes to TRUE.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError (ErrorID)	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded).	• When <i>bExecute</i> shifts from True to False. (Error code is cleared)

Output Update Timing

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Specify the axis group	DMC_AXIS_ GROUP_REF*	DMC_AXIS_GROUP_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- When this instruction is executed for an axis group, the axis group state will switch from GroupStandby to GroupDisable but the state of axes in the axis group will remain unchanged.
- If the axis group is not in GroupStandby state, an error will occur when

DMC_GroupDisable is executed.

For more details on axis states, please refer to **Axis State Transitions**.

• Troubleshooting

- When an error occurs during the instruction execution or the axis group enters GroupErrorstop state, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to **Appendices** of this manual.

• Programming Example

Switch the axis group state from GroupStandby to GroupDisable.

	_		
	DMC_Grou	upDisable	
	EN	ENO	
DMC_Axis_Group —↔	AxisGroup	bDone	groupdis_done
groupdis_exe —	bExecute	bBusy	-groupdis_busy
		bError	-groupdis_error
		ErrorID	groupdis_errorID
			1

- This instruction enables the group axis DMC_Axis_Group specified by AxisGroup to enter the GroupDisable state.
- DMC_GroupDisable is executed when groupdis_exe (*bExecute*) changes to true. When groupdis_done (*bDone*) changes to true, it indicates that DMC_Axis_Group axis group has successfully entered GroupDisable state.

• Supported Products

AX-308E, AX-364E

2.3.2.3 DMC_GroupReadParameter

DMC_GroupReadParameter reads axis group parameters.

FB/FC	Instruction	Graphic expression		
FB	DMC_GroupReadParameter	DMC_GroupReadParameter AxisGroup DMC_AXIS_GROUP_REF BOOL BOOL DEnable BOOL BOOL BEOL Parameter DMC_GROUP_PARAMETER BOOL DEFROR DMC_ERROR DMC_ERROR LREAL ItValue		
	ST expression			

FB/FC	Instruction	Graphic expression				
DMC_GroupReadParameter_instance(AxisGroup:= ,						
bEnab	le:= ,					
Param	eter:= ,					
bValid:	=> ,					
bBusy	=> ,					
bError	bError=> ,					
ErrorID	ErrorID=> ,					
IrValue	e=>);					

Inputs

Name	Functio n	Data type	Setting value (Default value)	Timing for updatin g
bEnable	The instructio n is enabled when <i>bEnable</i> changes from False to True.	BOOL	True/False(False)	_
Paramet er	Set the paramet er to be written	DMC_GROUP_PARAMET ER [*]	DMC_GROUP_PARAMET ER* (PARAM_RAMP_TYPE)	Whew the function block <i>bEnable</i> <i>is</i> True, the setting paramet er of Paramet er will be updated.

*Note: DMC_GROUP_PARAMETER: Enumeration (Enum)

Setting Value	Name	Function
16	PARAM_RAMP_TYPE	Velocity ramp type
17	PARAM_MAX_VELOCITY_LIMIT	Max. velocity limit
18	PARAM_MAX_ACCELERATION_LIMIT	Limit on max.

Setting Value	Name	Function
		acceleration
19	PARAM_MAX_DECELERATION_LIMIT	Limit on max. deceleration
22	PARAM_STOP_METHOD	Stop method
24	PARAM_VELOCITY_WARNING_PERCENTAGE	Velocity warning range
25	PARAM_ACCELERATION_WARNING_PERCENTAGE	Acceleration warning range
26	PARAM_DECELERATION_WARNING_PERCENTAGE	Deceleration warning range
28	PARAM_RADIUS_CORRECTION_PERCENTAGE	Allowable correction range of radius

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when the output value is valid.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*1	DMC_ERROR (DMC_NO_ERROR)
IrValue	Read parameter value	LREAL*2	Positive number, negative number , or 0 (0)

*Note:

- 1. DMC_ERROR: Enumeration (Enum)
- 2. No matter what number type of the original parameter type is (including ENUM), the read parameter will be expressed as LREAL.

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bValid	• When <i>bEnable</i> shifts to True, and the output pin IrValue is valid.	When bEnable shifts to False.When <i>bError</i> shifts to True.
bBusy	• When <i>bEnable</i> shifts to True.	• When <i>bValid</i> shifts to True.

Name	Timing for shifting to True	Timing for shifting to False
		• When <i>bError</i> shifts to True.
bError	When an error occurs in the execution conditions or input	When bEnable shifts to False (clear the error code recorded in
ErrorID	values for the instruction (error code is recorded in <i>ErrorID</i>).	ErrorID).
IrValue	 Continuously update the value when <i>bEnable</i> is True. 	 Continuously update the value when <i>bEnable</i> is True.

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Axis group that is mapped to	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bEnable</i> shifts to True, and <i>bBusy</i> is False.

*Note: DMC_AXIS_GROUP_REF(FB): The interface is built in every function block and works as the starting program of the function block.

Function

■ If the parameter to be read is of the ENUM type, the read parameter will be its corresponding number.

• Troubleshooting

- When an error occurs in the instruction execution or the axis group enters GroupErrorstop state, *bError* changes to True and axes stops running. To confirm current error state, see the error code in *ErrorID*.
- For error codes and corresponding trouble shootings, refer to **Appendices** for error code descriptions.

• Programming Example

■ This example shows how to directly use DMC_GroupReadParameter to read axis

group parameters.

	DMC_GroupReadParameter_0	
	DMC_GroupReadParameter	
	EN ENO	
DeltaAxisGroup —	AxisGroup bValid	
	bEnable bBusy	-
DMC_GROUP_PARAMETER.PARAM_MAX_VELOCITY_LIMIT	Parameter bError	-
	ErrorId	-
	lrValue	-

• Supported Products

AX-308E, AX-364E

2.3.2.4 DMC_GroupWriteParameter

DMC_GroupWriteParameter writes axis group parameters.

FB/FC	Instruction	Graphic expression			
FB	DMC_GroupWriteParameter	DMC_GroupWriteParameter AxisGroup DMC_AXIS_GROUP_REF BOOL bDone bExecute BOOL BOOL bBusy Parameter DMC_GROUP_PARAMETER BOOL bError IrValue LREAL DMC_ERROR ErrorId			
	ST expression				
DMC_	GroupWriteParameter_instan	ce(
AxisGr	roup:= ,				
bExec	ute:= ,				
Param	Parameter:= ,				
IrValue	IrValue:= ,				
bDone	bDone=> ,				
bBusy	bBusy=> ,				
bError	bError=> ,				
ErrorID	ErrorID=>);				

• Inputs

Name	Functio n	Data type	Setting value (Default value)	Timing for updatin g
bExecute	The instructio n is executed	BOOL	True/False(False)	-

Name	Functio n	Data type	Setting value (Default value)	Timing for updatin g
	when bExecut e changes from False to True.			
Paramet er	Set the paramet er to be written	DMC_GROUP_PARAMET ER ^{*2}	DMC_GROUP_PARAMET ER (PARAM_RAMP_TYPE)	Whew the function block <i>bExecute</i> <i>is</i> True, the setting paramet er of Paramet er will be updated.
lrValue	The value to be written	LREAL*1	Positive number, negative number , or 0 (0)	When the function block <i>bExecute</i> shifts to True, the setting paramet er of Paramet er will be updated.

*Note:

1. No matter what number type of the original parameter type is (including ENUM), the read parameter will be expressed as LREAL.

2. DMC_GROUP_PARAMETER: Enumeration (Enum)

Setting Value	Name	Function
16	PARAM_RAMP_TYPE	Velocity ramp type
17	PARAM_MAX_VELOCITY_LIMIT	Max. velocity limit
18	PARAM_MAX_ACCELERATION_LIMIT	Limit on max. acceleration
19	PARAM_MAX_DECELERATION_LIMIT	Limit on max. deceleration

Setting Value	Name	Function
22	PARAM_STOP_METHOD	Stop method
24	PARAM_VELOCITY_WARNING_PERCENTAGE	Velocity warning range
25	PARAM_ACCELERATION_WARNING_PERCENTAGE	Acceleration warning range
26	PARAM_DECELERATION_WARNING_PERCENTAGE	Deceleration warning range
28	PARAM_RADIUS_CORRECTION_PERCENTAGE	Allowable correction range of radius

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the parameter is written.	BOOL	True/False(False)
bBusy	True when the instruction is being executed.	BOOL	True/False(False)
bError	True when an instruction error occurs.	BOOL	True/False(False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR(DMC_NO_ERR)

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False		
bDone	• When the parameter is written	 When <i>bEexcute</i> shifts to False. When <i>bError</i> shifts to True. 		
bBusy	• When <i>bExexcute</i> shifts to True	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. 		
bError	When an error occurs in the execution conditions or input	When <i>bEexcute</i> shifts to False (clear the error code recorded in		
ErrorID	values for the instruction (error code is recorded in <i>ErrorID</i>).	ErrorID).		

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Axis group that is mapped to	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bExecute</i> shifts to True, and <i>bBusy</i> is False.

*Note: DMC_AXIS_GROUP_REF(FB): The interface is built in every function block and works as the starting program of the function block.

• Function

If the parameter to be write is of the ENUM type, set IrValue as the corresponding number.

• Troubleshooting

- When an error occurs in the instruction execution or the axis group enters GroupErrorstop state, bError changes to True and axes stops running. To confirm current error state, see the error code in ErrorID.
- For error codes and corresponding trouble shootings, refer to **Appendices** for error code descriptions.

• Programming Example

■ Refer to the programming example of DMC_GroupReadParameter.

Supported Products

■ AX-308E, AX-364E

Chapter 2

2.3.2.5 DMC_GroupReadStatus

 $\label{eq:def_DMC_GroupReadStatus} \mathsf{PMC}_\mathsf{GroupReadStatus} \text{ reads the state of an axis group}.$

FB/FC	Instruction	Graphic expression			
FB	DMC_GroupReadStatus	DHC_GroupReadStatus AxisGroup DMC_AXIS_GROUP_REF BOOL bBooL bBooL			
		ST expression			
DMC_ AxisGi bEnab bValid bBusy bError ErrorII bGrou	ST expression DMC_GroupReadStatus_instance (AxisGroup: = , bEnable: = , bValid=> , bValid=> , bBusy=> , bError=> , ErrorID=> , bGroupMoving=> , bGroupErrorStop=> , bGroupStandby=> , bGroupDisabled=> , bConstantVelocity=> , bAccelerating=> ,				

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>bEnable</i> changes from False to True.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when the output values are valid.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR [*]	DMC_ERROR (DMC_NO_ERROR)
bGroupMoving	True when the axis group state is <i>bGroupMoving</i> .	BOOL	True/False (False)
bGroupHoming	True when the axis group state is <i>bGroupHoming.</i>	BOOL	True/False (False)
bGroupErrorStop	True when the axis group state is <i>bGroupErrorStop</i> .	BOOL	True/False (False)
bGroupStandby	True when the axis group state is <i>bGroupStandby</i> .	BOOL	True/False (False)
bGroupStopping	True when the axis group state is <i>bGroupStopping</i> .	BOOL	True/False (False)
bGroupDisabled	True when the axis group state is <i>bGroupDisabled</i> .	BOOL	True/False (False)
bConstantVelocity	True when the axis group runs at a constant velocity.	BOOL	True/False (False)
bAccelerating	True when the axis group accelerates.	BOOL	True/False (False)
bDecelerating	True when the axis group decelerates.	BOOL	True/False (False)
bInPosition	True when the axis group reaches the target position.	BOOL	True/False (False)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bValid	• When <i>bEnable</i> is True and other axis group state outputs are valid.	 When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.

Name	Timing for shifting to True	Timing for shifting to False
bBusy	 When <i>bEnable</i> changes to TRUE. 	 When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bError (ErrorID)	 When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded). 	 When <i>bEnable</i> shifts from True to False. (Error code is cleared).
bGroupMoving	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bGroupHoming	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bGroupErrorStop	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bGroupStandby	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bGroupStopping	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bGroupDisabled	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bConstantVelocity	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bAccelerating	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bDecelerating	 When <i>bEnable</i> is True and the output keeps updating its value. 	 When <i>bEnable</i> is True and the output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bInPosition	• When <i>bEnable</i> is True and the	• When <i>bEnable</i> is True and the

Name	Timing for shifting to True	Timing for shifting to False
	output keeps updating its value.	 output keeps updating its value. When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Specify the axis group	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bEnable</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

■ DMC_GroupReadStatus can be used to read the state of an axis group.

• Troubleshooting

- When an error occurs during the instruction execution or the axis group enters GroupErrorstop state, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to Appendices of this manual.

• Programming Example

The example shows how DMC_GroupReadStatus is used to read the current state of the specified axis group





- Add DMC_Axis_Group in **Device** of the software.
- When groupstatus_valid (*bValid*) changes to True after groupstatus_en (*bEnable*) changes to True, DMC_GroupReadStatus reads the state of the axis group DMC_Axis_Group via its outputs.
- Supported Products
 - AX-308E, AX-364E

2.3.2.6 DMC_GroupReadError

DMC_GroupReadError reads axis group errors.

FB/FC	Instruction	Graphic expression			
FB	DMC_GroupReadError	DMC_GroupReadError AxisGroup DMC_AXIS_GROUP_REF BOOL bValid bEnable BOOL BBusy BOOL bError DMC_ERROR ErrorID DMC_ERROR GroupErrorID			
		ST expression			
DMC_	GroupReadError_instan	ce (
AxisG	roup: = ,				
bEnab	le: = ,				
bValid:	bValid=> ,				
bBusy	bBusy=> ,				
bError=> ,					
ErrorI	ErrorID=> ,				
Group	GroupErrorID=>) ;				

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>bEnable</i> changes from False to True.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when the output value is valid.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR [*]	DMC_ERROR (DMC_NO_ERROR)
GroupErrorID	When the axis group is in ErrorStop state, the output shows an error code for the current axis group. Refer to Appendices for error code descriptions.	DMC_ERROR	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bValid	 When <i>bEnable</i> is True and the output value is valid. 	When bEnable shifts to False.When bError shifts to True.
bBusy	• When <i>bEnable</i> is True	When bEnable shifts to False.When bError shifts to True.
bError (ErrorID)	 When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded in <i>ErrorID</i> and axis group error code is recorded in <i>GroupErrorID</i>). 	 When bEnable shifts from True to False. (Both the error code in ErrorID and axis group error code in GroupErrorID are cleared)
GroupErrorID	• When <i>bEnable</i> is True and the output keeps updating.	When bEnable is True and the output keeps updating.

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Specify the axis group	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bEnable</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- DMC_GroupReadError can be used to read axis group errors.
- The value of *GroupErrorID* is 0 if no axis group error occurs.

• Troubleshooting

- When an error occurs during the instruction execution or the axis group enters GroupErrorstop state, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to **Appendices** in this manual.

• Programming Example

The example shows how DMC_GroupReadError is used to read an axis group error after the axis group is created.



DMC_GroupReadError_0		
ReadError		
ENO		
bValid	-groupreaderr_valid	
bBusy	groupreaderr_busy	
bError	groupreaderr_error	
ErrorID	groupreaderr_errorID	
GroupErrorID	groupreaderr_grouperrorID	
	eadError_0 ReadError ENO bValid bBusy bError ErrorID GroupErrorID	

- Add DMC_Axis_Group in **Device**.
- When groupreaderr_valid (*bValid*) changes to True after groupreaderr_en (*bEnable*) changes to True, DMC_GroupReadError reads the state of the axis group DMC_Axis_Group via its output.

• Supported Products

AX-308E, AX-364E

2.3.2.7 DMC_GroupRe DMC_GroupReset resets an axis group which is in GroupErrorstop state.

FB/FC	Instruction	Graphic expression			
FB	DMC_GroupReset	DMC_GroupReset AxisGroup DMC_AXIS_GROUP_REF BOOL bDone bExecute BOOL BOOL bBusy BOOL bError DMC_ERROR ErrorID			
	ST expression				
DMC_	DMC_GroupReset_instance(
AxisG	AxisGroup: = ,				
bExec	bExecute: = ,				
bDone	bDone=> ,				
bBusy	bBusy=> ,				
bError	bError=> ,				
ErrorI	ErrorID=>) ;				

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
	completed.		
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When axis group errors clearing is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one cycle when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	 When bExecute changes to TRUE. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError (ErrorID)	• When an error occurs in the execution conditions or input values for the instruction. (Error code is recorded).	• When <i>bExecute</i> shifts from True to False. (Error code is cleared)

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
AxisGroup	Specify the axis group	DMC_AXIS_ GROUP_REF*	DMC_AXIS_ GROUP_REF	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

DMC_AXIS_GROUP_REF (FB): All function blocks for an axis group contain this variable, which works as the starting program for function blocks.

• Function

- When an axis group is in GroupErrorstop state, DMC_GroupReset can be used to clear axis group errors and switch the axis group state to GroupStandby.
- When the axis group enters the GroupStandby state, it indicates that the axis group motion can be performed.

• Troubleshooting

- When an error occurs during the instruction execution or the axis group enters GroupErrorstop state, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.
- For error codes and corresponding troubleshooting, please refer to **Appendices** of this manual.

• Supported Products

AX-308E, AX-364E

2.3.2.8 DMC_CamReadTappetStatus

DMC_CamReadTappetStatus reads the status of multiple tappets.

FB/FC	Instruction	Graphic expression	
FB	DMC_CamReadTappetStatus	DMC_CamReadTappetStatus Tappets BOOL bValid - bEnable BOOL bBusy - TrackID1 INT BOOL bError - TrackID2 INT BOOL bStatus1 - TrackID3 INT BOOL bStatus2 - TrackID4 INT BOOL bStatus2 - TrackID5 INT BOOL bStatus3 - TrackID6 INT BOOL bStatus4 - TrackID6 INT BOOL bStatus5 - TrackID6 INT BOOL bStatus5 - TrackID6 INT BOOL bStatus5 - TrackID8 INT BOOL bStatus5	
ST expression			

FB/FC	Instruction	Graphic expression
DMC_	CamReadTappetStatus_instar	ice (
Tappe	ts : =,	
bEnab	le : =,	
iTrack	ID1 : =,	
iTrack	ID2 : =,	
iTrack	ID3 : =,	
iTrack	ID4 : =,	
iTrack	ID5 : =,	
iTrack	ID6 : =,	
iTrack	ID7 : =,	
iTrack	ID8 : =,	
bValid	=>,	
bBusy	=>,	
bError	=>,	
ErrorI) =>,	
bStatu	s1 =>,	
bStatu	s2 =>,	
bStatu	s3 =>,	
bStatu	s4 =>,	
bStatu	s5 =>,	
bStatu	s6 =>,	
bStatu	s7 =>,	
bStatu	s8 =>) ;	

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>bEnable</i> changes from False to True.	BOOL	True/False (True)	-
iTrackID1	Specify the tappet number.	INT	0~512 (0) *	When <i>bEnable</i> is True.
iTrackID2	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.
iTrackID3	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.
iTrackID4	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.

Name	Function	Data type	Setting value (Default value)	Timing for updating
iTrackID5	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.
iTrackID6	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.
iTrackID7	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.
iTrackID8	Specify the tappet number.	INT	0~512 (0)	When <i>bEnable</i> is True.

*Note:

If the Track ID is set to 0, the corresponding output will not be used to read the tappet status.

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when the outputs are valid.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)
bStatus1	The status of the tappet specified by <i>iTrackID1</i> .	BOOL	True/False (False)
bStatus2	The status of the tappet specified by <i>iTrackID2</i> .	BOOL	True/False (False)
bStatus3	The status of the tappet specified by <i>iTrackID3.</i>	BOOL	True/False (False)
bStatus4	The status of the tappet specified by <i>iTrackID4</i> .	BOOL	True/False (False)
bStatus5	The status of the tappet specified by <i>iTrackID5</i> .	BOOL	True/False (False)
bStatus6	The status of the tappet specified by <i>iTrackID6</i> .	BOOL	True/False (False)
bStatus7	The status of the tappet specified by <i>iTrackID7</i> .	BOOL	True/False (False)

Chapter 2

Name	Function	Data type	Output range (Default value)
bStatus8	The status of the tappet specified by <i>iTrackID8</i> .	BOOL	True/False (False)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bValid	• When <i>bEnable</i> shifts to True.	 When <i>bError</i> shifts to True. When <i>bEnable</i> shifts to False.
bBusy	• When <i>bEnable</i> shifts to True.	• When <i>bError</i> shifts to True.
bError	• When an error occurs in the	When <i>bEnable</i> shifts to Ealso
ErrorID	values for the instruction.	• When behave shins to Palse.
bStatus1	• When the status of the specified tappet is True.	 When the status of the specified tappet is False.
bStatus2	• When the status of the specified tappet is True.	• When the status of the specified tappet is False.
bStatus3	• When the status of the specified tappet is True.	 When the status of the specified tappet is False.
bStatus4	• When the status of the specified tappet is True.	 When the status of the specified tappet is False.
bStatus5	 When the status of the specified tappet is True. 	 When the status of the specified tappet is False.
bStatus6	 When the status of the specified tappet is True. 	 When the status of the specified tappet is False.
bStatus7	• When the status of the specified tappet is True.	 When the status of the specified tappet is False.
bStatus8	 When the status of the specified tappet is True. 	 When the status of the specified tappet is False.

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Tappets	Tappet signal source	SMC_TappetData	SMC_TappetData*	When <i>bEnable</i> shifts to True.

*Note:

SMC_TappetData (STRUCT): the internal interface between MC_CamIn and SMC_GetTappetValue for tappet data transmission.

Name	Function	Data type	Setting range (Default value)
ctt	Specify the direction in which a tappet point is passed so that there will be an action then.	SMC_CAMTAPPETTYPE	 0: TAPPET_pos (pass in the positive direction) 1: TAPPET_all (pass in both positive and negative directions) 2: TAPPET_neg (pass in the negative direction)
cta	Specify the action when the tappet point is passed.	SMC_CAMTAPPETACTIO N	0: TAPPETACTION_on (switch to ON) 1: TAPPETACTION_off (switch to OFF) 2: TAPPETACTION_inv (Invert) 3: TAPPETACTION_tim e (be ON for a period of time and then switch to OFF.) (TAPPETACTION_on)
dwDelay	Specify the delay time before the tappet changes to ON under TAPPETACTION_tim e mode.	DWORD	Positive number or 0 (0)
dwDuratio n	For how long the tappet is ON under TAPPETACTION_tim e mode.	DWORD	Positive number or 0 (0)
iGroupID	Specify the track ID of	INT	Positive number,

Name	Function	Data type	Setting range (Default value)
	the tappet.		negative number or 0 (0)
x	Tappet position	LREAL	Positive number, negative number or 0 (0)
dwActive	The internal variable	DWORD	Positive number or 0 (0)

Function

- The instruction allows users to watch the states of eight tappets. The tappet number range for iTrackID1~8 is 0~512. If the setting is outside the range, the instruction will report an error, which indicates that the output status is disabled.
- After bEnable changes to False, the instruction will not update the states of tappets anymore and then outputs will maintain current tappet states.

• Troubleshooting

■ When an error occurs during the instruction execution, *bError* will change to True and the axes will stop running. Refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

- The example explains the action principle for CamReadTappetStatus.
- Input 1 for *iTrackID1*, 2 for *iTrackID2*, 50 for *iTrackID3*, 4 for *iTrackID4*, 3 for *iTrackID7*. No tappet numbers for *iTrackID4*, *iTrackID6* and *iTrackID8* are given and thus there will be no actions on these tappets.





Tappets Setting

	Track ID	х	positive pass	negative pass
•	1			
Ŵ		0	invert	switch OFF
1		60	switch OFF	switch OFF
•	2			
1		180	invert	none
•	50			
Ŵ		60	switch ON	switch OFF
•	3			
Ŵ		300	invert	none
•	4			
Ŵ		270	switch ON	switch OFF
•				

Timing Diagram

Master Position 180 60 0			\square		
DMC_CamReadTap	petStatus				
bEnable					
bValid					
bBusy					
bStatus1		[
bStatus2			 		
bStatus3					
bStatus4					
bStatus5					
bStatus6					
bStatus7					
bStatus8					

- When bEnable changes to True, DMC_CamReadTappetStatus starts to update the statuses of tappets.
- Take the second output point (*bStatus2*) for example. The corresponding tappet ID is 2 and the action is to invert its status when the position 180 is reached.
- When *bEnable* changes to False, the outputs maintain current statuses of tappets.
- Supported Products
 - AX-308E, AX-364E

2.3.2.9 DMC_CamReadTappetValue

DMC_CamReadTappetValue reads the data of one single tappet.

FB/FC	Instruction	Graphic expression				
FB	DMC_CamReadTappetValue	CamTable MC_CAM_REF BOOL bValid CamTable MC_CAM_REF BOOL bBusy BOOL bBusy bEnable BOOL DOL ENTOR ITrackID INT ARRAY [07] OF DMC_CAMTAPPETACTION NegativeMode ARRAY [07] OF DMC_CAMTAPPETACTION NegativeMode				
	ST expression					
DMC_	CamReadTappetValue_instan	ice (
bEnab	le : =,					
CamTa	able : =,					
Maste	r: =,					
iTrack	D: =,					
bValid	=>,					
bBusy	=>,					
bError	=>,					
ErrorI) =>,					
IrMast	erPos =>,					
Positiv	eMode =>,					
Negati	veMode =>) ;					

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>bEnable</i> changes from False to True.	BOOL	True/False (True)	-
iTrackID	Specify the ID of the Track to be read.	INT	1~512 (0)	When <i>bEnable</i> is True.

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when	BOOL	True/False (False)
Name	Function	Data type	Output range (Default value)
------------------	--	-------------------------	---
	the outputs are valid.		
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*1	DMC_ERROR (DMC_NO_ERROR)
IrMasterPos	The tappet position which is corresponde d to master axis position (Unit: user unit)	LREAL[07]*2	Positive number, negative number or 0 (0) ^{*3}
PositiveMode	Specify the mode for the tappet point when it is passed in the positive direction.	DMC_CAMTAPPETACTION[07]	0: TAPPETACTION_none 1: TAPPETACTION_on 2: TAPPETACTION_off 3: TAPPETACTION_inv 4: TAPPETACTION_time (TAPPETACTION_none)
NegativeMod e	Specify the mode for the tappet point when it is passed in the negative direction.	DMC_CAMTAPPETACTION[07]	0: TAPPETACTION_none 1: TAPPETACTION_on 2: TAPPETACTION_off 3: TAPPETACTION_inv 4: TAPPETACTION_time (TAPPETACTION_none)

*Note:

1. DMC_ERROR: Enumeration (ENUM)

- 2. One Track can have multiple tappet points set inside it. 8 tappet points at most can be read from the same Track via this instruction by default.
- 3. There is no tappet data to be output when *IrMasterPos* is set to 0 and *PositiveMode* and *NegativeMode* are both set to TAPPETACTION_none.

Name	Timing for shifting to True	Timing for shifting to False
bValid	• When <i>bEnable</i> shifts to True.	 When <i>bError</i> shifts to True. When <i>bEnable</i> shifts to False.
bBusy	• When bEnable shifts to True.	• When <i>bError</i> shifts to True.
bError	• When an error occurs in the	When bEnable shifts to False
ErrorID	values for the instruction.	

Output Update Timing

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	The specified cam table	MC_CAM_REF ^{*1}	MC_CAM_REF	When <i>bEnable</i>
Master	The reference master axis	AXIS_REF_SM3*2	AXIS_REF_SM3	shifts to True.

*Note:

- 1. MC_CAM_REF (FB): The basic CAM
- 2. AXIS_REF_SM3 (FB): Generally, all motion function blocks have the InOut AXIS_REF_SM3.
- Function
 - A tappet table can be set in the Cam table. Multiple tappet points can be set for one Track. 8 tappet points at most can be read from the same tappet track via the function block.

- The tappet data contains the master axis position corresponding to the tappet point, the positive passing mode and the negative passing mode. The modes include TAPPETACTION_none, TAPPETACTION_on, TAPPETACTION_off, TAPPETACTION_inv and TAPPETACTION_time
- See the meanings of the modes in the following table.

Mode	Function	Action
TAPPETACTION_none	No action	The tappet does not take an action when the master axis passes the point.
TAPPETACTION_on	ON	The tappet is enabled when the master axis passes the point.
TAPPETACTION_off	OFF	The tappet is disabled when the master axis passes the point.
TAPPETACTION_inv	Invert	The tappet status is inverted when the master axis passes the point.
TAPPETACTION_time	ON	When the master axis passes the point, the tappet is ON for a set period of time and then turns OFF.

Т

• Troubleshooting

When an error occurs during the instruction execution, *bError* will change to True. Refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

- The example explains the action principle for DMC_CamReadTappetValue and how to read the tappet data of Track ID 2.
- The example explains the action principle for DMC_CamReadTappetValue by reading the tappet data of Track ID 2.



Setting tappet points

	Track ID	х	positive pass	negative pass
•	1			
1		60	switch OFF	switch OFF
•	2			
1		50	switch ON	switch OFF
1		180	none	invert
•	50			
1		60	switch ON	switch OFF
•				

VasterPos	ARRAY [07] OF LREAL	
▲ IrMasterPos[0]	LREAL	50
IrMasterPos[1]	LREAL	180
V IrMasterPos[2]	LREAL	0
IrMasterPos[3]	LREAL	0
IrMasterPos[4]	LREAL	0
IrMasterPos[5]	LREAL	0
IrMasterPos[6]	LREAL	0
IrMasterPos[7]	LREAL	0
♥ PositiveMode	ARRAY [07] OF DMC_CAMTAPPETACTION	
♥ PositiveMode[0]	DMC_CAMTAPPETACTION	TAPPETACTION_on
PositiveMode[1]	DMC_CAMTAPPETACTION	TAPPETACTION_none
PositiveMode[2]	DMC_CAMTAPPETACTION	TAPPETACTION_none
PositiveMode[3]	DMC_CAMTAPPETACTION	TAPPETACTION_none
PositiveMode[4]	DMC_CAMTAPPETACTION	TAPPETACTION_none
PositiveMode[5]	DMC_CAMTAPPETACTION	TAPPETACTION_none
PositiveMode[6]	DMC_CAMTAPPETACTION	TAPPETACTION_none
PositiveMode[7]	DMC_CAMTAPPETACTION	TAPPETACTION_none
NegativeMode	ARRAY [07] OF DMC_CAMTAPPETACTION	
NegativeMode[0]	DMC_CAMTAPPETACTION	TAPPETACTION_off
NegativeMode[1]	DMC_CAMTAPPETACTION	TAPPETACTION_inv
NegativeMode[2]	DMC_CAMTAPPETACTION	TAPPETACTION_none
NegativeMode[3]	DMC_CAMTAPPETACTION	TAPPETACTION_none
NegativeMode[4]	DMC_CAMTAPPETACTION	TAPPETACTION_none
NegativeMode[5]	DMC_CAMTAPPETACTION	TAPPETACTION_none
NegativeMode[6]	DMC_CAMTAPPETACTION	TAPPETACTION_none
NegativeMode[7]	DMC_CAMTAPPETACTION	TAPPETACTION_none

The tappet of Track ID 2 has two switch points: 50 and 180. Array 1 stores the data of switch position 50 and array 2 stores the data of switch position 180. The position -1 indicates no tappet switch data.

Track ID	MasterPosition	Positive Pass	Negative Pass
2	50	TAPPETACTION_on	TAPPETACTION_off
2	180	TAPPETACTION_none	TAPPETACTION_inv

• Supported Products

AX-308E, AX-364E

2.3.2.10 DMC_CamWriteTappetValue

DMC_CamWriteTappetValue modifies the tappet data for the specified existing track.

FB/FC	Instruction	Graphic expression			
FB	DMC_ CamWriteTappetValue	CamTable MC_CAM_REF DRC_CamWriteTappetValue BOOL bDone BOOL BDO			
		ST expression			
DMC_	CamWriteTappetValue_	instance (
Camia	able : =,				
DExec	ute : =,				
IIrack	D: =, prDepition : =				
Desitiv	erPosition . –,				
rositivelvioue,					
hogenvervourse : -,					
bBusy =>					
bError	bError =>				
ErrorI	ErrorID =>) ;				

Inputs

Name	Functio n	Data type	Setting value (Default value)	Timing for updating
bExecute	The instructio n is executed when bExecut e changes from False to True.	BOOL	True/False (True)	-

Name	Functio n	Data type	Setting value (Default value)	Timing for updating
iTrackID	Specify the Track ID where the tappet data is to be modified.	INT	1~512 (0)	When <i>bExecut</i> <i>e</i> shifts from False to True.
IrMasterPos	The master axis position of the tappet point (Unit: user unit)	LREAL[07] ^{*1}	Positive number, negative number or 0 (-1)	When <i>bExecut</i> <i>e</i> shifts from False to True.
PositiveMod e	Specify the mode for the tappet point when it is passed in the positive direction.	DMC_CAMTAPPETACTION[0 7]*	0: TAPPETACTION_non e 1: TAPPETACTION_on 2: TAPPETACTION_off 3: TAPPETACTION_inv 4: TAPPETACTION_tim e (TAPPETACTION_no ne)	When bExecut e shifts from False to True.
NegativeMo de	Specify the mode for the tappet point when it is passed in the negative direction.	DMC_CAMTAPPETACTION[0 7] [*]	0: TAPPETACTION_non e 1: TAPPETACTION_on 2: TAPPETACTION_off 3: TAPPETACTION_inv 4: TAPPETACTION_tim e (TAPPETACTION_no ne)	When bExecut e shifts from False to True.

*Note:

One tappet track can be set with multiple tappet points. Maximum 8 tappet points can be written

for one tappet track via the function block.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	When the output is valid.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the instruction is completed. 	 When <i>bError</i> shifts to True. When <i>bExecute</i> shifts to False.
bBusy	• When <i>bExecute</i> shifts to True.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError	 When an error occurs in the execution conditions or input values for the instruction. 	• When <i>bExecute</i> shifts from True to False.

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	The specified cam table	MC_CAM_REF [*]	MC_CAM_REF	When <i>bExecute</i> is True.

*Note: MC_CAM_REF (FB): The basic CAM

• Function

- The tappet table can be set in the cam table. Tappets can be used to track the current position of the master axis and output a signal to trigger an event under particular conditions.
- One tappet table has multiple tappet tracks.
- This function block can delete all original tappet points in the specified tappet track and replace them with maximum 8 tappet points which are described in the inputs of the function block.
- The Tappet Track
 - One tappet track contains one track ID, one tappet switch (Boolean signal) and multiple tappet points.
- The Tappet
 - One tappet point includes the Track ID of the tappet track where the tappet point is, the master axis position corresponding to the tappet point, the positive passing mode and the negative passing mode.

See the modes and their meanings in the following table.	

Mode	Function	Action
TAPPETACTION_none	No action	The tappet switch does not take an action when the master axis passes the point.
TAPPETACTION_on	ON	The tappet switch is enabled when the master axis passes the point.
TAPPETACTION_off	OFF	The tappet switch is disabled when the master axis passes the point.
TAPPETACTION_inv	Invert	The tappet switch status is inverted when the master axis passes the point.
TAPPETACTION_time	ON	When the master axis passes the point, the tappet switch is ON for a set period of time and then turns OFF.

*Note:

When the mode is set to TAPPETACTION_time in this function block, the tappet switch will turn off after being ON for a fixed 100 ms.

Troubleshooting

When an error occurs during the instruction execution or the axis is in Errorstop

state, *bError* will change to True. Refer to *ErrorID* (Error Code) to address the problem.

- Programming Example
 - The example explains the action principle for DMC_CamWriteTappetValue by writing the tappet data of Track ID 1.
 - Initial setting for tappet points

	Track ID	x	positive pass	negative pass
•	1			
1		100	switch ON	switch OFF
1		500	switch OFF	switch OFF
1		1000	switch ON	switch OFF
•	7			
1		7000	invert	none
•	2			
1		0	switch ON	switch OFF
•				

Function block setting

DMC_CamWriteTappetValue_0					
TRUE	TRUE DMC CamWriteTappetValue				
	EN	ENO			
CamREF —	CamTable	bDone	-		
	bExecute	bBusy	-		
uiTrackID —	iTrackID	bError	-		
lrMasterPos —	lrMasterPos	dwErrorID	-		
РМ —	PositiveMode				
NM	NegativeMode				
]		

■ Input 1 for uiTrackID. Refer to the figure below for the setup of IrMasterPos, PositiveMode and NegativeMode.

\$	IrMasterPos	ARRAY [0 (GVL.MAX_FB_SWITCH_NUM - 1)] OF LREAL	
	IrMasterPos[0]	LREAL	1250
	IrMasterPos[1]	LREAL	7050
	IrMasterPos[2]	LREAL	3050
	IrMasterPos[3]	LREAL	0
	IrMasterPos[4]	LREAL	0
	IrMasterPos[5]	LREAL	0
	IrMasterPos[6]	LREAL	0
	IrMasterPos[7]	LREAL	0
\$	PM	ARRAY [0 (GVL.MAX_FB_SWITCH_NUM - 1)] OF DMC_CAMTAPPE	
	PM[0]	DMC_CAMTAPPETACTION	TAPPETACTION_on
	PM[1]	DMC_CAMTAPPETACTION	TAPPETACTION_off
	PM[2]	DMC_CAMTAPPETACTION	TAPPETACTION_inv
	PM[3]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[4]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[5]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[6]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[7]	DMC_CAMTAPPETACTION	TAPPETACTION_none
1	NM	ARRAY [0 (GVL.MAX_FB_SWITCH_NUM - 1)] OF DMC_CAMTAPPE	
	M[0]	DMC_CAMTAPPETACTION	TAPPETACTION_off
	NM[1]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[2]	DMC_CAMTAPPETACTION	TAPPETACTION_inv
	NM[3]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[4]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[5]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[6]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[7]	DMC_CAMTAPPETACTION	TAPPETACTION_none

The tappet table before the function block is executed

Track ID	Master axis position	Direction	Passing mode
1	100	Negative	TAPPETACTION_off
1	100	Positive	TAPPETACTION_on
1	500	Negative	TAPPETACTION_off
1	500	Positive	TAPPETACTION_off
1	1000	Negative	TAPPETACTION_off
1	1000	Positive	TAPPETACTION_on
7	7000	Positive	TAPPETACTION_inv
2	0	Negative	TAPPETACTION_off
2	0	Positive	TAPPETACTION_on

■ The tappet table after the function block is executed

Track ID	Master axis position	Direction	Passing mode
1	1250	Negative	TAPPETACTION_off
1	1250	Positive	TAPPETACTION_on
1	7050	Positive	TAPPETACTION_off
1	3050	Negative	TAPPETACTION_inv
1	3050	Positive	TAPPETACTION_inv
7	7000	Positive	TAPPETACTION_inv
2	0	Negative	TAPPETACTION_off
2	0	Positive	TAPPETACTION_on

• Supported Products

AX308E, AX-364E

2.3.2.11 DMC_CamAddTappet

DMC_CamAddTappet adds a new tappet track at the end of the tappet table.

FB/FC	Instruction	Graphic expression				
FB	DMC_CamAddTappet	-Сантаніе МС. САН, ВЯТ -Docada SOX. -Docada SOX. -Matshee ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF LRBAL. -Postovehode ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF DMC, CANTARFERCTION -Negdovehode ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF DMC, CANTARFERCTION -Negdovehode ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF DMC, CANTARFERCTION -Negdovehode ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF DMC, CANTARFERCTION -Negdovehode ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF DMC, CANTARFERCTION -Negdovehode ARRY (S. (OX. MAX, FR. SHITOY, M.M I) OF DMC, CANTARFERCTION				
		ST expression				
DMC_ CamTa bExect IrMasta Positiv Negati bDone bBusy bError	DMC_CamAddTappet_instance (CamTable : =, bExecute : =, IrMasterPosition : =, PositiveMode : =, NegativeMode : =, bDone =>, bBusy =>, bError =>,					
iTrackl	iTrackID =>) ;					

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (True)	-
IrMasterPos	The master axis position of the tappet	LREAL[07]*	Positive number, negative number or 0 (- 1)	When <i>bExecute</i> shifts from False to True.

Name	Function	Data type	Setting value (Default value)	Timing for updating
	point (Unit: user unit)			
PositiveMode	Specify the mode for the tappet point when it is passed in the positive direction.	DMC_CAM TAPPETACTION [07] [*]	0: TAPPETACTION_none 1: TAPPETACTION_on 2: TAPPETACTION_off 3: TAPPETACTION_inv 4: TAPPETACTION_time (TAPPETACTION_none)	When <i>bExecute</i> shifts from False to True.
NegativeMode	Specify the mode for the tappet point when it is passed in the negative direction.	DMC_CAM TAPPETACTION [07] [*]	0: TAPPETACTION_none 1: TAPPETACTION_on 2: TAPPETACTION_off 3: TAPPETACTION_inv 4: TAPPETACTION_time (TAPPETACTION_none)	When <i>bExecute</i> shifts from False to True.

*Note:

One tappet track can be set with multiple tappet points. Maximum 8 tappet points can be written for one tappet track via the function block.

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)
iTrackID	The Track ID of the new tappet track	INT	1~512

*Note: DMC_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the instruction is completed. 	 When <i>bError</i> is True. When <i>bExecute</i> shifts to False.
bBusy	• When <i>bExecute</i> is True.	 When <i>bDone</i> is True. When <i>bError</i> is True.
bError	• When an error occurs in the execution conditions or input values for the instruction.	• When <i>bExecute</i> shifts from True to False

Output Update Timing

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	The specified cam table	MC_CAM_REF	MC_CAM_REF	When <i>bExecute</i> changes to True.

*Note:

MC_CAM_REF (FB): The basic CAM.

• Function

- The tappet table can be set in the cam table. Tappets can be used to track the current position of the master axis and output a signal to trigger an event under particular conditions.
- One tappet table has multiple tappet tracks.
- This function block adds a tappet track and outputs its track ID to its output uiTappetNum. The track ID is the smallest one which has not been used yet.
- The tappet track
 - One tappet track contains one track ID, one tappet switch (Boolean signal) and multiple tappet points.
- The tappet

One tappet point includes the Track ID of the tappet track where the tappet point is, the master axis position corresponding to the tappet point, the positive passing mode and the negative passing mode.

See the modes and their meanings in the following table.

Mode	Function	Action
TAPPETACTION_none	No action	The tappet switch does not take an action when the master axis passes the point.
TAPPETACTION_on	ON	The tappet switch is enabled when the master axis passes the point.
TAPPETACTION_off	OFF	The tappet switch is disabled when the master axis passes the point.
TAPPETACTION_inv	Invert	The tappet switch status is inverted when the master axis passes the point.
TAPPETACTION_time	ON	When the master axis passes the point, the tappet switch is ON for a set period of time and then turns OFF.

*Note:

When the mode is set to TAPPETACTION_time in this function block, the tappet switch will turn off after being ON for a fixed 100 ms.

• Troubleshooting

When an error occurs during the instruction execution or the axis is in Errorstop state, *bError* will change to True and the axis stops running. Refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

- The example explains the action principle for DMC_CamAddTappetValue by adding a new track of tappet points.
- Initial setting for tappet points

	Track ID	Х	positive pass	negative pass
•	1			
1		100	switch ON	switch OFF
1		500	switch OFF	switch OFF
1		1000	switch ON	switch OFF
•	7			
1		7000	invert	none
•	2			
1		0	switch ON	switch OFF
•				

Function block setting



Ξ 🚸	IrMasterPos	ARRAY [0 (GVL.MAX_FB_SWITCH_NUM - 1)] OF LREAL	
	IrMasterPos[0]	LREAL	1250
	IrMasterPos[1]	LREAL	7050
	IrMasterPos[2]	LREAL	3050
	IrMasterPos[3]	LREAL	0
	IrMasterPos[4]	LREAL	0
	IrMasterPos[5]	LREAL	0
	IrMasterPos[6]	LREAL	0
	IrMasterPos[7]	LREAL	0
8 🔷	PM	ARRAY [0 (GVL.MAX_FB_SWITCH_NUM - 1)] OF DMC_CAMTAPPE	
	PM[0]	DMC_CAMTAPPETACTION	TAPPETACTION_on
	PM[1]	DMC_CAMTAPPETACTION	TAPPETACTION_off
	PM[2]	DMC_CAMTAPPETACTION	TAPPETACTION_inv
	PM[3]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[4]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[5]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[6]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	PM[7]	DMC_CAMTAPPETACTION	TAPPETACTION_none
Ξ 🚸	NM	ARRAY [0(GVL.MAX_FB_SWITCH_NUM - 1)] OF DMC_CAMTAPPE	
	M[0]	DMC_CAMTAPPETACTION	TAPPETACTION_off
	NM[1]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[2]	DMC_CAMTAPPETACTION	TAPPETACTION_inv
	NM[3]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	NM[4]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	NM[5]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	MM[6]	DMC_CAMTAPPETACTION	TAPPETACTION_none
	NM[7]	DMC_CAMTAPPETACTION	TAPPETACTION_none

See the tappet table before the function block is executed

Track ID	Master axis position	Direction	Mode
1	100	Negative	TAPPETACTION_off
1	100	Positive	TAPPETACTION_on
1	500	Negative	TAPPETACTION_off
1	500	Positive	TAPPETACTION_off
1	1000	Negative	TAPPETACTION_off
1	1000	Positive	TAPPETACTION_on
7	7000	Positive	TAPPETACTION_inv
2	0	Negative	TAPPETACTION_off
2	0	Positive	TAPPETACTION_on

Track ID	Master axis position	Direction	Mode
1	100	Negative	TAPPETACTION_off
1	100	Positive	TAPPETACTION_on
1	500	Negative	TAPPETACTION_off
1	500	Positive	TAPPETACTION_off
1	1000	Negative	TAPPETACTION_off
1	1000	Positive	TAPPETACTION_on
7	7000	Positive	TAPPETACTION_inv
2	0	Negative	TAPPETACTION_off
2	0	Positive	TAPPETACTION_on
3	1250	Negative	TAPPETACTION_off
3	1250	Positive	TAPPETACTION_on
3	7050	Positive	TAPPETACTION_off
3	3050	Negative	TAPPETACTION_inv
3	3050	Positive	TAPPETACTION_inv

See the tappet table after the function block is executed

• Supported Products

AX308E, AX-364E

2.3.2.12.DMC_CamDeleteTappet

DMC_CamDeleteTappet deletes the specified tappet track.

FB/FC	Instruction	Graphic expression			
FB	DMC_CamDeleteTappet	DMC_CamDeleteTappet CamTable MC_CAM_REF BOOL bDone bExecute BOOL iTrackID INT BOOL bError DMC_ERROR dwErrorID			
		ST expression			
DMC_ CamTa bExec	DMC_CamDeleteTappet_instance(CamTable : =, bExecute : =.				
iTrackl	ITrackID : =,				
bBusy bError	bBusy =>, bError =>,				
dwErro	orID =>) ;				

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (True)	-
iTrackID	Specify the ID of the track to be deleted.	INT	1~512 (0)	When <i>bExecute</i> is True.

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note:

DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the instruction is completed. 	 When <i>bError</i> is True. When <i>bExecute</i> shifts to False.
bBusy	• When <i>bExecute</i> is True.	 When <i>bDone</i> is True. When <i>bError</i> is True.
bError	When an error occurs in the execution conditions or input	When <i>bExecute</i> shifts from True to False
ErrorID	values for the instruction.	

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	The specified cam table	MC_CAM_REF	MC_CAM_REF [*]	When <i>bExecute</i> changes to True.

*Note:

MC_CAM_REF (FB): The basic CAM.

Function

- The tappet table can be set in the cam table. Tappets can be used to track the current position of the master axis and output a signal to trigger an event under particular conditions.
- One tappet table has multiple tappet tracks.
- The function block deletes a specified tappet track from the tappet table.
- The tappet track
 - One tappet track contains one track ID, one tappet switch (Boolean signal) and multiple tappet points.
- The tappet
 - One tappet point includes the Track ID of the tappet track where the tappet point is, the master axis position corresponding to the tappet point, the positive passing mode and the negative passing mode.

See the modes and their meanings in the following table.

Mode	Function	Action
TAPPETACTION_none	No action	The tappet switch does not take an action when the master axis passes the point.
TAPPETACTION_on	ON	The tappet switch is enabled when the master axis passes the point.
TAPPETACTION_off	OFF	The tappet switch is disabled when the master axis passes the point.

Mode	Function	Action
TAPPETACTION_inv	Invert	The tappet switch status is inverted when the master axis passes the point.
TAPPETACTION_time	ON	When the master axis passes the point, the tappet switch is ON for a set period of time and then turns OFF.

*Note:

When the mode is set to TAPPETACTION_time in this function block, the tappet switch will turn off after being ON for a fixed 100 ms.

• Troubleshooting

When an error occurs during the instruction execution or the axis enters Errorstop state, *bError* will change to True and the axis stops running. Refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

The example explains the action principle for DMC_CamDeleteTappet by deleting the specified track data from the tappet table.

	Track ID	Х	positive pass	negative pass
•	1			
Ŵ		100	switch ON	switch OFF
Ŵ		500	switch OFF	switch OFF
1		1000	switch ON	switch OFF
0	7			
1		7000	invert	none
•	2			
1		0	switch ON	switch OFF
0				

Initial tappets setting

Function block setting



Track ID	Master axis position	Direction	Mode
1	100	Negative	TAPPETACTION_off
1	100	Positive	TAPPETACTION_on
1	500	Positive and negative	TAPPETACTION_off
1	1000	Negative	TAPPETACTION_off
1	1000	Positive	TAPPETACTION_on
7	7000	Positive	TAPPETACTION_inv
2	0	Negative	TAPPETACTION_off
2	0	Positive	TAPPETACTION_on

See the tappet table before the function block is executed

See the tappet table after the function block is executed

Track ID	Master axis position	Direction	Mode
1	100	Negative	TAPPETACTION_off
1	100	Positive	TAPPETACTION_on
1	500	Positive and negative	TAPPETACTION_off
1	1000	Negative	TAPPETACTION_off
1	1000	Positive	TAPPETACTION_on
2	0	Negative	TAPPETACTION_off
2	0	Positive	TAPPETACTION_on

• Supported Products

AX308E, AX-364E

2.3.2.13 DMC_CamReadPoint

DMC_CamReadPoint reads the data of one single cam point.

FB/FC	Instruction	Graphic expression	
FB	DMC_CamReadPoint	DMC_CamReadPoint CamTable MC_CAM_REF BOOL bDone bExecute BOOL iCamPointNum INT BOOL bError DMC_ERROR ErrorID LREAL IrSlavePos LREAL IrSlaveVel LREAL IrSlaveVel LREAL IrSlaveAcc	
ST expression			

FB/FC	Instruction	Graphic expression
DMC_	CamReadPoint_instance(
CamTa	able : =parameter,	
bExec	ute: =parameter,	
iCamF	ointNum: =parameter,	
bDone	e =>parameter,	
bBusy	=>parameter,	
bError	=>parameter,	
Errorl	D =>parameter,	
IrMast	erPos =>parameter,	
IrSlave	Pos =>parameter,	
IrSlave	eVel =>parameter,	
IrSlave	eAcc =>parameter) ;	

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (True)	-
iCamPointNum	Specify the number of the cam point to be read.	INT	0~256 (0)	When <i>bExecute</i> is True.

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR [*]	DMC_ERROR (DMC_NO_ERR)
IrMasterPos	The position of the cam master axis	LREAL	Positive number, negative number or 0 (0)

Name	Function	Data type	Output range (Default value)
IrSlavePos	The position of the cam slave axis	LREAL	Positive number, negative number or 0 (0)
IrSlaveVel	The velocity of the cam slave axis	LREAL	Positive number, negative number or 0 (0)
IrSlaveAcc	The acceleration of the cam slave axis	LREAL	Positive number, negative number or 0 (0)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	• When <i>bExecute</i> changes to True.	When bError shifts to True.When bExecute shifts to False.
bBusy	• When bExecute changes to True.	• When bError shifts to True.
bError	• When an error occurs in the execution conditions or input values for the instruction.	• When bExecute shifts to False.

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	The specified cam table	MC_CAM_REF	MC_CAM_REF [*]	When <i>bExecute</i> changes to True.

*Note: MC_CAM_REF (FB): The basic CAM.

• Function

- CamTable determines which cam table is to read. *iCamPointNum* determines the number of the cam point to read. *IrMasterPos* shows the master position that the cam point corresponds to. *IrSlavePos* shows the slave position that the cam point corresponds to, i.e. coordinates of the cam point. *IrSlaveVel* is the slave velocity that the cam point corresponds to. *IrSlaveAcc* is the slave acceleration rate that the cam point corresponds to.
- If no data of the specified cam point exists, the output will show Infinity.

• Programming Example



1. Build a cam table: "Cam".

- - 2. Input Cam for the specified *CamTable* and 2 for *CamPointNum*, the number of the cam point to be read.
 - 3. Set DMC_CamReadPoint_0.bExecute to True.
 - 4. DMC_CamReadPoint_0.IrMasterPos: 240, DMC_CamReadPoint_0.IrSlavePos: 240, DMC_CamReadPoint_0.IrSlaveVel: 1 and DMC_CamReadPoint_0.IrSlaveAcc: 0 can be read while the instruction is waiting until DMC_CamReadPoint_0.bDone changes from False to True.

TRUE	DMC CamReadPoint					
	EN	ENO				
Cam —	CamTable	bDone -				
	bExecute	bBusy				
CamPointNum —	iCamPointNum	bError				
		ErrorID				
		lrMasterPos -				
		lrSlavePos -				
		lrSlaveVel				
		1rSlaveAcc -				

• Supported Products

AX308E, AX-364E

2.3.2.14 DMC_CamWritePoint

DMC_CamWritePoint writes the data of one single cam point.

FB/FC	Instruction	Graphic expression
FB	DMC_CamWritePoint	DMC_CamWritePoint CamTable MC_CAM_REF BOOL bDone bExecute BOOL BOOL bBusy iCamPointNum INT BOOL bError IrMasterPos LREAL DMC_ERROR ErrorID IrSlavePos LREAL IrSlaveAcc LREAL
		ST expression
DMC_ CamTa bExect bCam0 IrMasto IrSlave IrSlave bDone bBusy bError ErrorIE	CamWritePoint_instance (able : =, ute: =, ChangedPoint: =, erPos : =, ePos : =, eVel : =, eAcc : =, e =>, =>, =>, D =>) ;	

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (True)	-
iCamPointNum	Specify the number of the cam point to be written.	INT	0~256 (0)	When <i>bExecute</i> is True.
IrMasterPos	Specify the position of the cam master axis	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> is True.
IrSlavePos	Specify the position of the cam slave axis	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> is True.
lrSlaveVel	Specify the velocity of the cam slave axis	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> is True.
IrSlaveAcc	Specify the acceleration of the cam slave axis	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> is True.

Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERR)

*Note: DMC_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When <i>bExecute</i> changes to True. 	 When <i>bError</i> shifts to True. When <i>bExecute</i> shifts to False.
bBusy	 When <i>bExecute</i> changes to True. 	• When <i>bError</i> shifts to True.
bError	 When an error occurs in the execution conditions or input values for the instruction. 	• When <i>bExecute</i> shifts to False.

Output Update Timing

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	The specified cam table	MC_CAM_REF	MC_CAM_REF*	When <i>bExecute</i> changes to True.

*Note: MC_CAM_REF (FB): The basic CAM.

• Function

- The CamTable determines which cam table to write data to and iCamPointNum determines the cam point number to be written. IrMasterPos and IrSlavePos write respectively the master axis position and slave axis position of the cam data point (i.e. cam point coordinate positions). IrSlaveVel writes the slave axis velocity corresponding to the cam data point and IrSlaveAcc writes the slave axis acceleration corresponding to the cam data point.
- The data point information accessed in the cam table corresponds to different data according to different cam data types. When DMC_CamWritePoint writes data, the cam operation will not be affected even if parameters are input to the inputs of the instruction if no specific data (e.g. *IrSlaveVel* and *IrSlaveAcc*) is accessed in the cam table.
- When DMC_CamWritePoint modifies the cam table data in the synchronized cam motion, the slave axis in synchronization will change its path immediately, which may

cause a jolt of the mechanism.

When the starting or ending cam data points are modified and the master axis position written by *IrMasterPos* exceeds the range of the original cam table, the running cam will have no change. And the cam table with the modified boundary range cannot work until the MC_Camtableselect is restarted.

• Troubleshooting

When an error occurs during the instruction execution or the axis enters Errorstop state, *bError* will change to True and the axis stops running. Refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

	Х	Y	٧	Α	J	Segm	min(P	max(P	max(V	max(A
	0	0	0	0	0					
•						Poly5	0	120	1.5120	0.0328
Ŵ	120	120	1	0	0					
•						Poly5	120	240	1	0
1	240	240	1	0	0					
0						Poly5	240	360	1.512	0.0328
	360	360	0	0	0					

1. Build a cam table: "Cam".



- 2. Input Cam for the specified *CamTable* and 2 for *CamPointNum*, the number of the cam point to be written.
- 3. Input 300 for *MasterPos*, 250 for *SlavePos*, 2 for *SlaveVel*, 4 for *SlaveAcc* in the selected cam point data.
- 4. Set DMC_CamWritePoint_0.bExecute to True.
- 5. The data writing is completed when DMC_CamWritePoint_0.bDone changes from False to True.

	DMC CamWritePoint		
	EN	ENO	
Cam -	CamTable	bDone	
	bExecute	bBusy	
CamPointNum -	iCamPointNum	bError	
MasterPos -	lrMasterPos	ErrorID	
SlavePos -	lrSlavePos		
SlaveVel -	lrSlaveVel		
SlaveAcc -	lrSlaveAcc		

6. After the writing is finished, the actual values for the cam table "Cam" are shown as below.

	Х	Y	V	А
0	0	0	0	0
1	120	120	1	0
2	300	250	2	4
3	360	360	0	0

• Supported Products

AX308E, AX-364E

2.3.2.15 DMC_ChangeMechanismGearRation

DMC_ChangeMechanismGearRation modifies the ratio between user units and pulses, axis type and user units per rotation of the rotary axis.

FB/FC	Instruction	Graphic expression			
FB	DMC_ChangeMechanismGearRation	DMC_ChangeMechanismGearRation Axis AXIS_REF_SM3 BOOL bDone bExecute BOOL BBOUL bBusy udiInputRotation UDINT BOOL bError udiPulsePerRotation UDINT SM3_ERROR.SMC_ERROR ErrorID udiUnitsPerRotation UDINT Axis Type SM2_ERROR_SMC_ERROR ErrorID udiUnitsPerRotation UDINT Axis Type MC_MOVEMENTTYPE IrModulo LREAL			
	ST expression				

FB/FC	Instruction	Graphic expression					
DMC_	ReadMotionState_instance(
Axis : :	=,						
bExec	ute: =,						
udilnp	utRotation: =,						
udiOut	putRotation: =,						
udiPul	sePerRotation: =,						
udiUni	tsPerRotation: =,						
AxisTy	pe: =,						
IrModu	ılo: =,						
bDone	bDone=>,						
bBusy	bBusy=>,						
bError	bError=>,						
ErrorI)=>,) ;						

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
udiInputRotation	Specify the input of the gearbox.	UDINT	Positive number (0)	When bExecute is True and bBusy is False.
udiOutputRotation	Specify the output of the gearbox.	UDINT	Positive number (0)	When bExecute is True and bBusy is False.
udiPulsePerRotation	Specify how many pulses per rotation of the input end of the gearbox. (Unit: pulses/ rotation)	UDINT	Positive number (0)	When bExecute is True and bBusy is False.
udiUnitsPerRotation	Specify how many units the terminal	UDINT	Positive number (0)	When <i>bExecute</i> is True

Chapter 2

Name	Function	Data type	Setting value (Default value)	Timing for updating
	actuator travels per rotation of the output end of the gearbox			and <i>bBusy</i> is False.
AxisType	Specify the axis type.	SMC_MOVEMENTTYPE*	0: rotary 1: linear (rotary)	When bExecute is True and bBusy is False.
IrModulo	Specify how many units per rotation of the rotary axis.	LREAL	Positive number (0)	When bExecute is True and bBusy is False.

*Note: SMC_MOVEMENTTYPE: Enumeration (ENUM)

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the instruction is completed. 	 When <i>bExecute</i> shifts to False. When <i>bError</i> shifts to True.
bBusy	• When <i>bExecute</i> shifts to	• When <i>bExecute</i> shifts to False.

Name	Timing for shifting to True		Timing for shifting to False
	True.	•	When <i>bError</i> shifts to True.
bError	When an error occurs in the execution conditions or		
ErrorID	input values for the instruction. (Error code is recorded).	•	When <i>bExecute</i> shifts from True to False. (Error code is cleared)

Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bExecute</i> is True and <i>bBusy</i> is False.

*Note: AXIS_REF_SM3 (FB): All function blocks contain this variable, which works as the starting program for function blocks.

Function



DMC_ChangeMechanismGearRation modifies the ratio between user units and

pulses, axis type and user units per rotation of the rotary axis.

The corresponding relationship between the function block inputs and the mechanism is shown in the figure above. udiPulsePerRotation is the number of pulses required per rotation of the input end of the gearbox, udiInputRotation is the input of the gearbox, udiOutputRotation is the output of the gearbox and udiUnitsPerRotation is the number of terminal actuator travel units per rotation of the output end of the gearbox.

Troubleshooting

- The instruction can be executed only when the state machine is power_off. Refer to *ErrorID* (Error Code) to address the problem if an error occurs during the instruction execution.
- Programming Example
 - The example shows the behavior of DMC_ChangeMechanismGearRation.
 - Relevant parameters setting: udiOutputRotation: udiInputRotation= 2: 1 udiPulsePerRotation: 10000 pulses udiUnitsPerRotation: 20000 us AxisType: 0 (rotary axis) IrModulo: 360
 - Function block setting



- Supported Products
 - AX-308E, AX-364E

Chapter 2

2.3.2.16 DMC_ReadMotionState

DMC_ReadMotionState reads the behavior state of the axis in motion.

FB/FC	Instruction	Graphic expression			
FB	DMC_ReadMotionState	DMC_ReadMotionState Axis AXIS_REF_SM3 bEnable BOOL Source DMC_SOURCE SM3_ERROR.SMC_ERROR ErrorId BOOL bConstantVelodty BOOL bDecelerating BOOL bDecelerating BOOL bDirectionNegative BOOL bDirectionNe			
		ST expression			
DMC_	ReadMotionState_instanc	e (
Axis :	=,				
bEnab	ie : =,				
bValid	=, =>				
bBusv	=>.				
bError	=>,				
bCons	tantVelocity=>,				
bAccle	erating =>,				
bDece	bDecelerating =>,				
bDirec	bDirectionPositive =>,				
bDirec	bDirectionNegative =>,) ;				

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is enabled when <i>Enable</i> changes from FALSE to TRUE.	BOOL	True/False (False)	-
Source	Select the data source. Commanded: instruction- commanded value. Actual: actual value of the axis.	DMC_ SOURCE*	0: dmcCommandedValue (0)	When <i>bEnable</i> shifts to True and <i>bBusy</i> is False.

*Note: MC_SOURCE: Enumeration (ENUM)

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when the axis stops and the velocity reaches 0.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Record the error code when an error occurs. Refer to Appendices for error code descriptions.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)
bConstantVelocity	Shows that the current velocity is constant.	BOOL	True/False (False)
bAccelerating	Shows that the absolute value of the current velocity is increasing.	BOOL	True/False (False)
bDecelerating	Shows that the absolute value of the current velocity is decreasing.	BOOL	True/False (False)
bDirectionPositive	Shows that the current position is increasing.	BOOL	True/False (False)
bDirectionNegative	Shows that the current position is decreasing.	BOOL	True/False (False)

*Note: DMC_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bValid	• When <i>bEnable</i> is True and the axis motion state can be read.	 When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bBusy	• When <i>bEnable</i> is True.	 When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bError	When an error occurs in the execution conditions or	 When bEnable shifts to False
ErrorID	input values for the instruction. (Error code is recorded).	(The error code in <i>ErrorID</i> is cleared.)
bConstantVelocity	When the current velocity is constant.	• When <i>bEnable</i> is True but the velocity is not constant.
bAccelerating	• When the absolute value of	• When <i>bEnable</i> is True but the

Name	Timing for shifting to True	Timing for shifting to False
	the current velocity is increasing.	velocity does not increase.
bDecelerating	 When the absolute value of the current velocity is decreasing. 	• When <i>bEnable</i> is True but the velocity does not decrease.
bDirectionPositive	 When the current position is increasing. 	 When <i>bEnable</i> is True and the direction of motion is not positive. When <i>bEnable</i> is True and the axis does not move any more.
bDirectionNegative	 When the current position is decreasing. 	 When <i>bEnable</i> is True and the direction of motion is not negative. When <i>bEnable</i> is True and the axis does not move any more.

Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bEnable</i> is True and <i>bBusy</i> is False.

***Note:** AXIS_REF_SM3 (FB): All function blocks contain this variable, which works as the starting program for function blocks.

• Function

- DMC_ReadMotionState reads the behavior state of the axis in motion (i.e. acceleration/deceleration, constant velocity, positive/negative direction of motion).
- When the velocity is 0, the output *bConstantVelocity* changes to True.

• Troubleshooting

When an error occurs during the instruction execution, *bError* will change to True. Refer to *ErrorID* (Error Code) to address the problem.

• Programming Example

The example shows the motion behavior that MC_ReadMotionState reads MC_MoveVelocity and MC_Stop.


Chapter 2

Timing Diagram



- 1. When *bvalid* and *bBusy* change to True after DMC_ReadMotionState is started, it indicates that the motion state can be read.
- 2. The axis starts to accelerate until the target velocity after MC_MoveVelocity is started. When *bAccelerating* and *bDirectionPositive* change to True, it indicates that the axis is accelerating in the positive direction.
- 3. When the axis reaches the specified target velocity, the instruction maintains a

constant velocity, *bAccelerating* changes to False and *bConstantVelocity* changes to True.

- 4. When MC_Stop is started, MC_MoveVelocity is interrupted and the axis starts to decelerate to a stop. Then *bConstantVelocity* changes to False and *bDecelerating* changes to True.
- 5. When the velocity of the axis reaches 0, *bDecelerating* and *bDirectionPositive* change to False and *bConstantVelocity* changes to True.
- 6. When DMC_ReadMotionState is disabled during the deceleration of the axis in the next motion cycle, both *bDecelerating* and *bDirectionPositive* will remain True and will not update any longer no matter how motion instructions work.

• Supported Products

AX-308E, AX-364E

2.3.2.17 DMC_AxesObserve

DMC_AxesObserve monitors the deviation between the master axis position and slave axis position and it will output a reminder when the deviation exceeds the allowed setting value.

FB/FC	Instruction	Graphic expression	on		
FB	DMC_AxesObserve	DMC_AxesObserv Master AXIS_REF_SM3 Slave AXIS_REF_SM3 bEnable BOOL iReferenceType INT bRotarySelectDeviation BOOL IrPermittedDeviation LREAL	e BOOL bEnabled BOOL bInvalid BOOL bBusy LREAL IrDeviatedValue BOOL bError DMC_ERROR ErrorID		
	ST expression				
DMC_/ Master Slave : bEnabl	DMC_AxesObserve_instance(Master :=, Slave :=, bEnable :=,				
bRotar IrPerm	<pre>IReference I ype :=, bRotarySelectDeviation:=, IrPermittedDeviation :=,</pre>				
bEnabled =>, bInvalid=>, bBusy =>					
IrDevia bError ErrorI[IrDeviatedValue=>, bError =>, ErrorID =>);				

• Inputs

Name Function		Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is executed when <i>bEable</i> changes from False to True.	BOOL	True/False (False)	-
iReferenceType	nceType Specify the position type.		0: Command position 1: Actual position (0)	When <i>bEnable</i> is True.
bRotarySelect Deviation	Specify the shorter or longer distance between axes. The parameter is valid only when the master axis and slave axis are both rotary axes.	BOOL	True/False (False)	When <i>bEnable</i> is True.
IrPermitted Deviation Devi		LREAL	Positive number or 0(0)	When <i>bEnable</i> is True.

• Outputs

Name	Function	Data type	Output range (Default value)
bEnabled	True when the instruction outputs are valid.	BOOL	True/False (False)
blnvalid	True when the difference between the two axes exceeds the allowed value.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
IrDeviatedValue	The error value between the two axes	LREAL	Positive number, negative number or 0 (0)
bError	True when an error occurs during instruction execution.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code	DMC_ERROR*	DMC_ERROR (DMC_NO_ERR)

Chapter 2

Name	Function	Data type	Output range (Default value)
	descriptions.		

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
bEnabled	• When <i>bEnable</i> shifts to True.	When bError shifts to True.When bEnable shifts to False.
blnvalid	 When <i>bEnable</i> shifts to True. When the difference between the two axes exceeds the allowed value. 	When bError shifts to True.When bEnable shifts to False.
bBusy	• When <i>bEnable</i> shifts to True.	When bError shifts to True.When bEnable shifts to False.
lrDeviatedValue	• When <i>bEnable</i> shifts to True.	 When bEnable shifts to False, the data update stops.
bError	• When an error occurs in the	a Million h Enchla shifta ta Eslas
ErrorID	values for the instruction.	

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Master	Specify the master axis.	AXIS_REF_SM3	AXIS_REF_SM3 [⁺]	When <i>bEnable</i>
Slave	Specify the slave axis.	AXIS_REF_SM3	AXIS_REF_SM3 [*]	shifts to True.

*Note:

AXIS_REF_SM3 (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

DMC_AxesObserve checks if the deviation between the master axis position and slave axis position exceeds the allowed setting value.

When | IrDeviatedValue | is > IrPermittedDeviation, *bInvalid* changes to True.

- It is suggested that the same mode should be set for the master and slave axes. If one is set as a linear axis and the other is set as a rotary axis, the calculation of the error between axes will be done in linear axis mode.
- When both the master axis and slave axis are rotary axes but their distances per rotation are different, the calculation of *IrDeviatedValue* (error between axes) is done in linear axis mode.
- BRotarySelectDeviation is valid only when the distances per rotation for the master axis and slave axis are the same. False means to read the shorter direction and True means to read the longer direction.

Master axis mode	Slave axis mode	Calculation method
Linear axis	Linear axis	
Rotary axis	Linear axis	<i>IrDeviatedValue</i> (Error between axes) = Master axis position – Slave axis position
Linear axis	Rotary axis	
		<i>IrDeviatedValue</i> (Error between axes) = Master axis position – Slave axis position
	Rotary axis	(Master axis position – Slave axis position)
Rotary axis		<i>IrDeviatedValue</i> outputs the value of the longer or shorter distance according to the setting of <i>bRotarySelectDeviation</i> .
		When the current positon of the master axis > the current positon of the slave axis, the sign of <i>IrDeviatedValue</i> (Error between axes) is positive (+).
		When the current positon of the master axis < he current positon of the slave axis, the sign of <i>IrDeviatedValue</i> (Error between axes) is negative (-).

■ Calculation of *IrDeviatedValue*

• Troubleshooting

When an error occurs in the instruction execution, see the error code in *ErrorID* to confirm the current error state.

• Programming Example

The example illustrates the behavior performed by DMC_AxesObserve when both the master and slave axes are rotary axes with the cycle of 360.



Timing Diagram



1. When the master and slave axes operate together, the master axis is faster than

the slave axis in velocity. Therefore, the starting master axis position is greater than the slave axis position, and the value of *IrDeviatedValue* is positive. When the *IrDeviatedValue* value is greater than the setting value of *IrPermittedDeviation* 100, *bInvalid* changes to True.

- 2. When the master axis rotates one circle, the master axis returns to 0 behind the slave axis in position, then the slave axis position is negative.
- 3. When *bRotarySelectDeviation* changes to True, it means that *IrDeviatedValue* selects the longer distance between axes and the value must exceed 180 based on the calculation of *IrDeviatedValue* value mentioned in Function section. Since the *IrPermittedDeviation* is set to 100, *bInvalid* must be True.

• Supported Products

AX-308E, AX-364E

2.3.2.18 DMC_PositionLag

DMC_PositionLag sets the allowed range of lag error and observe whether the allowed position lag is exceeded.

FB/FC	Instruction	Graphic expression			
FB	DMC_PositionLag	DMC_PositionLag Axis AXIS_REF_SM3 BOOL bOutOfRange — bEnable BOOL BOOL bBusy — eStopMode SMC3_CheckPositionLagMode BOOL bError — fMaxPositionLag LREAL DMC_ERROR dwErrorID — fSetActTimeLagCycles LREAL LREAL IrPosLag			
	ST expression				
DMC_I	PositionLag_instance(
Axis:=,					
bEnabl	e :=,				
eStopN	/lode :=,				
fMaxPo	ositionLag :=,				
fSetAc	fSetActTimeLagCycles :=,				
bOutOfRange=>,					
bBusy =>,					
bError =>,					
dwErro	dwErrorID =>,				
IrPosL	IrPosLag =>);				

• Inputs

Name	Functio n	Data type	Setting value (Default value)	Timing for updating
bEnable	The instructio n is executed when <i>bEable</i> changes from False to True.	BOOL	True/False (False)	-
eStopMode	Specify the stop mode for axis motion when the lag error occurs.	SMC3_CheckPositionL ag Mode	0: SMC3_PCL_OFF 1:SMC3_PCL_DISAB LE 2: SMC3_PCL_HALT 3: SMC3_PCL_ENABLE (SMC3_PCL_OFF)	When <i>bEnabl</i> e and <i>bBusy</i> are True.
fMaxPositionLag	Specify the maximu m lag error value.	LREAL	Positive number or 0 (0)	When <i>bEnabl</i> e and <i>bBusy</i> are True.
fSetActTimeLagCycl es	Specify the lag cycle between comman d value and actual value.	LREAL	Positive number or 0 (3)	When <i>bEnabl</i> <i>e</i> and <i>bBusy</i> are True.

• Outputs

Name	Function	Data type	Output range (Default value)
bOutOfRange True when LagTime exceeds the setting value.		BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
dwErrorID	Contains error codes.	DMC_ERROR*	DMC_ERROR (DMC_NO_ERROR)
lrPosLag	Contains current LagError value	LREAL	Positive number or 0 (0)

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name Timing for changing to TRUE		Timing for changing to FALSE	
bOutOfRange	• True when LagTime exceeds the setting value.	• When bEnable shifts to False.	
bBusy	When the instruction is being executed.	When bError shifts to Ture.	
bError	When an error occurs in the execution conditions or input	• When bEnable shifts to False.	
dwErrorID	values for the instruction.	(Error code is cleared.)	

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bExecute</i> shifts to True.

***Note:** AXIS_REF_SM3 (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

Explanation of *eStopMode*

ENUM	ENUM Name
0	SMC3_PCL_OFF
1	SMC3_PCL_DISABLE
2	SMC3_PCL_HALT
3	SMC3_PCL_ENABLE

- SMC3_PCL_OFF: When LagError is out of the allowed range, the axis is still running.
- SMC3_PCL_DISABLE: When LagError is out of the allowed range, the axis parameter bRegulatorOn changes to False.
- SMC3_PCL_HALT: When LagError is out of the allowed range, the axis parameter *bDriveStart* changes to False.
- SMC3_PCL_ENABLE: When LagError is out of the allowed range and the axis stops, there are no change for *bRegulatorOn* and *bDriveStart* states.
- Calculation and Judgement of Lag Error
 - (fActPosition + fSetActTimeLagCycles * [Task cycle time] * fActVelocity –
 fSetPosition) | > fMaxPositionLag
 - fSetActTimeLagCycles sets the lag cycle between the command value and actual value. The bigger the difference between the set lag cycle and actual lag cycle, the more likely the lag error will occur due to the error between the command position and actual position.
- When LagError is out of the range, *bOutOfRange* will change to True and the axis will perform corresponding action based on the setting of *eStopMode*.

• Troubleshooting

When an error occurs in the instruction execution or the axis enters Errorstop state, bError changes to True and the axis stops running. To confirm current error state, see the error code in ErrorID.

• Programming Example

The example illustrates how to observe the position lag state and modify the position lag parameters via DMC_PositionLag.

	DMC_PositionLa	lg_0
TRUE	DMC_PositionI	ag
	EN	ENO
SM_Drive_ETC_Delta_ASDA_A2 - 😁	Axis	bOutOfRange FALSE
TRUE	bEnable	bBusy TRUE
SMC3_PCL_0 -	eStopMode	bError FALSE
0 -	fMaxPositionLag	dwErrorID _ DMC_NO_ERR
3 -	fSetActTimeLagCycles	lrPosLag 0

Timing Diagram



- 1. Firstly, set *eStopMode* to SMC3_PCL_OFF. The axis starts to run. Then no matter whether the lag error occurs, the axis will not stop running with *bOutOfRange* of the instruction always being False.
- 2. Then set *eStopMode* to SMC3_PCL_HALT and set *fMaxPositionLag* to a value which is greater than LagError value. Then the position lag value will never be out of the range for the constant-velocity motion.
- 3. Eventually, adjust *fMaxPositionLag* to a value which is less than LagError value. Then it can be found that the axis stops running and enters ErrorStop state. And *bOutOfRange* of the instruction shifts to True.

• Supported Products

AX-308E, AX-364E

2.3.2.19 DMC_SetTorqueLimit

DMC_SetTorqueLimit sets the maximum torque of an axis.

FB/FC	Instruction	Graphic expression		
FB	DMC_SetTorqueLimit	DMC_SetTorqueLimit — Axis AXIS_REF_SM3 BOOL bDone — bExecute BOOL — IrMaxTorque LREAL BOOL bError — DMC_ERROR dwErrorID		
	ST expression			

FB/FC	Instruction	Graphic expression			
DMC_	DMC_SetTorqueLimit_instance(
bExec	bExecute :=,				
IrMaxT	IrMaxTorque :=,				
bDone	bDone =>,				
bBusy	bBusy =>,				
bComr	bCommandAborted =>,				
bError	pError =>,				
dwErro	ErrorID =>);				

• Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
IrMaxTorque	Specify the maximum rated torque. (Unit: Nm)	LREAL	Positive number or 0(0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the setting is done.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
dwErrorID	Contains error codes.	DMC_ERROR*1	DMC_ERROR(DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (Enum)

Output	Update	Timing
--------	--------	--------

Name	Timing for changing to TRUE	Timing for changing to FALSE	
bDone	 When the setting is completed. 	 When bExecute shifts to False. bDone will change to False after remaining True for one period when bExecute is False but <i>bDone</i> changes to True. 	
bBusy	 When bExecute shifts to True. 	When bDone shifts to Ture.When bError shifts to Ture.	
bError	When an error occurs in the execution conditions or input	• When <i>bExecute</i> shifts from True	
dwErrorID	values for the instruction.	to False. (Error code is cleared.)	

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bExecute</i> shifts to True.

***Note:** AXIS_REF_SM3 (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- After the maximum torque is set, the torque of the motor will be limited to the setting value to protect the motor from damage caused by the excessive torque when large resistance is encountered.
- DMC_SetTorqueLimit can be used to set the maximum torque of an axis with the unit: Nm.
- DMC_SetTorqueLimit can be used only in CSP or CSV mode.

• Troubleshooting

■ When an error occurs in the instruction execution or the axis enters Errorstop state, *bError* changes to True and the axis stops running. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

■ The example illustrates how to use DMC_SetTorqueLimit.



Timing Diagram

Axis	Step1	Step2
Position		
Velocity		
0.2		
0.1		
DMC_SetTorqueLimit	R	eSetting
Execute		
IrMaxTorque _{0.1}		

- 1. Set the maximum rated torque of the axis to 0.1Nm before the operation. Then the operation is performed at a constant velocity.
- 2. Use the external force to make the axis stop (Step 1) during operation. It can be found that the actual torque of the axis reaches 0.1Nm. Then remove the external force.
- 3. Set the maximum rated torque to 0.2 Nm and use the external force to make the axis stop (Step2). It is found that the actual torque of the axis reaches 0.2 Nm at the moment. Finally, the Following Error is generated and Servo ON is disabled.

• Supported Products

AX-308E, AX-364E

2.3.2.20 DMC_SetSoftwareLimit

DMC_SetSoftwareLimit is used to enable, disable and set the upper and lower software limits

FB/FC	Instruction	Graphic expression			
FB	DMC_SetSoftwareLimit	DMC_SetSoftwareLimit Axis AXIS_REF_SM3 BOOL bValid bEnable BOOL BOOL BBusy bSoftLimitSwitch BOOL BOOL bError IrSWLimitNegative LREAL DMC_ERROR dwErrorID IrSWLimitPositive LREAL DMC_ERROR dwErrorID			
	ST expression				
DMC_SetSoftwareLimit_instance (Axis:=, bEnable :=, bSoftLimitSwitch :=, IrSWLimitNegative :=, IrSWLimitPositive :=, bValid =>, bBusy =>, bError =>, dwErrorID =>):					

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is executed when <i>bEable</i> changes from False to True.	BOOL	True/False (False)	-
bSoftLimitSwitch	Enables or disables software limits.	BOOL	True/False (False)	When <i>bEnable</i> and <i>bBusy</i> are True.
IrSWLimitNegative	Negative software limit (User unit)	LREAL	Positive number, negative number or 0	When <i>bEnable</i> and <i>bBusy</i> are True.
IrSWLimitPositive	Positive software limit (User unit)	LREAL	Positive number, negative number or 0	When <i>bEnable</i> and <i>bBusy</i> are True.

• Outputs

Name	Function	Data type	Output range (Default value)
bValid	True when the control over software limit parameters is valid.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
dwErrorID	Contains error codes.	DMC_ERROR*	DMC_ERROR(DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
bValid	• When the control over software limit parameters is valid.	When bEnable shifts to False.When bError shifts to Ture.
bBusy	• When <i>bEnable</i> shifts to True.	When bEnable shifts to False.When bError shifts to Ture.
bError	When an error occurs in the execution conditions or input	• When bEnable is False. (Error
dwErrorID	values for the instruction.	code is cleared.)

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis.	AXIS_REF_SM3*	AXIS_REF_SM3	When <i>bEnable</i> shifts to True.

*Note: AXIS_REF_SM3 (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

After DMC_SetSoftwareLimit is executed, the writing and monitoring of bSoftLimitSwitch, fSWLimitNegative and fSWLimitPositive axis parameters will be conducted according to the settings on bSoftLimitSwitch, IrSWLimitNegative and IrSWLimitPositive of the instruction.

• Troubleshooting

When an error occurs in the instruction execution or the axis enters Errorstop state, bError changes to True and the axis stops running. To confirm current error state, see the error code in ErrorID.

• Programming Example

■ The example illustrates how to use DMC_SetSoftwareLimit to set the software limits.

	DMC_SetSoftwareL	imit_0
TRUE	DMC_SetSoftware	Limit
	EN	ENO
SM_Drive_ETC_Delta_ASDA_A2	Axis	bValid TRUE
E1 TRUE	bEnable	bBusy TRUE
TRUE	bSoftLimitSwitch	bError FALSE
200 —	lrSWLimitNegative	dwErrorID - DMC_NO_ERR
800 —	lrSWLimitPositive	

Timing Diagram

Axis		
Position	1000	
bSWLimitEnable	200	
bSWLimitNegative	0 1000	
bSWLimitPositive	800	
DMC_SetSoftwareLimi	it	
bExecute		
bSoftLimitSwitch	200	
IrSWLimitNegative	0	
IrSWLimitPositive	0	

- 1. After DMC_SetSoftwareLimit is started, the axis parameters writing is conducted based on the set input parameters of the instruction.
- 2. When *bSoftLimitSwitch* is True, the axis stopping starts as the axis position is outside the software limits.

• Supported Products

■ AX-308E, AX-364E

2.3.2.21 DMC_CamKeyPointWrite

DMC_CamKeyPointWrite writes key cam points by selecting a curve type and generating corresponding cam curve based on related parameters. After the new cam curve is generated, the selected cam table will be changed accordingly.

FB/FC	Instruction	Graphic expression	
FB	DMC_CamKeyPointWrite	CAM_MC_CAM_RBF BOOL bDone 	
ST expression			

FB/FC	Instruction	Graphic expression			
DMC_	DMC CamKeyPointWrite instance (
CAM ::	=,				
bExeci	ute :=,				
lrKeyP	ointX :=,				
lrKeyP	ointY :=,				
CamC	urveType :=,				
bVeloc	ityEnable :=,				
lrVeloc	IrVelocity :=,				
bAccel	erationEnable :=,				
IrAccel	IrAcceleration :=,				
wWrite	Amount :=,				
bDone	bDone =>,				
bBusy	bBusy =>,				
bError	=>,				
dwErro	orID =>);				

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> changes from False to True.	BOOL	True/False (False)	-
IrKeyPointX	The master axis positions of key points which are set (Unit: user unit)	LREAL [063]	Negative number, Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrKeyPointY	The slave axis positions of key points which are set. (Unit: user unit)	LREAL [063]	Negative number, Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
CamCurve Type	Select types of cam curves between key cam points.	DMC_ Cam Curve Type [062] [*]	0: Line 1: Quadratic_Parabola 2: Poly5 3: Basic_Sine 4: Inclined_Sine 5: Mod_Acc_Sine 6: Mod_Acc_Trapezoidal	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.

Chapter 2

Name	Function	Data type	Setting value (Default value)	Timing for updating
			7: Cubic_Spline_Nature 8: Cubic_Spline_Clamp 9: Cubic_Spline (Line)	
bVelocity Enable	Enable or disable velocity settings of key points.	BOOL [063]	Negative number, Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrVelocity	Velocities of key cam points	LREAL [063]	Negative number, Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
bAccelerationEnable	Enable or disable acceleration settings of key points	BOOL [063]	Negative number, Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
IrAcceleration	Acceleration rates of key cam points	LREAL [063]	Negative number, Positive number or 0 (0)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.
wWriteAmount	The amount of key cam points which are set	WORD	2~64 (2)	When <i>bExecute</i> is True and the output <i>bBusy</i> is False.

*Note: DMC_CamCurveType: Enumeration (ENUM)

• Outputs

Name	Function	Data type	Output range (Default value)
bDone	True when the instruction is complete.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)

Name	Function	Data type	Output range (Default value)
bError	True when an error occurs.	BOOL	True/False (False)
dwErrorID	Contains error codes.	DMC_ERROR*	DMC_ERROR(DMC_NO_ERROR)

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
bDone	 When the instruction is completed. 	 When <i>bExecute</i> shifts to False. <i>bDone</i> will change to False after remaining True for one period when <i>bExecute</i> is False but <i>bDone</i> changes to True.
bBusy	• When <i>bExecute</i> shifts to True.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to Ture.
bError	When an error occurs in the execution conditions or input	• When <i>bExecute</i> shifts from True
dwErrorID	values for the instruction.	to False. (Error code is cleared.)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
CamTable	Specify a cam table	MC_CAM_REF*	MC_CAM_REF	When <i>bExecute</i> shifts to True.

*Note: MC_CAM_REF (FB): The basic CAM.

• Function

This function block may take a long time to perform the calculation of curves and cam points. Therefore, it is suggested that this function block should be used in a non-

EtherCAT Task in order to avoid the issue of Lost Sync in EtherCAT Task when DMC_CamKeyPointWrite is executed.

■ CamCurveType

CamCurveType	Description			
Line (0)	Used in the situation where the velocity-constant motion is maintained. There will be a large force on the start point and end point of a straight line (the accelerations for the start point and end point of the line segment approaches infinity), which is very obvious in the high speed operation. So the curve type is suitable for use in low-speed operation.			
Quadratic_Parabola (1)	Used in the situation where the acceleration must maintain a constant-velocity motion. This type of curve (with non-zero acceleration rates at the start point and end point of the line segment) is more likely to cause shock as well as vibration. So the curve type is suitable for use in lower speed operation.			
Poly5 (2)	Users can set the velocity and acceleration boundaries of the start point and the end point, or automatically continue the velocity and acceleration boundary value of the previous or next segment (via disabling <i>bVelocityEnable / bAccelerationEnable</i>)			
Basic_Sine (2)	Used in the situation where the follower needs to do a simple harmonic motion. This curve is a cosine curve in the acceleration diagram. The positive maximum acceleration rate and negative maximum acceleration rate are at the start position and the end position respectively and it is zero at the middle point. So the Jerk is infinite at the start position and end position, which is prone to shock and vibration. So the curve type is suitable for applications in the medium and low speed operation.			
Inclined_Sine (3)	Used in the situation where the follower needs to perform a cycloid motion. This curve is a sine curve in the acceleration diagram, and the acceleration at the start position and the end position is zero, so the jump produced will not cause the acceleration to reach infinity. And thus the curve type can be applied for high-speed operation due to smooth operation.			
Mod_Acc_Sine (4)	The acceleration graph of the curve is a sine curve changed from a typical ladder graph, so that the acceleration is smoother. The curve type is applied for high-speed operation.			
Mod_Acc_Trapezoidal (5)	The acceleration graph of the curve is a sine curve changed from oblique straight lines for the acceleration and deceleration segments of a typical ladder diagram. So the acceleration has better smoothness. The curve type is applied for high-speed operation.			
Cubic_Spline_Nature (6)	The acceleration at the start and end points of the cubic curve is zero. That is, there is no force on both ends of the follower.			

CamCurveType	Description
Cubic_Spline_Clamp (7)	The velocities for the start and end points of the cubic curve are user-set values. The acceleration rates for both ends are the positive maximum and negative maximum, so shock and vibration are likely to occur.
Cubic_Spline (8)	The cubic curve is used when four or more key points are used as interpolation points in order to link two boundary curves as well as avoid the Runge phenomenon of multi-order curves.

- Velocity Enable / Acceleration Enable
 - Users can enable or disable the velocities and accelerations of key points through the *bVelocityEnable* and *bAccelerationEnable* parameters of the instruction.
 - ◆ False means that the user-set velocity or acceleration value is not enabled for curve planning. The boundary condition values of key points will automatically obtain the velocity or acceleration calculated for the previous or next curve segment so as to achieve continuous velocity or acceleration for the intersection of curves. True means that a curve will be produced based on the velocities and accelerations of key points, which are the condition values of *IrVelocity* and *IrAcceleration* set by user.
 - For some of the following curves, the velocity and acceleration of their key points can be specified via *bVelocityEnable* and *bAccelerationEnable*. See details in the following table.

No.	Curve type	VelocityEnable	AccelerationEnable	AccelerationEnable Velocity	
0	Straight line	Not possible *1	Not possible *1	Automatically calculated	0
1	Parabola	Not possible	Not possible	0	Automatically calculated
2	Poly5	Possible	Possible	User can define	User can define
3	Acceleration cosine curve	Not possible	Not possible 0		Automatically calculated
4	Acceleration sine curve	Not possible	Not possible	0	0
5	Modified acceleration sine curve	Possible	Not possible User can define		0
6	Modified acceleration trapezoidal curve	Not possible	Not possible 0		0
7	Cubic spline curve (nature boundary)* ²	Not possible	Not possible	Automatically calculated	0

No.	Curve type	VelocityEnable	AccelerationEnable	Velocity	Acceleration
8	Cubic spline curve (clamp boundary)* ²	Possible	Not possible	User can define	Automatically calculated
9	Cubic spline curve ^{*3}	Not possible	Not possible	Automatically calculated	Automatically calculated

*Note:

- 1. Not possible: the setting value is invalid; Possible: the setting value is valid.
- 2. The boundary conditions of the cubic spline curve are classified into nature boundary and clamp boundary. The nature boundary means that the acceleration of the spline curve is specified as 0 and the velocity for both ends of the curve cannot be specified. The clamp boundary means the velocity for both ends of the curve can be specified but the acceleration cannot be specified.
- 3. The Cubic_Spline curve is a curve for connecting two boundaries and the boundary curves at the two ends of the cubic spline curve must be the same as follows.

CamCurve_Type[0] := Cubic_Spline_Nature;

CamCurve_Type[1] := Cubic_Spline;

CamCurve_Type[2] := Cubic_Spline_Nature;

- Key point number specified by WriteAmount
 - The amount of key points specified by WriteAmount is up to 64 points, but the key point amount cannot exceed the total resolution of the cam table.
 - Each key point (except the last point) needs to select a curve type, the resolution between the straight lines is fixed as 1, and the resolution of the remaining curves is averaged by the remaining analytical points; but when there are only straight lines in the entire cam table, then the points of the entire cam table will be divided equally by all straight lines.

Curve Type	Description
Line (0)	Used in the situation where the velocity-constant motion is maintained. There will be a large force on the start point and end point of a straight line (the accelerations for the start point and end point of the line segment approaches infinity), which is very obvious in the high speed operation. So the curve type is suitable for use in low-speed operation.
Parabola	Used in the situation where the acceleration must maintain a constant- velocity motion. This type of curve (with non-zero acceleration rates at the start point and end point of the line segment) is more likely to cause shock as well as vibration. So the curve type is suitable for use in lower speed operation.
Poly5	Users can set the velocity and acceleration boundaries of the start point and the end point, or automatically continue the velocity and acceleration boundary value of the previous or next segment (via disabling <i>bVelocityEnable / bAccelerationEnable</i>)
Acceleration	Used in the situation where the follower needs to do a simple harmonic

Curve Types

Curve Type	Description	
cosine curve	motion.	
	This curve is a cosine curve in the acceleration diagram. The positive maximum acceleration rate and negative maximum acceleration rate are at the start position and the end position respectively and it is zero at the middle point. So the Jerk is infinite at the start position and end position, which is prone to shock and vibration. So the curve type is suitable for applications in the medium and low speed operation.	
Acceleration sine curve	Used in the situation where the follower needs to perform a cycloid motion. This curve is a sine curve in the acceleration diagram, and the acceleration at the start position and the end position is zero, so the jump produced will not cause the acceleration to reach infinity. And thus the curve type can be applied for high-speed operation due to smooth operation.	
Modified acceleration sine curve	The acceleration graph of the curve is a sine curve changed from a typical ladder graph, so that the acceleration is smoother. The curve type is applied for high-speed operation.	
Modified acceleration trapezoidal curve	The acceleration graph of the curve is a sine curve changed from oblique straight lines for the acceleration and deceleration segments of a typical ladder diagram. So the acceleration has better smoothness. The curve type is applied for high-speed operation.	
Cubic spline curve (nature boundary)	The acceleration at the start and end points of the cubic curve is zero. That is, there is no force on both ends of the follower.	
Cubic spline curve (clamp boundary)	The velocities for the start and end points of the cubic curve are user-set values. The acceleration rates for both ends are the positive maximum and negative maximum, so shock and vibration are likely to occur.	
Cubic spline curve	The cubic curve is used when four or more key points are used as interpolation points in order to link two boundary curves as well as avoid the Runge phenomenon of multi-order curves.	

Troubleshooting

When an error occurs in the instruction execution or the axis enters Errorstop state, bError changes to True and the axis stops running. To confirm current error state, see the error code in ErrorID.

• Programming Example

- Programming Example1:
 - The example illustrates the synchronized motion based on the cam table generated from DMC_DMC_CamKeyPointWrite.

TRUE	EXECUTE
EN	ENO
± Curve	Type[0] := DMC_CamCurveType.PoTy5; Type[1] := DMC_CamCurveType.Mod_Acc_Trapezoidal:
-	
TRUF	
EN	EXECUTE EAECUTE ENO
+ KevPo	intX[0] := 0:
KeyPo	<pre>intY[0] := 0; KeyPointV[1] := 0; VelocityEnable[1] := TRUE;</pre>
KeyPo	<pre>intX[1] := 180; KeyPointV[2] := 1; VelocityEnable[2] := TRUE;</pre>
KeyPo	<pre>intY[1] := 180; KeyPointA[0] := 0; AccelerationEnable[0] := TRUE; intY[2] := 260; KeyPointA[1] := 0; AccelerationEnable[1] := TPUF;</pre>
KeyPo	<pre>intY[2] := 0; KeyPointA[2] := 0; AccelerationEnable[2] := TRUE; intY[2] := 0; KeyPointA[2] := 0; AccelerationEnable[2] := TRUE;</pre>
-	
TRUE	DMC_CamkeyPointwrite_0
	DMC_CamKeyPointWrite
CTT for Con Con	
GVL_IOT_Cam.Cam -	LAM BLONE TRUE
TRUE	DEXEcute DBusy 34453
KeyPointx	IFREYFOINTA DEFFOR
KeyPointy -	awerrorib awerrorib
Curvefype —	Camburverype
velocityEnable -	DVELOCITYMADIE
KeyPointV	irvelocity
AccelerationEnable -	DACCELETATIONENADIE
KeyPointA —	IrAcceleration
3 —	wWriteAmount

 The cam table generated from DMC_CamKeyPointWrite can be used by MC_CamTableSelect directly.



Timing Diagram



Three key points are used to make up a curve. The first segment of the curve is a 5th Polynomial curve, and the second segment is a Mod_Acc Trapezoidal curve.

- Programming Example2:
 - The example illustrates the special applications of cubic interpolation curves:

CamCurve_Type[0] := Line;	
CamCurve_Type[1] := Cubic_Spline_Nature;	
CamCurve_Type[2] := Cubic_Spline_Nature;	Case I.
CamCurve_Type[3] := Line;	
CamCurve_Type[4] := Cubic_Spline_Nature;	1
CamCurve_Type[5] := Cubic_Spline_Nature;	- Case 2.
CamCurve_Type[6] := Cubic_Spline_Nature;]
CamCurve_Type[7] := 5th Polynomial;	
CamCurve_Type[8] := Cubic_Spline_Nature;	1
CamCurve_Type[9] := Cubic_Spline;	Coro 3
CamCurve_Type[10] := Cubic_Spline;	Case 5.
CamCurve_Type[11] := Cubic_Spline_Nature;]
CamCurve_Type[12] := 5th Polynomial;	

- Case 1. If you want to plan a cubic curve with three key points, just select the curve types with the same boundaries.
- Case 2. If there are three or more boundary condition curves, each two curves will be counted as a segment in the curve planning calculation. If there are no continuous boundary curves, the single curve will be calculated as a boundary condition curve.
- Case 3. If there are four or more key points to be on the same curve, you can use spline curves as the continuous line segments of the continuous boundary condition curves at both ends. Then the key points between the two ends will be used as inner interpolation points of the cubic curve.

• Supported Products

AX-308E, AX-364E

2.3.2.22 DMC_TouchProbeCyclically

DMC_TouchProbeCyclically can continuously record the captured position of an axis.

FB/FC	Instruction	Graphic expression				
FB	DMC_TouchProbeCyclically	DMC_TouchProbeCyclically Axis AXIS_REF_MAPPING_SM3 BOOL bTouched TriggerInput DMC_TRIGGER_REF BOOL bBOUL bBusy bEnable BOOL BOOL bCommandAborted bWindowOnly BOOL BOOL BEOL bError IrFirstPosition LREAL DMC_ERROR dwErrorID IrLastPosition LREAL LREAL IrRecordedPosition				
		ST expression				
DMC_	TouchProbeCyclically_instan	ce (
Axis :=	,					
Trigger	rInput :=,					
bEnab	le :=,					
bWind	owOnly :=,					
IrFirstF	Position :=,					
IrLastP	Position :=,					
bTouch	bTouched =>,					
bBusy =>,						
bCommandAborted =>,						
bError =>,						
dwErrorID =>,						
IrReco	IrRecordedPosition =>);					

Inputs

Name	Function	Data type	Setting value (Default value)	Timing for updating
bEnable	The instruction is executed when <i>bEnable</i> changes from False to True.	BOOL	True/False (False)	-
bWindowOnly	Enable the Window range setting.	BOOL	True/False (False)	When <i>bEnable</i> and <i>bBusy</i> are False.
IrFirstPosition	Defines the start position of Window. (Unit: user unit)	LREAL	Negative number, Positive number or 0 (0)	When <i>bEnable</i> and <i>bBusy</i> are False.

Name	Function	Data type	Setting value (Default value)	Timing for updating
IrLastPosition	Defines the end position of Window. (Unit: user unit)	LREAL	Negative number, Positive number or 0 (0)	When <i>bEnable</i> and <i>bBusy</i> are False.

• Outputs

Name	Function	Data type	Output range (Default value)
bTouched	True when the trigger signal is True and axis position recording is completed.	BOOL	True/False (False)
bBusy	True when the instruction is being executed.	BOOL	True/False (False)
bCommand Aborted	True when the instruction is aborted by another instruction.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
dwErrorID	Contains error codes.	DMC_ERROR*1	DMC_ERROR(DMC_NO_ERROR)
IrRecorded Position	Contains the position when a trigger occurs.	LREAL	Positive number, negative number or 0 (0)

*Note: DMC_ERROR: Enumeration (Enum)

Output Update Timing

Name	Timing for changing to TRUE	Timing for changing to FALSE
bTouched	• When the trigger signal is True and axis position recording is completed.	 When <i>bEnable</i> shifts to False. When <i>bCommandAborted</i> shifts to True. When <i>bError</i> shifts to True. After a period when <i>bEnable</i> shifts to True.
bBusy	• True when the instruction execution starts.	 When bEnable shifts to False. When bCommandAborted shifts to True. When bError shifts to True.
bCommand Aborted	 When the instruction is aborted by another instruction. 	When bEnable shifts to False.

Name	Timing for changing to TRUE	Timing for changing to FALSE
bError	When an error occurs in the execution conditions or	When bEnable changes from True to
dwErrorID	input values for the instruction.	False.

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis.	AXIS_REF_SM3*1	AXIS_REF_SM3 (Must be specified)	-
TriggerInput	Trigger signal	DMC_TRIGGER_REF *2	TRIGGER_REF (-1)	When <i>bEnable</i> shifts to True and <i>bBusy</i> is False.

*Note:

- 1. AXIS_REF_SM3 (FB): The interface is built in every function block and works as the starting program of the function block.
- 2. DMC_TRIGGER_REF: Structure (STRUCT)

Name Eurotion Data type		Setting value	
Name	Function	Data type	(Default)
iTriggerNumber	The trigger channel	INT	0: Touch Probe 1 1: Touch Probe 2 (-1)
eFastLatching	The trigger signal	DMC_LATCH_MODE	0: DRIVE_MODE 1: CONTRL_MODE (DRIVE_MODE)
bInput	The trigger signal source when the	BOOL	The trigger signal source

Name	Function	Data type	Setting value (Default)
	controller is triggered		
bActive	Activate or deactivate the trigger signal	BOOL	True: Activate the trigger signal (False)
iCtrlTriggerSource	The recorded position source	INT	0: Set Position 1: Act Position (0)
iCtrlTriggerNumber	The mode of triggering the controller	INT	0: Rising edge data capture 1: Falling edge data capture 2: Rising/falling edge data capture (-1)

Function

- When the trigger signal (*eFastLatching*) is DRIVE_MODE, then the position is provided by the servo and *iCtrlTriggerSource* is meaningless. *iCtrlTriggerSource* is available only for CONTRL_MODE.
- When DMC_TouchProbeCyclically is used, the Touch Probe Function (60B8h) cannot be configured to PDO. If users configure it to PDO, the function block will report an error when being executed.
- DMC_TouchProbeCyclically cannot be used with MC_TouchProbe together. If MC_TouchProbe is already executed, an error will occur when DMC_TouchProbeCyclically is executed. DMC_TouchProbeCyclically will also report an error if MC_TouchProbe is executed during DMC_TouchProbeCyclically execution.
- If the trigger signal is DRIVE_MODE, the position stored in the servo is read directly and then the *iCtrlTriggerSource* of *TriggerInput* is an invalid parameter.
- blnput of TriggerInput is the trigger signal source under CONTRL_MODE, and it is an invalid parameter under DRIVE_MODE mode.
- When DRIVE_MODE is used, TouchProbe1 and TouchProbe2 can be started respectively in two independent DMC_TouchProbeCyclically instructions.

Troubleshooting

■ When an error occurs in the instruction execution or the axis enters Errorstop state, *bError* changes to True and the axis stops running. To confirm current error state, see the error code in ErrorID.

• Programming Example

- Programming Example1:
 - This example illustrates how to use DMC_TouchProbeCyclically in

CONTRL_MODE mode.



• Timing Diagram

Axi	s	1	1	
fActPosition				
DMC_TouchProbe	Cyclically			
binput				
bEnable				
bTouched				
IrRecordedPosition				

- 1. DMC_TouchProbeCyclically specifies CONTRL_MODE and uses the rising edge or falling edge as the trigger signal with the actual position of the axis (*fActPosition*) as the reference position.
- 2. When the signal source *blnput* of *Triggerlnput* is triggered in CONTRL_MODE mode and the state of *blnput* changes, the function block will record the actual position of the current axis, and *bTouched* will remain True for one period.
- Programming Example 2:
 - The example illustrates how to use DMC_TouchProbeCyclically by using SSI Encoder as the signal source in CONTRL_MODE.



Device tree setting

BuiltIn_IO (BuiltIn_IO)					
DIO (DIO)					
G SSI_Encoder (SSI_Encoder)					
Encoder_Axis_SSI (Encoder_Axis)					

♦ Timing Diagram

Trigge	er		•	
E1				
Axi	S			
fActPosition				
DMC_TouchProbe	Cyclic <u>ally</u>	1 1 1 1	1 1 1 1	1 1 1 1 1
bEnable			1 1 1 1 1	
bTouched				
			1 1 1 1 1	
bBusy		1 1 1 1 1	1 1 1 1 1	1 1 1 1 1
IrRecordedPosition				

- 1. Select SSI Encoder as the signal source for DMC_TouchProbeCyclically.
- 2. Add an SSI Encoder to the device tree and then connect the SSI Encoder to the AX-308 module. For wiring, please refer to section 2.2.4 CPU Module Input and Output Terminals in **AX-3 Series Operation Manual**.
- 3. When the *blnput* of *TriggerInput* is triggered, DMC_TouchProbeCyclically will record the position of the current SSI Encoder.
- Programming Example 3:
 - The example illustrates how to use DMC_TouchProbeCyclically with Pulse Encoder as the signal source in CONTRL_MODE mode.



♦ Device tree setting



Timing Diagram



- 1. Select Pulse Encoder as the signal source for DMC_TouchProbeCyclically.
- 2. Add a Count to the device tree (here is Count 1), and then add DFB_HCnt to the program to read the value of the Pulse Encoder. Finally connect the Pulse Encoder. For wiring, please refer to Section 2.2.4 CPU Module Input and Output Terminals in **AX-3 Series Operation Manual**.
- 3. When the *blnput* of *TriggerInput* is triggered, DMC_TouchProbeCyclically will record the position of the current Pulse Encoder.

Chapter 2

- Programming Example 4:
 - The example illustrates how to use DMC_TouchProbeCyclically in DRIVE_MODE.

	MC_F	?ower_0			MC_Move	Velocity_0	
TRUE	MC	Power			MC Mov	eVelocity	
	EN	ENO			EN	ENO	
SM_Drive_ETC_Delta_ASDA_A2 -	Axis	Status	- SM_Drive_E	TC_Delta_ASDA_A2 ─←	Axis	InVelocity	-
TRUE -	Enable	bRegulatorRealState	-		Execute	Busy	-
TRUE	bRegulatorOn b	DriveStartRealState	-	5	Velocity	CommandAborted	-
TRUE -	bDriveStart	Busy	-	1000 —	Acceleration	Error	-
		Error	-	1000 —	Deceleration	ErrorID	-
		ErrorID	-	10000 —	Jerk		
			MC_DI	RECTION.positive —	Direction		
TRUE	EXE	CULLE					
EN EN	DAL	JC011	ENO				
DMC_Trigger.i	TriggerNumber := (0;(*0:TP0,1:TP1*)					
DMC_Trigger.i	CtrlTriggerNumber	:= 0;(*0:rsing 1:fa	ling 2:all*)				
DMC_Irigger.e	rastLatening := D	MC_LAICH_MODE.DRIVE_	IODE;				
	DMC_TouchPr	obeCyclically_0					
TRUE	DMC TouchP	robeCyclically					
	EN	ENC) ——				
SM_Drive_ETC_Delta_ASDA_A2 - +	Axis	bTouched	-				
DMC_Trigger -	TriggerInput	bBusy	-				
	bEnable	bCommandAborted	-				
	bWindowOnly	bError	-				
	lrFirstPosition	dwErrorID	-				
	lrLastPosition	lrRecordedPosition	-				

• Wiring figure



- 1. The trigger signal comes from DI13 of extension DIs of the servo drive's CN7. Please refer to the wiring figure above for configuration.
- 2. In this example, the TouchProbe 1 trigger is taken as an example and so the photoelectric switch is connected to DI13. If the TouchProbe 2 trigger is selected, the photoelectric switch should be connected to DI14.

Timing Diagram

Axi	s			
fActPosition				
DMC_TouchProbe	Cyclic <u>ally</u>			
bEnable				
bTouched				
		, 1 1 1 1	, , , , , ,	1 1 1 1
bBusy				
IrRecordedPosition			ſ	ſ



- 1. DMC_TouchProbeCyclically specifies DRIVE_MODE with TouchProbe 1 which is triggered by the rising edge signal.
- 2. When the switch trigger occurs, the drive will record the current position, send it back to the controller and record it in the function block IrRecordedPosition, and *bTouched* will remain True for one period.
- 3. In DRIVE_MODE, the drive will record the current position in real time and thus the recorded position will be earlier than the actual feedback position of the controller.
- Supported Products
 - AX-308, AX-364E
2.3.3 Positioning Axis Instructions

The function blocks in this section come from the function library $^{\Gamma}$ DL_MotionControlLight $_{J}$. The main motion curve planning and calculation of function blocks are handled by the drive. So please select the positioning axis when setting the axis. For related settings on a positioning axis, please refer to section 7.4 in AX-3 Series Operation Manual.

2.3.3.1 MC_Power_DML

MC_Power_DML is used to enable, disable and immediately stop the specified axis.

FB/FC	Instruction	Graphic expression							
FB	_DML	MC_Power_DML Axis AXIS_REF_DML BOOL bStatus bEnable BOOL BOOL bRegulatorRealState bRegulatorOn BOOL BOOL bDriveStartRealState bDriveStart BOOL BOOL bBusy BOOL bError DML_ERROR ErrorId							
	ST expression								
MC_P	ower_DML_instance(
Axis :=	,								
bEnab	le :=,								
bRegu	latorOn:=,								
bDrive	Start :=,								
bStatus =>,									
bRegulatorRealState =>,									
bDriveStartRealState =>,									
bBusy =>,									
bError	=>,								
ErrorIL) =>);								

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bEnable	The instruction is executed when <i>bEnable</i> shifts from False to True.	BOOL	True/False (False)	-
bRegulatorOn	Power ON	BOOL	True/False (False)	Only valid when <i>bEnable</i> is True.
bDriveStart	Disable the	BOOL	True/False	Only valid when

Name	Function	Data type	Setting value (Default)	Timing for updating
	immediate stop mechanism.		(False)	<i>bEnable</i> is True.

Outputs

Name	Function	Data type	Output range (Default)
bStatus	bStatus True when the specified axis can move.		True/False (False)
bRegulatorRealState	True when the power is ON	BOOL	True/False (False)
bDriveStartRealState	True when the immediate stop mechanism can be used.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs in execution of the instruction.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False		
bStatus	• When <i>bEnable</i> is True and <i>bRegulatorRealState</i> and <i>bDriveStartRealState</i> shift to True.	 When bEnable is True and bRegulatorRealState or bDriveStartRealState shifts to False. When bError shifts to True. 		
bRegulatorRealState	• When <i>bEnable</i> and <i>bRegulatorRealState</i> are True.	 When <i>bEnable</i> is True and <i>bRegulatorRealState</i> shifts to False. When <i>bError</i> shifts to True. 		
bDriveStartRealState	• When <i>bEnable</i> and <i>bRegulatorRealState</i> , <i>bDriveStartRealState</i> are True.	 When bEnable is True, and bRegulatorRealState or bDriveStartRealState shifts to False. When bError shifts to True. 		

Chapter 2

Name	Timing for shifting to True	Timing for shifting to False
bBusy	• When <i>bEnable</i> shifts to True.	 When <i>bEnable</i> shifts to False. When <i>bError</i> shifts to True.
bError	When an error occurs in the execution conditions or input	• When error code is
ErrorID	values for the instruction.	cleared.

• Timing Diagram

bEnable				
bRegulatorOn				
bDriveStart		ļ		
bStatus	 	ļ		
bBusy				
bRegulatorRealStatus	 			
bDriverStartStatus				

In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bEnable</i> shifts to True.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- *bRegulatorOn* and *bDriveStart* are effective only when *bEnable* is True.
- When bEnable, bRegulatorOn and bDriveStart are all True, bStatus changes to True and nAxisState (state machine) changes to Standstill
- When *bEnable* and *bRegulatorOn* are True and then *bDriveStart* is set to False, *nAxisState* (state machine) changes to Stopping.
- When *bEnable* and *bDriveStart* are True and then *bRegulatorOn* is set to False, *nAxisState* (state machine) changes to Disabled.

• Troubleshooting

■ When an error occurs in the instruction execution or the axis enters Errorstop state, *bError* changes to True and the axis stops running. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_Power function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

■ AX-308E, AX-364E

2.3.3.2 MC_Stop_DML

MC_Stop_DML decelerates the specified axis to a stop.

FB/FC	Instruction	Graphic expression					
FB	MC_Stop_DML	MC_Stop_DML — Axis AXIS_REF_DML BOOL bDone — bExecute BOOL BOOL bCommandAborted BOOL bError DML_ERROR ErrorId					
ST expression							
MC_St Axis := bExect bDone bBusy bComr bError	top_DML_instance (;, ute :=, =>, =>, mandAborted=>, =>,						

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to	BOOL	True/False (False)	-

Name	Function	Data type	Setting value (Default)	Timing for updating
	True.			

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the velocity reaches 0.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID Contains error code if an error occurs. Refer to Appendices for error code descriptions.		DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note:

DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	• When the axis decelerates to a stop or the velocity is 0.	 When <i>bExecute</i> shifts from True to False. If <i>bExecute</i> is False and <i>bDone</i> shifts to True, <i>bDone</i> will be True for one period and then immediately shift to False.
bCommandAborted	 When the axis state switches to Disabled during instruction execution. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bCommandAborted</i> shifts to True, <i>bCommandAborted</i> will be True for one period and then immediately shift to False.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts to

Name	Timing for shifting to True	Timing for shifting to False
ErrorID	execution conditions or input values for the instruction.	False. (Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- MC_Stop_DML can be used to stop the axis in motion and State Machine enters Stopping.
- When MC_Power is set to False during deceleration, the motor will be in Free Run.
- When the axis velocity is already decreased to 0 and *Done* of MC_Stop changes to True, *Execute* of MC_Stop changes to False and State Machine changes from Stopping to Standstill.
- The deceleration rate can follow the setting value of Quick stop deceleration (16#6085) in the CiA402 object dictionary.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_Stop function block
- For Axis of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.3 MC_Reset_DML

MC_Reset_DML clears axis-related errors.

FB/FC	Instruction	Graphic expression			
FB	MC_Reset_DML	MC_Reset_DML — Axis AXIS_REF_DML BOOL bDone — bExecute BOOL BOOL BOOL bError DML_ERROR ErrorId			
		ST expression			
MC_R	eset_DML_instance(
Axis :=	;,				
bExec	ute :=,				
bDone	bDone =>,				
bBusy	bBusy =>,				
bError	bError =>,				
ErrorI	ErrorID =>);				

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to True.	BOOL	True/False (False)	-

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when axis error clearing is completed and the axis enters Standstill or	BOOL	True/False (False)

Name	Function	Data type	Output range (Default)
	Disabled.		
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When axis error clearing is completed. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bDone</i> shifts to True, <i>bDone</i> will be True for one period and then immediately shift to False.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bError</i> shifts to True. When <i>bDone</i> shifts to True.
bError	When an error occurs in the execution conditions or input	• When <i>bExecute</i> shifts to False.
ErrorID	values for the instruction.	(Error code is cleared)

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

 MC_Reset_DML can change the axis from abnormal error state to normal operational state.

When MC_Power_DML.Enable is True, the axis state changes from Errorstop to Standstill.

When MC_Power_DML.Enable is False, the axis state changes from Errorstop to Disabled.

- When the servo controller reports an error, MC_Reset_DML can be used to clear the error. After the error is cleared, the axis state will return to Standstill or Disabled.
- If errors (e.g. a communication error) cannot be cleared by MC_Reset_DML, the instruction will report DML_R_ERROR_NOT_RESETTABLE (122) error.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_Reset function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

■ AX-308E, AX-364E

2.3.3.4 MC_Halt_DML

MC_Halt_DML halts an axis in a controllable way.

FB/FC	Instruction	Graphic expression	
FB	MC_Halt_DML	MC_Halt_DML Axis AXIS_REF_DML BOOL bDone bExecute BOOL BOOL bBusy IrDeceleration LREAL BOOL bCommandAborted BOOL bError DML_ERROR ErrorId	
ST expression			

FB/FC	Instruction	Graphic expression			
MC_H	alt_DML_instance(
Axis :=	,				
bExec	ute :=,				
IrDece	leration :=,				
bDone	=>,				
bBusy	bBusy =>,				
bCom	bCommandAborted =>,				
bError =>,					
ErrorI) =>);				

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to True.	BOOL	True/False (False)	-
IrDeceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the axis stops and the velocity is 0.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.		DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	• When the axis decelerates to a stop.	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bDone</i> shifts to True, <i>bDone</i> will be True for one period and then immediately shift to False.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When this instruction is aborted by another function block. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bCommandAborted</i> shifts to True, <i>bCommandAborted</i> will be True for one period and immediately shift to False.
bError	• When an error occurs in the execution conditions or	 When bExecute shifts to False
ErrorID ErrorID ErrorID		(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- MC_Halt_DML is different from MC_Stop_DML in stopping the axis motion. MC_Halt_DML can be interrupted by other motion function blocks.
- When MC_Halt_DML is executed, the axis will enter discrete_motion state. When the velocity of the axis reaches zero, the axis will enter Standstill state.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_Halt function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

■ AX-308E, AX-364E

2.3.3.5 MC_Home_DML

MC_Home_DML controls the axis to perform the homing operation.

FB/FC	Instruction	Graphic expression				
FB	MC_Home_DML	MC_Home_DML Axis AXIS_REF_DML BOOL bDone bExecute BOOL BOOL bBusy IrPosition LREAL BOOL bCommandAborted BOOL bError DML_ERROR ErrorId				
		ST expression				
MC_H Axis :=	ome_DML_instance(=					
bExec	, ute:=,					
IrPosit	ion:=,					
bDone	bDone =>,					
bBusy =>,						
bCommandAborted =>,						
bError	bError =>,					
ErrorI	ErrorID =>);					

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to True.	BOOL	True/False (False)	-
IrPosition	Specify the absolute home position. (Unit: user unit)	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when homing is completed and the axis is in Standstill state.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML _NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the homing is completed. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bDone</i> shifts to True, <i>bDone</i> will be True for one period and then

Name	Timing for shifting to True	Timing for shifting to False
		immediately shift to False.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When this instruction is aborted by another instruction. When the instruction is aborted by MC_Stop_DML. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bCommandAborted</i> shifts to True, <i>bCommandAborted</i> will be True for one period and immediately shift to False.
bError	When an error occurs in the execution conditions or	
ErrorID	input values for the instruction.	When error code is cleared.

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

Function

- This function block is executed only when the axis is in Standstill state and the state is Homing during the instruction execution. The function block cannot be executed when the axis is in any state else.
- *Position* is the absolute position when the homing is completed.
- The home mode can be selected from the axis parameter page.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_Home function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.6 MC_MoveAbsolute_DML

MC_MoveAbsolute_DML controls the specified axis to move to the specified absolute target position based on the specified motion behavior.

FB/FC	Instruction	Graphic expression			
FB	MC_MoveAbsolute_DML	MC_MoveAbsolute_DML Axis AXIS_REF_DML BOOL BOOL bExecute BOOL IrPosition LREAL BOOL BOOL IrVelocity LREAL BOOL BOOL IrAcceleration LREAL IrDeceleration LREAL			
		ST expression			
MC_M	loveAbsolute_DML_instanc	e(
Axis :=	⁼,				
bExec	ute :=,				
IrPosit	ion :=,				
IrVeloc	city :=,				
IrAcce	leration :=,				
IrDece	IrDeceleration :=,				
bDone =>,					
bBusy =>,					
bCom	bCommandAborted =>,				
bError	bError =>,				
ErrorI	ErrorID =>);				

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to True.	BOOL	True/False (False)	-
IrPosition	Absolute target position (Unit: user unit)	LREAL	Negative number, positive number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
lrVelocity	Target velocity (Unit: user unit/s)	LREAL	Positive number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
IrAcceleration	Acceleration rate (Unit: user unit/s²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
IrDeceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the absolute target position is reached.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 True when the absolute target position is reached. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bDone</i> shifts to True, <i>bDone</i> will be True for one period and then immediately shift to False.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When this instruction is aborted by another instruction. When the instruction is aborted by MC_Stop_DML. 	 When bExecute shifts to False. If bExecute is False and bCommandAborted shifts to True, bCommandAborted will be True for one period and then immediately shift to False.
bError	When an error occurs in the execution conditions or input	When bExecute shifts to Ealse (Error code is
ErrorID	values for the instruction.	cleared)

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

- Function
 - MC_MoveAbsolute_DML performs absolute positioning according to specified target velocity (*IrVelocity*), acceleration rate (*IrAcceleration*) and deceleration rate (*IrDeceleration*) when *bExecute* shifts to True.
- Troubleshooting
 - When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.
- Programming Example
 - For the example, please refer to the programming example for MC_MoveAbsolute function block
 - For *Axis* of the function block, please enter a positioning axis.
- Supported Products
 - AX-308E, AX-364E

2.3.3.7 MC_MoveRelative_DML

MC_MoveRelative_DML controls the specified axis to move to the specified relative target position according to the specified motion behavior.

FB/FC	Instruction	Graphic	expression	
FB	MC_MoveRelative_DML	MC_MoveR Axis AXIS_REF_DML bExecute BOOL IrDistance LREAL IrVelocity LREAL IrAcceleration LREAL IrDeceleration LREAL	elative_DML BOOL bDone BOOL bBusy BOOL bCommandAborted BOOL bError DML_ERROR ErrorId	
	ST expression			

FB/FC	Instruction	Graphic expression				
MC_N	MC_MoveRelative_DML_instance(
Axis :=	=,					
bExec	ute :=,					
IrDista	nce :=,					
IrVeloo	city :=,					
IrAcce	leration :=,					
IrDece	leration :=,					
bDone	e =>,					
bBusy	bBusy =>,					
bCom	bCommandAborted =>,					
bError	bError =>,					
Errorl) =>);					

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts to True.	BOOL	True/False (False)	-
IrDistance	Relative distance to be moved (Unit: user unit)	LREAL	Negative number, positive number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
lrVelocity	Target velocity (Unit: user unit/s)	ty t/s) LREAL Positive number or 0 (0)		When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
IrAcceleration	Acceleration rate (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
IrDeceleration	Deceleration rate (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the relative distance is completed.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)

Name Function		Data type	Output range (Default)	
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)	
bError	True when an error occurs.	BOOL	True/False (False)	
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)	

***Note:** DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the relative positioning is completed. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bDone</i> shifts to True, <i>bDone</i> will be True for one period and immediately shift to False.
bBusy	 When <i>bExecute</i> shifts to True and the instruction is executed. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When this instruction is aborted by another instruction. When the instruction is aborted by MC_Stop_DML. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bCommandAborted</i> shifts to True, <i>bCommandAborted</i> will be True for one period and then immediately shift to False.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts to False.
ErrorID	values for the instruction.	(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

Function

MC_MoveRelative_DML performs relative positioning according to specified target velocity (*IrVelocity*), acceleration rate (*IrAcceleration*) and deceleration rate (*IrDeceleration*) when *bExecute* shifts to True.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_MoveRelative function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

■ AX-308E, AX-364E

2.3.3.8 MC_MoveVelocity_DML

MC_MoveVelocity_DML performs velocity control on an axis in the position mode with a specified behavior and a constant velocity.

FB/FC	Instruction	Graphic expression			
FB	MC_MoveVelocity_DML	MC_MoveVelocity_DML Axis AXIS_REF_DML BOOL bInVelocity bExecute BOOL BOOL BBusy IrVelocity LREAL BOOL bCommandAborted IrAcceleration LREAL BOOL bError IrDeceleration LREAL DML_ERROR ErrorId			
	ST expression				
MC_M Axis := bExect IrVeloc IrAccel IrDece bInVelo bBusy bComr bError ErrorIE	oveVelocity_DML_instance ;, ute :=, ;; eration :=, leration :=, leration :=, ocity =>, =>, mandAborted =>, =>, D =>);	؛ (

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to True.	BOOL	True/False (False)	-
IrVelocity	Target velocity (Unit: user unit/s)	LREAL	Positive number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
IrAcceleration	Acceleration rate (Unit: user unit/s ²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
IrDeceleration	Deceleration rate. (Unit: user unit/s²)	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and

Chapter 2

Name	Function	Data type	Setting value (Default)	Timing for updating
				<i>bBusy</i> is False.

• Outputs

Name	Function	Data type	Output range (Default)
bInVelocity	True when the target velocity is reached.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bInVelocity	 When the target velocity is reached. 	 When <i>bCommandAborted</i> shifts to True. When <i>bExecute</i> shifts to True again and <i>IrVelocity</i> value is changed.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When this instruction is aborted by another instruction. When the instruction is aborted by MC_Stop_DML. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bCommandAborted</i> shifts to True, <i>bCommandAborted</i> will be True for one period and then immediately shift to False.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts to

Name	Timing for shifting to True	Timing for shifting to False
ErrorID	execution conditions or input values for the instruction.	False. (Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- When *bExecute* shifts to True, the instruction will perform constant-velocity motion according to the specified target speed (*IrVelocity*), acceleration (*IrAcceleration*), and deceleration (*IrDeceleration*).
- The executing MC_MoveVelocity_DML can be aborted by another motion instruction.
- When the instruction is aborted by another instruction, the output *blnVelocity* changes to False and the output *bCommandAborted* changes to True.
- When bExecute of MC_MoveVelocity_DML switches to True, the axis will start to move at the target velocity. Even if bExecute switches to False, the operation of the function block will not be affected.
- When bExecuteInputs of MC_MoveVelocity_DML changes to True again and a new target velocity is assigned, the axis velocity is adjusted to the new velocity.
- When bExecute changes to False after the function block is executed and then the target velocity is reached, the blnVelocity of MC_MoveVelocity_DML changes to True. Afterward, blnVelocity will be True until it is aborted by another instruction.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_MoveVelocity function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.9 MC_WriteBoolParameter_DML

MC_WriteBoolParameter_DML writes a Boolean value in the specified parameter.

FB/FC	Instruction	Graphic expression		
FB	MC_WriteBoolParameter_DML	MC_WriteBoolParameter_DML Axis AXIS_REF_DML BOOL bDone bExecute BOOL BOOL bBusy diParameterNumber DINT BOOL bError bValue BOOL DML_ERROR ErrorId		
	ST expression			
MC_W	/riteBoolParameter_instance(
Axis :=	=,			
bExec	ute :=,			
diPara	meterNumber :=,			
bValue	bValue :=,			
bDone =>,				
bBusy =>,				
bError =>,				
ErrorI	ErrorID =>);			

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts to True.	BOOL	True/False (False)	-
diParameterNumber	Specify the number of the axis parameter.	DINT	Positive number, negative number or 0 (0)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.
bValue	Set a Boolean value of the parameter to write.	BOOL	True/False (False)	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the parameter writing is completed.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the parameter writing is completed. 	• When <i>bExecute</i> shifts from True to False.
bBusy	 When <i>bExecute</i> shifts to True and the instruction is executed. When parameter writing is in progress. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts to False.

Name	Timing for shifting to True	Timing for shifting to False
ErrorID	execution conditions or input values for the instruction.	(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- How to use MC_WriteBoolParameter_DML to write the number of an EtherCAT object dictionary
 - Use the SHL instruction to shift the data length of the object dictionary where a value is to be written to the left by 24 bits
 - Use the SHL instruction to shift the index of the object dictionary where a value is to be written to the left by 8 bits
 - Add up the above parameters and the sub-index.

See the reference formula as follows.

diParameterNumber :=-DWORD_TO_DINT (SHL (TO_DWORD (object dictionary data length), 24) + SHL (TO_DWORD (object dictionary index), 8) + object sub-index);

■ To write a value in an axis parameter, please refer to the axis parameter AXIS_REF_DML (FB) and fill in its number in the *diParameterNumber* input parameter.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_WriteParameter function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.10 MC_ReadBoolParameter_DML

MC_ReadBoolParameter_DML reads the Boolean value of a specified parameter.

FB/FC	Instruction	Graphic expression			
FB	MC_ReadBoolParameter_DML	MC_ReadBoolParameter_DML Axis AXIS_REF_DML BOOL bValid bEnable BOOL BOOL bBusy diParameterNumber DINT BOOL bError DML_ERROR ErrorId BOOL bValue			
		ST expression			
MC_R	eadBoolParameter_DML_instan	ice(
Axis :=	=,				
bEnab	le :=,				
diPara	meterNumber :=,				
bValid	bValid =>,				
bBusy =>,					
bError	bError =>,				
ErrorI	ErrorID =>,				
bValue	bValue =>);				

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bEnable	The instruction is executed when <i>bEnable</i> shifts to True.	BOOL	True/False (False)	-
diParameterNumber	Specify the number of the axis parameter.	DINT	Positive number, negative number or 0 (0)	When <i>bEnable</i> shifts to True.

Outputs

Name	Function	Data type	Output range (Default)
bValid	True when the read parameter value is available.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)
bValue	The read parameter value	BOOL	True/False (False)

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bValid	 When <i>bEnable</i> shifts to True. When the parameter to be read is available. 	 When <i>bEnable</i> shifts from True to False. When <i>bError</i> shifts to True.
bBusy	 When <i>bEnable</i> shifts to True and the instruction is executed. When the parameter to be read is available. 	 When <i>bEnable</i> shifts from True to False. When <i>bError</i> shifts to True.
bError	• When an error occurs in the	• When <i>bEnable</i> is False. (Error

Name	Timing for shifting to True	Timing for shifting to False
ErrorID	execution conditions or input values for the instruction.	code is cleared)
bValue	 Updates continuously when bValid is True. 	• Update stops when <i>bValid</i> is False.

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bEnable</i> changes to True.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- How to use MC_ReadBoolParameter_DML to read the number of an EtherCAT object dictionary.
 - Use the SHL instruction to shift the data length of the object dictionary to be read to the left by 24 bits
 - Use the SHL instruction to shift the index of the object dictionary to be read to the left by 8 bits
 - Add up the above parameters and the sub-index.

See the reference formula as follows.

- diParameterNumber := DWORD_TO_DINT (SHL (TO_DWORD (object dictionary data length), 24) + SHL (TO_DWORD (object dictionary index), 8) + object sub-index);
- To read an axis parameter value, please refer to the axis parameter AXIS_REF_DML (FB) and fill in its number in the *diParameterNumber* input parameter.

Chapter 2

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_ReadParameter function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.11 MC_WriteParameter_DML

MC_WriteParameter_DML writes a value in the specified parameter.

B/FC	Instruction	Graphic expression				
FB	MC_WriteParameter_DML	MC_WriteParameter_DML Axis AXIS_REF_DML BOOL bDone bExecute BOOL BOOL bBusy diParameterNumber DINT BOOL bError IrValue LREAL DML_ERROR ErrorId				
	ST expression					
MC_V	MC_WriteParameter_DML_instance(
Axis :	=,					
bExe	cute :=,					
diPara	diParameterNumber :=,					
IrValu	IrValue :=,					
bDon	bDone =>,					
bBusy =>,						
bErro	bError =>,					
Errorl	ErrorID =>);					

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts to True.	BOOL	True/False (False)	-
diParameter Number	Specify the number of the axis parameter.	DINT	Positive number, negative number or 0 (0)	When <i>bExecute</i> is True and bBusy is False.
IrValue	Set a parameter value to write.	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> is True and bBusy is False.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the parameter writing is completed.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When the parameter writing is completed. 	• When <i>bExecute</i> shifts from True to False.
bBusy	 When <i>bExecute</i> shifts to True and the instruction is executed. When parameter writing is in progress. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError	• When an error occurs in	• When <i>bExecute</i> shifts to False.

ErrorID or input values for the instruction.
--

• Timing Diagram

bExecute			
bDone			
bBusy			
bError			

In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- How to use MC_WriteParameter_DML to write the number of an EtherCAT object dictionary.
 - Use the SHL instruction to shift the data length of the object dictionary where a value is to be written to the left by 24 bits
 - Use the SHL instruction to shift the index of the object dictionary where a value is to be written to the left by 8 bits
 - Add up the above parameters and the sub-index.

See the reference formula as follows.

diParameterNumber :=-DWORD_TO_DINT (SHL (TO_DWORD (object dictionary data length), 24) + SHL (TO_DWORD (object dictionary index), 8) + object sub-index);

■ To write a value in an axis parameter, please refer to the axis parameter AXIS_REF_DML (FB) and fill in its number in the *diParameterNumber* input parameter.

• Troubleshooting

When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

Chapter 2

• Programming Example

- For the example, please refer to the programming example for MC_WriteParameter function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

■ AX-308E, AX-364E

2.3.3.12 MC_ReadParameter_DML

MC_ ReadParameter_DML reads the value of a specified parameter.

FB/FC	Instruction	Graphic expression			
FB	MC_ReadParameter_DML	MC_ReadParameter_DML Axis AXIS_REF_DML BOOL bValid bEnable BOOL BOOL BOOL bBusy diParameterNumber DINT BOOL bError DML_ERROR ErrorId LREAL IrValue			
ST expression					
MC_R	MC_ReadParameter_DML_instance(
Axis :=	Axis :=,				
bEnab	le :=,				
diPara	meterNumber :=,				
bValid	bValid =>,				
bBusy =>,					
bError =>,					
ErrorI	ErrorID =>,				
IrValue	IrValue =>);				

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bEnable	The instruction is executed when <i>bEnable</i>	BOOL	True/False (False)	-

Name	Function	Data type	Setting value (Default)	Timing for updating
	shifts to True.			
diParameterNumber	Specify the number of the axis parameter.	DINT	Positive number, negative number or 0 (0)	When bEnable shifts to True.

Outputs

Name	Function	Data type	Output range (Default)	
bValid	True when the read parameter value is available.	BOOL	True/False (False)	
bBusy	True when the instruction is executed.	BOOL	True/False (False)	
bError	True when an error occurs.	BOOL	True/False (False)	
ErrorID	Indicates the error code if an error occurs.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)	
IrValue The read parameter value		LREAL	Positive number, negative number or 0 (0)	

*Note: DML_ERROR: Enumeration (ENUM)

Name	Timing for shifting to True	Timing for shifting to False		
bValid	 When <i>bEnable</i> shifts to True. When the read parameter value is available. 	 When <i>bEnable</i> shifts from True to False. When <i>bError</i> shifts to True. 		
bBusy	 When <i>Enable</i> shifts to True and the instruction is executed. When the read parameter value is available. 	 When <i>bEnable</i> shifts from True to False. When <i>bError</i> shifts to True. 		
bError	When an error occurs in the execution conditions or input	• When <i>bEnable</i> is False. (Error		
ErrorID	values for the instruction.	code is cleared)		
IrValue	 Updates continuously when bValid is True. 	• Update stops when <i>bValid</i> is False.		

• Timing Diagram



*Note:

Data = Parameter values 1 cycle = One task cycle

In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bEnable</i> shifts to True.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- How to use MC_ReadParameter_DML to read the number of an EtherCAT object dictionary
 - Use the SHL instruction to shift the data length of the object dictionary to be read to the left by 24 bits
 - Use the SHL instruction to shift the index of the object dictionary to be read to the left by 8 bits
 - Add up the above parameters and the sub-index.

See the reference formula as follows.

- diParameterNumber := DWORD_TO_DINT (SHL (TO_DWORD (object dictionary data length), 24) + SHL (TO_DWORD (object dictionary index), 8) + object sub-index);
- To read an axis parameter, please refer to the axis parameter AXIS_REF_DML (FB) and fill in its number in the *diParameterNumber* input parameter.
• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_ReadParameter function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

■ AX-308E, AX-364E

2.3.3.13 MC_ReadStatus_DML

MC_	_ReadStatus_	_DML reads the	e state of a specified axis.	

FB/FC	Instruction	Graphic expression
FB	MC_ReadStatus_DML	MC_ReadStatus_DML Axis AXIS_REF_DML BOOL bValid bEnable BOOL BOOL BUSY BOOL bError DML_ERROR ErrorId BOOL bErrorStop BOOL bDisabled BOOL bStopping BOOL bStopping BOOL bHoming BOOL bStandstill BOOL bDiscreteMotion BOOL bContinuousMotion
		ST expression

FB/FC	Instruction	Graphic expression						
MC_R	MC_ReadStatus_DML_instance(
Axis :=	Axis :=,							
bEnab	le :=,							
bValid	=>,							
bBusy	=>,							
bError	=>,							
ErrorID) =>,							
bError	Stop=>,							
bDisab	oled=>,							
bStopp	oing=>,							
bHomi	ng=>,							
bStand	bStandStill=>,							
bDiscr	bDiscreteMotion=>,							
bConti	nuousMotion=>);							

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bEnable	The instruction is executed when <i>bEnable</i> shifts to True.	BOOL	True/False (False)	-

Outputs

Name Function		Data type	Output range (Default)
True when the axis bValid state at the output is available.		BOOL	True/False (False)
bBusy True when the instruction is executed.		BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.		DML_ERROR*1	DML_ERROR (DML_NO_ERROR)
bErrorStop To know details on		BOOL	True/False (False)

AX Series-Standard Instructions Manual

Name	Function	Data type	Output range (Default)	
bDisabled	the axis state	BOOL	True/False (False)	
bStopping	SML_AXIS_STATE.*2	BOOL	True/False (False)	
bHoming		BOOL	True/False (False)	
bStandStill		BOOL	True/False (False)	
bDiscreteMotion		BOOL	True/False (False)	
bContinuousMotion		BOOL	True/False (False)	

*Note:

DML_ERROR: Enumeration (ENUM)
 SML_AXIS_STATE: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bValid	 When <i>bEnable</i> shifts to True. When the axis state at the output is available. 	 When <i>bEnable</i> shifts from True to False. When <i>bError</i> shifts to True.
bBusy	• When <i>bEnable</i> shifts to True and the instruction is executed.	 When <i>bEnable</i> shifts from True to False. When <i>bError</i> shifts to True.
bError	When an error occurs in the avagution conditions or	• When hEnchle is Felee (Error
ErrorID	input values for the instruction.	code is cleared)
bDisabled	 When the axis is in Disabled state. 	 When the axis is not in Disabled state.
bErrorstop	 When the axis is in Errorstop state. 	 When the axis is not in Errorstop state.
bStopping	 When the axis is in Stopping state. 	 When the axis is not in Stopping state.
bStandStill	 When the axis is in StandStill state. 	 When the axis is not in StandStill state.
bDiscreteMotion	• When the axis is in Discrete Motion state.	When the axis is not in Discrete Motion state.
bContinuousMotion	When the axis is in Continuous Motion state.	When the axis is not in Continuous Motion state.
bHoming	• When the axis is in Homing state.	• When the axis is not in Homing state.

In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bEnable</i> shifts to True.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_ReadStatus function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.14 MC_TorqueControl_DML

 $\ensuremath{\mathsf{MC_TorqueControl_DML}}$ controls the torque by using the torque control mode of the applied servo drive.

FB/FC	Instruction	Graphic expression					
FB	DMC_TorqueControl	MC_TorqueControl_DML Axis AXIS_REF_DML BOOL bInTorque bExecute BOOL BOOL bBusy bContinuousUpdate BOOL BOOL bCommandAborted IrTorque LREAL BOOL bError dwTorqueRamp DWORD DML_ERROR ErrorId IrVelocity LREAL IrAcceleration LREAL IrDeceleration LREAL IrDeceleration BOOL Direction BOOL Direction BOOL					
	ST expression						
MC_To Axis := bExec bConti IrTorqu dwToro IrVeloc IrAcce IrDece IrJerk : Directi bInTor bBusy bCom bError ErrorIE	MC_TorqueControl_DML_instance(Axis :=, bExecute :=, bContinuousUpdate :=, IrTorque :=, dwTorqueRamp :=, IrVelocity :=, IrVelocity :=, IrAcceleration :=, IrDeceleration :=, IrJerk :=, Direction :=, bInTorque =>, bBusy =>, bCommandAborted =>, bError =>,						

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts from False to True.	BOOL	True/False (False)	-

AX Series-Standard Instructions Manual

Name	Function	Data type	Setting value (Default)	Timing for updating
bContinuousUpdate	Continuously updates the target torque when <i>Continuousupdate</i> is True.	BOOL	True/False (False)	When <i>bExecute</i> shifts to True and <i>Busy</i> is False.
IrTorque	Specify the target torque. (Unit: N.m)	LREAL	Positive number, negative number or 0 (0)	When <i>bExecute</i> shifts to True and <i>Busy</i> is False.
dwTorqueRamp	Specify the change rate of the torque from current torque to target torque. (Unit: ms)*	DWORD	Positive number (0)	When <i>bExecute</i> shifts to True and <i>Busy</i> is False.
IrVelocity	Specify the maximum velocity.	LREAL	Positive number (0)	When <i>bExecute</i> shifts to True and <i>Busy</i> is False.
IrAcceleration	Reserved	LREAL	-	-
IrDeceleration	Reserved	LREAL	-	-
lrJerk	Reserved	LREAL	-	-
Direction	Reserved	BOOL	-	-

*Note:

Here is ASDA-A2 as an example with the unit of microsecond. For other servo models, please refer to 0x6087 in the object dictionary.

• Outputs

Name Function		Data type	Output range (Default)
bInTorque	blnTorque True when the target torque is reached.		True/False (False)
bBusy True when the instruction is executed.		BOOL	True/False (False)
bCommandAborted	True when the instruction is aborted.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error	DML_ERROR [*]	DML_ERROR

AX Series-Standard Instructions Manual

Chapter 2

Name	Function	Data type	Output range (Default)
	code if an error occurs. Refer to Appendices for error code descriptions.		(DML_NoError)

***Note:** DML_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bInTorque	• When <i>bExecute</i> shifts to True and the axis state is available.	 When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True. When <i>bExecute</i> shifts to True again and <i>lrTorque</i> value changes.
bBusy	• When <i>bExecute</i> shifts to True and the instruction is executed.	 When <i>bError</i> shifts to True. When <i>bCommandAborted</i> shifts to True.
bCommandAborted	 When the instruction is aborted. 	 When <i>bExecute</i> shifts to False. If <i>bExecute</i> is False and <i>bCommandAborted</i> shifts to True, <i>bCommandAborted</i> will be True for one period and then immediately shift to False.
bError	• When an error occurs in the execution conditions or	When <i>bExecute</i> shifts to False
ErrorID	input values for the instruction.	(Error code is cleared)

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

Function

- When bExecute of the instruction shifts to True, the target torque (*IrTorque*), torque ramp (*dwTorqueRamp*) and maximum velocity (*IrVelocity*) will be sent to the servo for servo torque control.
- When bExecute is True, the instruction is executed for a velocity-constant motion according to the specified target velocity (*IrVelocity*), acceleration rate (*IrAcceleration*) and deceleration rate (*IrDeceleration*).
- The executing MC_TorqueControl_DML can be aborted by executing another motion instruction.
- When MC_TorqueControl_DML is aborted by another motion instruction, the output bInTorque will shift to False and the output bCommandAborted will shift to True.
- When bExecute of MC_TorqueControl_DML shifts to True, the axis starts to move according to the target velocity. Even if bExecute shifts to False, the instruction execution will not be affected.
- When bExecute of MC_TorqueControl_DML shifts to True again and a new IrTorque value is set, the torque of the axis is adjusted to the new torque value.
- When its *bExecute* shifts to False after the instruction is executed and the target torque is reached, *bInTorque* of MC_TorqueControl_DML shifts to True. Afterward, *bInTorque* will remain True until it is aborted by another instruction.
- When using C2000+ or CH2000 Series AC Motor Drives, it is necessary to configure 0x6064 (Position actual value) and 0x6077 (Torque actual value) to the Slave PDO (Process data) mapping data.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

- For the example, please refer to the programming example for MC_TorqueControl function block
- For *Axis* of the function block, please enter a positioning axis.

• Supported Products

AX-308E, AX-364E

2.3.3.15 MC_ChangeAxisConfig_DML

MC_ChangeAxisConfig_DML modifies basic axis settings including the ratio between user units and pulse number, axis type and user units per rotary axis rotation.

FB/FC	Instruction	Graphic expression	
FB	MC_ChangeAxisConfig_DML	MC_ChangeAxisConfig_DML Axis AXIS_REF_DML BOOL bDone bExecute BOOL BOOL bBusy dwRatioTechUnitsDenom DWORD BOOL bError iRatioTechUnitsNum DINT DML_ERROR ErrorId fModuloPeriodU LREAL IMOVEMENTTYPE	
	ST expression		
MC_ChangeAxisConfig_DML_instance(Axis :=, bExecute :=, dwRatioTechUnitsDenom :=, iRatioTechUnitsNum :=, fModuloPeriodU :=, fMovementType :=, bDone =>, bBusy =>,			
bError Errorl[bError =>, ErrorID =>);		

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updatin g
bExecute	The instruction is executed when <i>bExecute</i> shifts to True.	BOOL	True/False (False)	-
dwRatioTechUnitsDen om	Electronic gear ratio denominat or (Pulse	DWORD	Positive number or 0 (0)	When <i>bExecut</i> <i>e</i> shifts to True and

AX Series-Standard Instructions Manual

Name	Function	Data type	Setting value (Default)	Timing for updatin g
	number)			<i>bBusy</i> is False.
iRatioTechUnits Num	Electronic gear ratio numerator (User units)	DINT	Positive number, negative number or 0 (0)	When bExecut e shifts to True and bBusy is False.
fModuloPeriodU	Maximum position of the rotary axis	LREAL	Positive number, negative number or 0 (0)	When bExecut e shifts to True and bBusy is False.
fMovementType	Linear axis/rotary axis	SML_MOVEMENTTY PE	0: SML_MT_MODU LO 1: SML_MT_FINITE	When bExecut e shifts to True and bBusy is False.

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when the parameter writing is completed.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	• When the parameter writing is completed.	• When <i>bExecute</i> shifts from True to False.

AX Series-Standard Instructions Manual

Name	Timing for shifting to True	Timing for shifting to False
bBusy	 When <i>bExecute</i> shifts to True and the instruction is executed. When the parameter writing is in progress. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.
bError	• When an error occurs in the	• When <i>bExecute</i> shifts to False.
ErrorID	values for the instruction.	(Error code is cleared)

• Timing Diagram



• In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- MC_ChangeAxisConfig_DML can be used to modify basic axis settings including the ratio between user units and pulse number (electronic gear ratio), axis type and user units per rotary axis rotation.
- The axis state must be Disabled if this function block is used.
- After modification, the new axis settings cannot be retained when power off and so they will disappear after repowering or resetting. And the axis will still run based on the settings on the axis parameter page next time.

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Programming Example

■ This example explains how MC_ChangeAxisConfig_DML is used to modify axis parameters.



Set the gear ratio denominator and gear ratio numerator (10000: 360), maximum position of the rotary axis (360) and axis type (0). Change bRegulatorOn of MC_Power to False before MC_ChangeAxisConfig is executed.

• Supported Products

AX-308E, AX-364E

2.3.3.16 MC_ReinitDrive_DML

MC_ReinitDrive_DML reinitializes the specified axis.

FB/FC	Instruction	Graphic expression	
FB	MC_ReinitDrive_DML	MC_ReinitDrive_DML —Axis AXIS_REF_DML BOOL bDone bExecute BOOL BOOL bBusy BOOL bError DML_ERROR ErrorId	
	ST expression		

FB/FC	Instruction	Graphic expression	
MC_Re	MC_ReinitDrive_DML_instance(
Axis :=	,		
bExecu	bExecute :=,		
bDone =>,			
bBusy =>,			
bError =>,			
ErrorID) =>);		

Inputs

Name	Function	Data type	Setting value (Default)	Timing for updating
bExecute	The instruction is executed when <i>bExecute</i> shifts to True.	BOOL	True/False (False)	-

Outputs

Name	Function	Data type	Output range (Default)
bDone	True when initialization is completed.	BOOL	True/False (False)
bBusy	True when the instruction is executed.	BOOL	True/False (False)
bError	True when an error occurs.	BOOL	True/False (False)
ErrorID	Indicates the error code if an error occurs. Refer to Appendices for error code descriptions.	DML_ERROR*	DML_ERROR (DML_NO_ERROR)

*Note: DML_ERROR: Enumeration (ENUM)

Output Update Timing

Name	Timing for shifting to True	Timing for shifting to False
bDone	 When initialization is completed. 	• When <i>bExecute</i> shifts from True to False.
bBusy	 When <i>bExecute</i> shifts to True and the instruction is executed. When initialization is in progress. 	 When <i>bDone</i> shifts to True. When <i>bError</i> shifts to True.

bError	When an error occurs in the execution conditions or input	•	When <i>bExecute</i> shifts to False.
ErrorID	values for the instruction.		(Error code is cleared)

• Timing Diagram



In-Outs

Name	Function	Data type	Setting value	Timing for updating
Axis	Specify the axis	AXIS_REF_DML*	AXIS_REF_DML	When <i>bExecute</i> shifts to True and <i>bBusy</i> is False.

*Note:

AXIS_REF_DML (FB): The interface is built in every function block and works as the starting program of the function block.

• Function

- MC_ReinitDrive_DML is used to initialize the drive which has an error or is no longer in synchronization.
- Resetting the network cannot clear errors of the positioning axis itself, e.g. left and right limits, emergency stop and etc.
- The function block resets EtherCAT network of the positioning axis and keeps the servo in the previous servo state. Please refer to the following table for details.

Before the reset action	Resetting	After the reset action
Servo Off	Servo Off	Servo Off
Servo On	Servo Off	Servo On

• Troubleshooting

■ When an error occurs in the instruction execution, *bError* changes to True. To confirm current error state, see the error code in *ErrorID*.

• Supported Products

■ AX-308E, AX-364E

• Programing Example

This example use FC instruction (DFC_CMP) to do comparison between two variable values.

	1	PROGRAM PLC_PRG
8	2	VAR
	3	liVar0: LINT :=1000;
	4	liVar1: LINT :=2000;
	5	wVar0: WORD;
	6	END_VAR
	-	
	- 1	<pre>wVar0:=DFC_CMP(liSrc1:=liVar0 , liSrc2:=liVar1);</pre>
	2	

Since variable1 (liVar0) is smaller than variable2 (liVar1), the calculation result (wVar0) would be 2.

• Supported Products

- AX series
- Library
 - DL_Comparison.library

Appendix A

A.1.Instruction Tables and Indexes

A.1.1 By Function

• Single-axis Motion Control Instruction (Synchronous axes)

Categories	Name	Description
	MC_Home	MC_Home controls the axis to perform the homing operation.
	MC_Stop	MC_Stop decelerates an axis to a stop.
	MC_Halt	MC_Halt commands a controlled axis motion stop.
	MC_MoveAbsolute	MC_MoveAbsolute controls the axis to move to the specified absolute target position at a specified behavior.
	MC_MoveRelative	MC_MoveRelative controls the axis to move a specified relative distance with a specified behavior.
	MC_MoveAdditive	MC_MoveAdditive controls the axis to move an additional distance at a given speed and acceleration.
Positioning control	MC_MoveSuperimposed	MC_MoveSuperimposed controls the axis to move a relative superimposed distance at a specified behavior while the axis is moving.
	MC_PositionProfile	MC_PositionProfile commands a time-position locked motion profile.
	MC_Jog	MC_Jog enables an axis to be moved forward or backward.
	DMC_Home_P	DMC_Home_P, an application function block of pulse output, drives the pulse axis to perform the homing in the set mode.
	DMC_ImmediateStop_P	DMC_ImmediateStop_P can stop the PO axis motion immediately and stop the pulse output.
	DMC_MoveVelocityStopByPos	DMC_MoveVelocityStopByPos controls an axis to stop at a specified position after a period of motion.
	MC_MoveVelocity	MC_MoveVelocity performs velocity control on an axis in the position mode with a specified behavior and an average velocity.
Velocity control	MC_VelocityProfile	MC_VelocityProfile commands a time-position locked motion profile; however, its position points are defined by the velocity variables in MC_TV_REF.
	MC_AccelerationProfile	MC_AccelerationProfile commands a time-position locked motion profile; however, its position points are defined by acceleration variables in MC_TV_REF.
	DMC_VelocityControl	DMC_VelocityControl performs a velocity control on a specified axis in the CSV speed mode with the specified behavior and an average velocity.

AX- Series Motion controller Manual

Appendix A

Categories	Name	Description
Torque control	DMC_TorqueControl	DMC_TorqueControl controls the torque according to the torque control mode of the servo drive.
	MC_CamIn	MC_CamIn performs cam operation.
	MC_CamOut	MC_CamOut deactivates the coupling between master and slave axis.
	MC_GearIn	The function block MC_GearIn activates a linear master-slave coupling.
Sync control	MC_GearOut	MC_GearOut disconnects the gear relation (velocity) between master and slave axis.
	MC_GearInPos	MC_GearInPos commands position synchronization which is achieved over a defined region of travel for both master and slave axis.
	MC_Phasing	MC_Phasing specifies the phase shift value between the master and slave axis.
	MC_Power	MC_Power enables or disables the specific axis.
	MC_SetPosition	MC_SetPositionn changes the current position by shifting the coordinates of an axis.
	MC_ReadParameter	MC_ReadParameter reads a value of a specific axis parameter.
	MC_WriteParameter	MC_WriteParameter writes a value to a specific parameter.
	MC_ReadBoolParameter	MC_ReadBoolParameter reads the value of a specific Boolean parameter.
	MC_WriteBoolParameter	MC_WriteBoolParameter writes a Boolean value to a specific parameter.
Administrative	MC_ReadActualPosition	MC_ReadActualPosition reads the current axis position.
	MC_ReadActualVelocity	MC_ReadActualVelocity reads the actual axis velocity value.
	MC_ReadActualTorque	MC_ReadActualTorque reads the actual torque value of axis.
	MC_Reset	MC_Reset clears axis-related errors so that the error memory is available for new error messages.
	MC_ReadStatus	MC_ReadStatus reads the status of the specified axis.
	MC_ReadAxisError	MC_ReadAxisError reads the error information of axis.
	MC_CamTableSelect	MC_CamTableSelect selects the cam table for use with MC_CamIn.
	MC_TouchProbe	MC_TouchProbe records an axis position at the time when a trigger event occurs.

AX- Series Motion controller Manual

Categories	Name	Description
	MC_AbortTrigger	MC_AbortTrigger aborts the instruction MC_TouchProbe which are intended to capture trigger events.
	MC_DigitalCamSwitch	MC_DigitalCamSwitch uses the axis position to control a switch of a digital output.
	DMC_ChangeMechanism GearRation	DMC_ChangeMechanismGearRation modifies the ratio between user units and pulses, axis type and user units per rotation of the rotary axis.
	DMC_ReadMotionState	DMC_ReadMotionState reads the behavior state of the axis in motion.
	DMC_CamReadTappetStatus	DMC_CamReadTappetStatus reads the status of multiple tappets.
	DMC_CamReadTappetValue	DMC_CamReadTappetValue reads the data of one single tappet.
	DMC_CamWriteTappetValue	DMC_CamWriteTappetValue modifies the tappet data for the specified existing track.
	DMC_CamAddTappet	DMC_CamAddTappet adds a new tappet track at the end of the tappet table.
	DMC_CamDeleteTappet	DMC_CamDeleteTappet deletes the specified tappet track.
	DMC_CamReadPoint	DMC_CamReadPoint reads the data of one single cam point.
Administrative	DMC_CamWritePoint	DMC_CamWritePoint writes the data of one single cam point.
	DMC_AxesObserve	DMC_AxesObserve monitors the deviation between the master axis position and slave axis position and it will output a reminder when the deviation exceeds the allowed setting value.
	DMC_PositionLag	DMC_PositionLag sets the allowed range of lag error and observe whether the allowed position lag is exceeded
	DMC_SetTorqueLimit	DMC_SetTorqueLimit sets the maximum torque of an axis.
	DMC_SetSoftwareLimit	DMC_SetSoftwareLimit is used to enable, disable and set the upper and lower software limits
	DMC_CamKeyPointWrite	DMC_CamKeyPointWrite writes key cam points by selecting a curve type and generating corresponding cam curve based on related parameters. After the new cam curve is generated, the selected cam table will be changed accordingly.
	DMC_TouchProbeCyclically	DMC_TouchProbeCyclically can continuously record the captured position of an axis.

• Single-axis Motion Control Instruction (Positioning axes)

.

Categories	Name	Description
Positioning control	MC_Home_DML	MC_Home_DML controls the axis to perform the homing operation.
	MC_Stop_DML	MC_Stop_DML decelerates an axis to a stop.
	MC_Halt_DML	MC_Halt_DML commands a controlled axis motion stop.
Positioning	MC_MoveAbsolute_DML	MC_MoveAbsolute_DML controls the axis to move to the specified absolute target position at a specified behavior.
control	MC_MoveRelative_DML	MC_MoveRelative_DML controls the axis to move a specified relative distance with a specified behavior.
Velocity Control	MC_MoveVelocity_DML	MC_MoveVelocity_DML performs velocity control on an axis in the position mode with a specified behavior and an average velocity.
Torque Control	MC_TorqueControl_DML	MC_TorqueControl_DML controls the torque according to the torque control mode of the servo drive.
	MC_Power_DML	MC_Power_DML enables or disables the specific axis.
	MC_ReadParameter_DML	MC_ReadParameter_DML reads a value of a specific axis parameter.
	MC_WriteParameter_DML	MC_WriteParameter_DML writes a value to a specific parameter.
	MC_ReadBoolParameter_DML	MC_ReadBoolParameter_DML reads the value of a specific Boolean parameter.
Administrative	MC_WriteBoolParameter_DML	MC_WriteBoolParameter_DML writes a Boolean value to a specific parameter.
	MC_Reset_DML	MC_Reset_DML clears axis-related errors.
	MC_ReadStatus_DML	MC_ReadStatus_DML reads the status of the specified axis.
	MC_ChangeAxisConfig_DML	MC_ChangeAxisConfig_DML modifies basic axis settings including the ratio between user units and pulse number, axis type and user units per rotary axis rotation.
	MC_ReinitDrive_DML	MC_ReinitDrive_DML re-initializes the axis.

Multi-axis Motion Control Instruction

Categories	Name	Description
	DMC_MoveLinearAbsolute	DMC_MoveLinearAbsolute controls a specified axis group to perform the absolute linear interpolation for a specified absolute position.
	DMC_MoveLinearRelative	DMC_MoveLinearRelative controls a specified axis group to perform the relative linear interpolation.
	DMC_MoveCircularAbsolute	DMC_MoveCircularAbsolute controls the axis group to perform circular or helical interpolation for a specified absolute target position.
Group Motion	DMC_MoveCircularRelative	DMC_MoveCircularRelative controls the axis group to perform circular or helical interpolation for a specified relative target position.
	DMC_GroupStop	DMC_GroupStop decelerates the group axes to a stop.
	DMC_GroupHalt	DMC_GroupHalt decelerates the axis group in motion to a pause.
	DMC_GroupInterrupt	DMC_GroupInterrupt makes the current motion pause but not stop, and it can be used with DMC_GroupContinue to restore the motion.
	DMC_GroupContinue	DMC_GroupContinue restores the interrupted motion of DMC_GroupInterrupt.
	DMC_GroupEnable	DMC_GroupEnable switches the axis group state from GroupDisable to GroupStandby.
	DMC_GroupDisable	DMC_GroupDisable sets the state of an axis group to GroupDisable.
	DMC_GroupReadParameter	DMC_GroupReadParameter reads axis group parameter.
Administrative	DMC_GroupWriteParameter	DMC_GroupWriteParameter writes axis group parameter.
	DMC_GroupReadStatus	DMC_GroupReadStatus reads the state of an axis group.
	DMC_GroupReadError	DMC_GroupReadError reads axis group errors.
	DMC_GroupReset	DMC_GroupReset resets an axis group which is in GroupErrorstop state.

Appendix A

A.1.2 By Model

• The supported model types are listed as follows:

Eurotian Plack	Model Type		
Function block	AX-3	AX-8	
MC_Home	•		
MC_Stop	•		
MC_Halt	•		
MC_MoveAbsolute	•		
MC_MoveRelative	•		
MC_MoveAdditive	•		
MC_MoveSuperimposed	•		
MC_CamIn	•		
MC_CamOut	•		
MC_MoveVelocity	•		
MC_PositionProfile	•		
MC_VelocityProfile	•		
MC_AccelerationProfile	•		
MC_Jog	•		
MC_GearIn	•		
MC_GearOut	•		
MC_GearInPos	•		
MC_Phasing	•		
MC_Power	•		
MC_SetPosition	•		
MC_ReadParameter	•		
MC_WriteParameter	•		
MC_ReadBoolParameter	•		

AX-	Series	Motion	controller	Manual

	Model Type		
	AX-3	AX-8	
MC_WriteBoolParameter	•		
MC_ReadActualPosition	•		
MC_ReadActualVelocity	•		
MC_ReadActualTorque	•		
MC_Reset	•		
MC_ReadStatus	•		
MC_ReadAxisError	•		
MC_CamTableSelect	•		
MC_TouchProbe	•		
MC_AbortTrigger	•		
MC_DigitalCamSwitch	•		
MC_Home_DML	•		
MC_Stop_DML	•		
MC_Halt_DML	•		
MC_MoveAbsolute_DML	•		
MC_MoveRelative_DML	•		
MC_MoveVelocity_DML	•		
MC_TorqueControl_DML	•		
MC_Power_DML	•		
MC_ReadParameter_DML	•		
MC_WriteParameter_DML	•		
MC_ReadBoolParameter_DML	•		
MC_WriteBoolParameter_DML	•		
MC_Reset_DML	•		
MC_ReadStatus_DML	•		
MC_ChangeAxisConfig_DML	•		

AX-	Series	Motion	controller	Manual

	Model Type		
	AX-3	AX-8	
MC_ReinitDrive_DML	•		
DMC_MoveVelocityStopByPos	•		
DMC_TorqueControl	•		
DMC_VelocityControl	•		
DMC_MoveLinearAbsolute	•		
DMC_MoveLinearRelative	•		
DMC_MoveCircularAbsolute	•		
DMC_MoveCircularRelative	•		
DMC_GroupStop	•		
DMC_GroupHalt	•		
DMC_Home_P	•		
DMC_ImmediateStop_P	•		
DMC_GroupEnable	•		
DMC_GroupDisable	•		
DMC_GroupReadParameter	•		
DMC_GroupWriteParameter	•		
DMC_GroupReadStatus	•		
DMC_GroupReadError	•		
DMC_GroupReset	•		
DMC_GroupInterrupt	•		
DMC_GroupContinue	•		
DMC_CamReadTappetStatus	•		
DMC_CamReadTappetValue	•		
DMC_CamWriteTappetValue	•		
DMC_CamAddTappet	•		
DMC_CamDeleteTappet	•		

AX- Series Motion controller Manual

Appendix A

Function Plack	Model Type		
	AX-3	AX-8	
DMC_CamReadPoint	•		
DMC_CamWritePoint	•		
DMC_ChangeMechanismGearRation	•		
DMC_ReadMotionState	•		
DMC_AxesObserve	•		
DMC_PositionLag	•		
DMC_SetTorqueLimit	•		
DMC_SetSoftwareLimit	•		
DMC_CamKeyPointWrite	•		
DMC_TouchProbeCyclically	•		

A.1.3 By Letter

•	A	DMC_GroupInterrupt
	MC_AbortTrigger	DMC_GroupContinue
	MC_AccelerationProfile	DMC_GroupReadParameter
	DMC_AxesObserve	DMC_GroupWriteParameter
•	C •	Н
	MC_CamIn	MC_Halt
	MC_CamOut	MC_Halt_DML
	MC_CamTableSelect	MC_Home
	MC_ChangeAxisConfig_DML	MC_Home_DML
	DMC_CamAddTappet	DMC_Home_P
	DMC_CamDeleteTappet •	1
	DMC_CamReadPoint	DMC_ImmediateStop_P
	DMC_CamReadTappetStatus	J
	DMC_CamReadTappetValue	MC_Jog
	DMC_CamWritePoint	М
	DMC_CamWriteTappetValue	MC_MoveAbsolute
	DMC_ChangeMechanismGearRation	MC_MoveAbsolute_DML
	DMC_CamKeyPointWrite	MC_MoveAdditive
•	D	MC_MoveRelative
	MC_DigitalCamSwitch	MC_MoveRelative_DML
•	G	MC_MoveSuperimposed
	MC_GearIn	MC_MoveVelocity
	MC_GearInPos	MC_MoveVelocity_DML
	MC_GearOut	DMC_MoveCircularAbsolute
	DMC_GroupDisable	DMC_MoveCircularRelative
	DMC_GroupEnable	DMC_MoveLinearAbsolute
	DMC_GroupHalt	DMC_MoveLinearRelative
	DMC_GroupReadError	DMC_MoveVelocityStopByP
	DMC_GroupReadStatus	Р
	DMC_GroupReset	MC_Phasing
	DMC_GroupStop	MC_PositionProfile

os

MC_Power

 $\mathsf{MC}_\mathsf{Power}_\mathsf{DML}$

DMC_PositionLag

- R
 - MC_ReadActualPosition
 - MC_ReadActualTorque
 - MC_ReadActualVelocity
 - MC_ReadAxisError
 - MC_ReadBoolParameter
 - MC_ReadBoolParameter_DML
 - MC_ReadParameter
 - $\mathsf{MC_ReadParameter_DML}$
 - MC_ReadStatus
 - MC_ReadStatus_DML
 - MC_ReinitDrive_DML
 - MC_Reset
 - MC_Reset_DML
 - DMC_ReadMotionState
- S
 - MC_SetPosition

MC_Stop

MC_Stop_DML

DMC_SetTorqueLimit

- DMC_SetSoftwareLimit
- •

Т

- MC_TouchProbe MC_TorqueControl_DML DMC_TorqueControl DMC_TouchProbeCyclically
- V

MC_VelocityProfile DMC_VelocityControl W

MC_WriteBoolParameter

- MC_WriteBoolParameter_DML
- MC_WriteParameter
- MC_WriteParameter_DML
- MC_WriteBoolParameter

A.2 Data Type: Enumeration and Structure

• The data types listed below are Enumeration type:

Data Type	Value	Description	Applicable Function Block Instruction and its Interface
MC_SOURCE	0: mcCommandedValue 1: mcActualValue	0: The commanded value of instruction 1: The actual value of motion axis	Function block: DMC_ReadMotionStat e Interface: <i>Source</i>
MC_StartMode	0: absolute 1: relative 2: ramp_in 3: ramp_in_pos 4: ramp_in_neg	0: Absolute mode 1: Relative mode 2: Ramp in mode 3: Positive Ramp in 4: Negative Ramp in mode	Function block: MC_CamIn Interface: <i>StartMode</i>
SMC_CAM TAPPETTYPE	0: TAPPET_pos 1: TAPPET_all 2: TAPPET_neg	0: When pass in a positive direction1: When pass in both direction2: When pass in a negative direction	Function block: MC_Camln. Tappets.pTaps Interface: <i>ctt</i>
SMC_CAM TAPPET ACTION	0: TAPPETACTION_on 1: TAPPETACTION_off 2: TAPPETACTION_inv 3: TAPPETACTION_time	 0: Switches ON 1: Switches OFF 2: Inverts 3: Switches on after a delay for a certain time period. 	Function block: MC_CamIn. Tappets.pTaps Interface: <i>cta</i>
MC_TAPPET MODE	0: tp_mode_auto 1: tp_mode_demandposition 2: tp_mode_actualposition	0: Auto mode 1: Use set values 2: Use actual values	Function block: MC_DigitalCamSwitch Interface: <i>TappetMode</i>
DMC_BUFFER_MODE	0: aborting 1: buffered 2: blending_low 3: blending_previous 4: blending_next 5: blending_high	 0: Any ongoing motion is aborted. 1: Start FB after current move has finished. 2: The velocity is blended with lowest velocity of both FBs 3: The velocity is blended with the velocity of the first FB. 4: The velocity is blended with velocity of the second FB. 5: The velocity is blended with highest velocity of both FBs 	Function block: DMC_MoveLinearAbs olute DMC_MoveLinearRel ative DMC_MoveCircularAb solute DMC_MoveCircularRe lative DMC_GroupHalt Interface: BufferMode

Data Type	Value	Description	Applicable Function Block Instruction and its Interface
DMC_GROUP_TRANSITI ON_MODE	0: None 1: Overlap	0: The previous & next instructions follow BufferMode setting during blending, and there is no special transition mode. 1: The previous & next instructions do not follow BufferMode setting during blending, which makes the deceleration period of the previous instruction overlap the next instruction.	Function block: DMC_MoveLinearAbs olute DMC_MoveLinearRel ative DMC_MoveCircularAb solute DMC_MoveCircularRe lative Interface: TransitionMode
DMC_CIRC_ PLANE	0: XY_plane 1: YZ_plane 2: ZX_plane	 0: The circle is parallel to the XY plane. 1: The circle is parallel to the YZ plane. 2: The circle is parallel to the ZX plane. 	Function block: DMC_MoveCircularAb solute DMC_MoveCircularRe lative Interface: CircPlane
DMC_CIRC_ MODE	0: radius 1: center 2: border	 0: Defines radius of a circle. 1: Defines a center point of a circle. 2: Defines a point on the circle which is crossed on the path from the starting to the end point. 	Function block: DMC_MoveCircularAb solute DMC_MoveCircularRe lative Interface: CircMode
DMC_CIRC_ PATHCHOICE	0: CLOCKWISE 1: COUNTER_CLOCKWISE	0: Clockwise 1: Counterclockwise	Function block: DMC_MoveCircularAb solute DMC_MoveCircularRe lative Interface: PathChoice
DMC_GROUP_STATE	 0: GroupDisabled 1: GroupStandby 2: GroupMoving 3: GroupHoming 4: GroupStopping 5: GroupErrorstop 	 0: Group state is Disabled 1: Group state is Standby 2: Group state is Moving 3: Group state is Homing 4: Group state is Stopping 5: Group state is Errorstop 	Function block: DMC_AXIS_GROUP_ REF Interface: GroupState
DMC_GROUP_RAMP_TY PE	0: Trapezoid 1: S_Curve	 0: The velocity curve is trapezoidal. 1: The velocity curve is S Curve. 	Function block: DMC_AXIS_GROUP_ REF Interface: RampType

Data Type	Value	Description	Applicable Function Block Instruction and its Interface
DMC_GROUP_PARAM ETER	16: PARAM_RAMP_TYPE 17: PARAM_MAX_VELOCITY_LI MIT 18: PARAM_MAX_ACCELERATI ON_LIMIT 19: PARAM_MAX_DECELERATI ON_LIMIT 21: PARAM_PLANNING_PRIORI TY 22: PARAM_STOP_METHOD 23: PARAM_FB_VADJ_TARGET 24: PARAM_FB_VADJ_TARGET 24: PARAM_FB_VADJ_TARGET 24: PARAM_FB_VADJ_TARGET 25: PARAM_ACCELERATION_ WARNING_PERCENTAGE 26: PARAM_DECELERATION_ WARNING_PERCENTAGE 28: PARAM_RADIUS_CORREC TION_PERCENTAGE	 16: Velocity ramp type 17: Max. velocity limit 18: Limit on max. acceleration 19: Limit on max. deceleration 21: Priority items of velocity ramp planning 22: Stop method 23: Applied target of function block velocity/acceleration/ deceleration/jerk 24: Velocity warning range 25: Acceleration warning range 26: Deceleration warning range 28: Allowable correction range of radius 	Function block: DMC_GroupReadP arameter DMC_GroupWriteP arameter Pin: Parameter

• The data types listed below are Structure type:

Data Type	Function Block	Definition
AXIS_REF_SM3 [*]	Applied to MC_ / DMC_ function block.	This structure contains all the required data and parameters for axis motion.
DMC_AXIS_GROUP_REF*	Applied to DMC_Group function block.	This structure contains all the required data and parameters for group motion.
AXIS_REF_VIRTUAL_SM3	Applied to MC_ / DMC_ function block.	This structure contains all the required data and parameters for virtual axis motion.
TRIGGER_REF	MC_TouchProbe MC_AbortTrigger	 Includes the trigger information The specified trigger channel The trigger condition and the mode (Triggered on the rising or falling edge of the trigger signal.)
MC_CAM_REF	MC_CamTableSelect	This structure contains information of the CAM table and points.

*Note: Please refer to AX-3 Series operational manual for more details of structural type parameters.

A.3 Error Codes and Troubleshooting

A.3.1For Synchronous Axes

When an error occurs, you can troubleshoot errors through error codes and the corresponding indicators. Please refer to **AX-3 Operational Manual** for more details of troubleshooting process.

The following table lists the error codes and the contents of the errors:

Error code	Description	Contents	Corrective Action
0x000 00	SMC_NO_ERROR	No error messages.	
0x000 01	SMC_DI_GENERAL_ COMMUNICATION_ ERROR	Communication error.	Make sure the servo's network cable is properly plugged, then reset EtherCAT master and execute MC_Reset.
0x000 02	SMC_DI_AXIS_ERROR	Axis error.	Check the error information and troubleshoot the error according to each servo's user manual, then execute MC_Reset.
0x000 03	SMC_DI_FIELDBUS_ LOST_SYNCRONICITY	Loss of synchronicity.	Execute SMC3_ReinitDrive. If the error occurs frequently, please refer to Task max cycle time and increase EtherCAT DC time.
0x000 0A	SMC_DI_SWLIMITS_ EXCEEDED	Software limit errors.	Execute MC_Reset and run reversely away from the limit.
0x000 0B	SMC_DI_HWLIMITS_ EXCEEDED	Hardware limit errors.	Execute MC_Reset.
0x000 0C	SMC_DI_LINEAR_AXIS_ OUTOFRANGE	Incremental position of a linear axis is out of range.	Execute MC_Reset
0x000 0D	SMC_DI_HALT_OR_ QUICKSTOP_NOT_ SUPPORTED	Not support Halt or Quickstop state of drivers.	Execute MC_Reset
0x000 10	SMC_DI_ POSITIONLAGERROR	Excessive position error.	Execute MC_Reset
0x000 11	SMC_DI_HOMING_ ERROR	Homing error occurs.	Execute MC_Reset
0x000 14	SMC_REGULATOR_OR_ START_NOT_SET	The motion FB cannot be executed under the current axis state.	Enable the servo and execute MC_Reset, then re-execute the motion FB.
0x000 15	SMC_WRONG_ CONTROLLER_MODE	The axis is under wrong controller mode.	Execute SMC_SetControllerMode to switch the axis to the proper controller mode.
0x000 19	SMC_INVALID_ACTION_ FOR_LOGICAL	Invalid action for logical axes.	Do not perform improper operation to logical axes, such as powering on logical axes.
0x000 1E	SMC_FB_WASNT_ CALLED_DURING_ MOTION	Function blocks cannot be called	Please execute FBs in bus cycle task.

Error code	Description	Contents	Corrective Action
		in movement state.	
0x000 1F	SMC_AXIS_IS_NO_AXIS_REF	AXIS_REF variable type errors.	The pointer must points to the register.
0x000 20	SMC_AXIS_REF_ CHANGED_DURING_ OPERATION	AXIS_REF variables have been changed while the modules being activated.	Execute MC_Reset and do not change the axis input of the function block.
0x000 21	SMC_FB_ACTIVE_AXIS_ DISABLED	Execute servo off while axis is in motion.	Power on the servo and execute MC_Reset.
0x000 22	SMC_AXIS_NOT_READY_FOR_MOTION	The motion instruction cannot be executed under the current axis state.	As a result that the axis is not able to be controlled, please check if the state is power ON or an error exists, then enables the axis or execute MC_Reset depending on the situation.
0x000 23	SMC_AXIS_ERROR_ DURING_MOTION	Error occurs during motion.	Please refer to the servo user manual to check on the error information, then execute MC_Reset.
0x000 28	SMC_VD_MAX_ VELOCITY_EXCEEDED	Exceeds the maximum velocity limit fMaxVelocity.	Troubleshoots with MC_Reset.
0x000 29	SMC_VD_MAX_ ACCELERATION_ EXCEEDED	Exceeds the maximum acceleration limit fMaxAcceleration.	Troubleshoots with MC_Reset.
0x000 2A	SMC_VD_MAX_ DECELERATION_ EXCEEDED	Exceeds the maximum deceleration limit fMaxDeceleration.	Troubleshoots with MC_Reset.
0x000 32	SMC_3SH_INVALID_ VELACC_VALUES	Invalid setting values of velocity or acceleration.	Please insert the value of velocity or acceleration again and then re- execute the function block.
0x000 33	SMC_3SH_MODE_ NEEDS_HWLIMIT	The current mode needs the hardware limit to be activated.	blgnoreHWLimit should not be True in the current mode. Please select the proper mode.
0x000 46	SMC_SCM_NOT_ SUPPORTED	The mode is not supported.	Device does not support this mode, please re-select the proper mode then activate the function block.
0x000 47	SMC_SCM_AXIS_IN_ WRONG_STATE	The controller mode cannot be changed in the current state.	Use MC_Reset to troubleshoot the error.
0x000 48	SMC_SCM_ INTERRUPTED	SMC_SetControll erMode is interrupted by MC_Stop or errorstop.	Please reactivate the function block.

Error code	Description	Contents	Corrective Action
0x000 4B	SMC_ST_WRONG_ CONTROLLER_MODE	The axis is under the wrong controller mode.	Use MC_Reset to troubleshoot the error.
0x000 50	SMC_RAG_ERROR_ DURING_STARTUP	Error occurs when the axis group is activated.	Make sure the configuration is normal and re-execute SMC3_ReinitDrive.
0x000 51	SMC_RAG_ERROR_AXIS_NOT_INITIALIZED	The axis is not in the required state.	SMC3_ReinitDrive cannot be executed when EtherCAT Master is in Initial state.
0x000 55	SMC_PP_WRONG_AXIS_TYPE	Virtual axes or logical axes are not supported by the function block	SMC3_PersistPosition cannot be used on the virtual axis.
0x000 56	SMC_PP_NUMBER_OF_ ABSOLUTE_BITS_ INVALID	Invalid absolute bits, which must be within 8~32 bits.	The value input to usiNumberOfAbsoluteBits of SMC3_PersistPositionSingleturn is incorrect, please re-enter the value.
0x000 5A	SMC_CGR_ZERO_ VALUES	Invalid value.	Change the values of dwRatioTechUnitsDenomand to non-zero values and then re- execute the function block.
0x000 5B	SMC_CGR_DRIVE_ POWERED	The gear ratio parameters of the drive cannot be modified when it is under controlled.	Make the axis enter Disable state, then re-execute the function block.
0x000 5C	SMC_CGR_INVALID_ POSPERIOD	Invalid position period (less than or equal to 0, or exceeds half the width of the band)	When iMovementType = 0, fPositionPeriod is set to a value greater than zero and smaller than half the value of dwBusBandWidth.
0x000 5D	SMC_CGR_POSPERIOD_NOT_INTEGRAL	The increment of the period is not integral and the case of modulo values is completed by the drive.	After modifying the parameters of fPositionPeriod, re-execute the function block.
0x000 6E	SMC_P_FTASKCYCLE_ EMPTY	There's no cycle information in the axis.(fTaskCycle = 0)	Change the value of TaskCycle into a non-zero value.
0x000 78	SMC_R_NO_ERROR_TO_RESET	There's no errors after using MC_Reset.	Before execute the function block, check if there're any errors in the specified axis.
0x000 7A	SMC_R_ERROR_NOT_ RESETTABLE	The error is not resettable.	Before reactivate MC_Reset, please make sure all errors in the drive have been removed.
0x000 83	SMC_RP_REQUESTING_ERROR	Please check the error code output by the FB ReadDriveParam eter if an error occurs when attempts to	 The OD you're trying to access does not exist, please confirm the correct OD input. Adjust MAX_MAILBOX_CHANNELS and MAX_SDO_CHANNELS in IODrvEtherCAT to 128.

Error code	Description	Contents	Corrective Action
		communicate to the drive.	
0x000 84	SMC_RP_DRIVE_ PARAMETER_NOT_ MAPPED	The parameter is not mapped to a specific drive.	The parameter you're trying to access does not exist.
0x000 8D	SMC_WP_SENDING_ ERROR	Error code to the FB WriteDriveParame ter.	The OD you're writing does not exist, please confirm the correct OD input.
0x000 8E	SMC_WP_DRIVE_ PARAMETER_NOT_ MAPPED	Enter a parameter number of a non-existent axis.	The written parameter does not exist.
0x000 AA	SMC_H_AXIS_WASNT_ STANDSTILL	The axis is not in standstill state.	Re-execute the FB after the axis enters standstill state.
0x000 AB	SMC_H_AXIS_DIDNT_ START_HOMING	Errors occur while homing.	Before execute SMC3_ReinitDrive, please make sure the drive you're using is complied with standards and there's no existing error.
0x000 AC	SMC_H_AXIS_DIDNT_ ANSWER	The drive does not answer after the homing is completed.	Before execute SMC3_ReinitDrive, please make sure the drive you're using is complied with standards and there's no existing error.
0x000 AE	SMC_H_AXIS_IN_ ERRORSTOP	The homing mode cannot be executed as a result because the drive is in errorstop state.	Re-execute the FB after the axis leaving ErrorStop state.
0x000 B5	SMC_MS_INVALID_ ACCDEC_VALUES	Invalid setting value of velocity or acceleration.	Re-execute the FB after correcting the input value of "Deceleration".
0x000 B7	SMC_MS_AXIS_IN_ ERRORSTOP	Drive in operating state Errorstop.	Re-execute the FB after the axis leaving ErrorStop state.
0x000 B8	SMC_BLOCKING_MC_ STOP_WASNT_CALLED	Please set Execute to falling edge when the axis is locked and MC_Stop cannot be called.	Check the input setting of MC_Stop and re-execute the FB.
0x000 B9	SMC_MS_AXIS_ ALREADY_STOPPING	A stop cannot be aborted while executing MC_Stop.	Re-execute the FB after the axis leaving Stopping state.
0x000 C9	SMC_MA_INVALID_ VELACC_VALUES	Invalid values of velocity or acceleration.	Re-execute the FB after correcting the input values of "Velocity", "Acceleration", "Deceleration" and "Jerk".
0x000 E2	SMC_MR_INVALID_ VELACC_VALUES	Invalid values of velocity or acceleration.	Re-execute the FB after correcting the input values of "Velocity", "Acceleration", "Deceleration" and "Jerk".
0x000 FB	SMC_MAD_INVALID_ VELACC_VALUES	Invalid values of velocity or acceleration.	Re-execute the FB after correcting the input values of

Error code	Description	Contents	Corrective Action
			"VelocityDiff", "Acceleration", "Deceleration" and "Jerk".
0x001 14	SMC_MSI_INVALID_ VELACC_VALUES	Invalid values of velocity or acceleration.	Re-execute the FB after correcting the input values of "VelocityDiff", "Acceleration" and "Deceleration".
0x001 16	SMC_MSI_INVALID_ EXECUTION_ORDER	An error will occur if activates the second MC_MoveSuperi mposed while the first one is still being executed.	Re-execute the FB after the execution of first MC_MoveSuperimposed is completed.
0x001 2D	SMC_MV_INVALID_ ACCDEC_VALUES	Invalid values of velocity or acceleration.	Re-execute the FB after correcting the input values of "Velocity", "Acceleration", "Deceleration" and "Jerk".
0x001 2E	SMC_MV_DIRECTION_ NOT_APPLICABLE	Direction = shortest/fastest is not applicable.	After correcting the input value of "Direction" to be not in shortest / fastest state, re-execute the function block.
0x001 45	SMC_PP_ARRAYSIZE	Incorrect array size.	Please re-enter the correct ArraySize, then re-execute the function blocks.
0x001 46	SMC_PP_STEP0MS	Delta_time is not allowed to be set to 0.	Please re-enter the correct Delta_Time, then re-execute the function blocks.
0x001 5E	SMC_VP_ARRAYSIZE	Incorrect array size	Please re-enter the correct ArraySize, then re-execute the function blocks.
0x001 5F	SMC_VP_STEP0MS	Delta_time is not allowed to be set to 0.	Please re-enter the correct Delta_Time, then re-execute the function blocks.
0x001 77	SMC_AP_ARRAYSIZE	Incorrect array size.	Please re-enter the correct ArraySize, then re-execute the function blocks.
0x001 78	SMC_AP_STEP0MS	Delta_time is not allowed to be set to 0.	Please re-enter the correct Delta_Time, then re-execute the function blocks.
0x001 90	SMC_TP_ TRIGGEROCCUPIED	The trigger has been activated.	Correct TriggerInput.bActive back to False, then re-execute the function block.
0x001 91	SMC_TP_COULDNT_SET_WINDOW	The driver interface does not support Mask function.	The specified devices do not support Window functions, please turn off Window functions to re- execute the function block.
0x001 9A	SMC_AT_ TRIGGERNOTOCCUPIED	Triggering has been reset.	Check if MC_TouchProbe is executed and the axis position has not been captured then re- activate the function block.
0x001 AA	SMC_MCR_INVALID_ VELACC_VALUES	Invalid values of velocity or acceleration.	Correct the input value of "Velocity", "EndVelocity", "Deceleration" and "Jerk", then re-execute the function block.

Error code	Description	Contents	Corrective Action
0x001 C3	SMC_MCA_INVALID_ VELACC_VALUES	Invalid values of velocity or acceleration.	Correct the input value of "Velocity", "EndVelocity", "Deceleration" and "Jerk", then re-execute the function block.
0x001 C5	SMC_MCA_DIRECTION_ NOT_APPLICABLE	Cannot set the shortest distance.	After correcting the input value of "EndVelocityDirection" to be not in shortest / fastest state, re- execute the function block.
0x001 DB	SMC_SDL_INVALID_ AXIS_STATE	SMC_ChangeDyn amic Limits can only be called in standstill or power_off state.	Check if the axis is in power_off or standstill state and then re- activate the function block.
0x001 DC	SMC_SDL_INVALID_ VELACC_VALUES	Invalid values of velocity, acceleration, deceleration and jerk.	After fixing the input value if "fMaxVelocity", fMaxAcceleration", "fMaxDeceleration" and "fMaxJerk", re-execute the function block.
0x002 58	SMC_CR_NO_TAPPETS_ IN_CAM	There're no tappets set in the CAM.	Please set tappets in the cam table and then re-execute the function block.
0x002 59	SMC_CR_TOO_MANY_ TAPPETS	The number of tappet groupID exceeds MAX_NUM_TAPP ETS	As a result of too many tappets in the cam table, you have to modify the number before re-executing the function block.
0x002 71	SMC_CI_NO_CAM_ SELECTED	No cam is selected.	Please enter the correct value given by MC_CamTableSelect after it's successfully executed to the input "CamTableID" and then re-execute the function block.
0x002 72	SMC_CI_MASTER_OUT_ OF_SCALE	The master exceeds the valid scale.	 Execute MC_Reset to make the axis back to standstill state and check the inputs of MC_CamTableSelect. Make sure that the cam master position, which is calculated by "Periodic" /"MasterAbsolute" of MC_CamTableSelect and "MasterOffset" of MC_CamIn, is in the range of master scale on the cam table before you re-execute the function block.
0x002 73	SMC_CI_RAMPIN_ NEEDS_VELACC_ VALUES	The value of Velocity and acceleration must be set in the function of ramp_in.	 Execute MC_Reset to make the axis back to standstill state and check the StartMode input. When "StartMode" is set to "ramp_in"/ "ramp_in_pos"/"ramp_in_neg", the input values of "VelocityDiff"/"Acceleration"/ "Deceleration" need to be non- zero. Then you can re-execute the function block.
Error code	Description	Contents	Corrective Action
---------------	---------------------------------------	--	--
0x002 74	SMC_CI_SCALING_ INCORRECT	Scaling variables fEditor/TableMast erMin/Max are not correct	 Execute MC_Reset to make the axis back to standstill state and check the inputs. Make sure that the max values must be bigger than the min values in fEditor / fTable while using a cam table not in "XYVA" format. Then you can re-execute the function block.
0x002 75	SMC_CI_TOO_MANY_ TAPPETS_PER_CYCLE	Activate too many tappets in the same period.	Modify the tappets on the cam table and make sure that there're no too many tappets gathering on the same position. After download the cam table again, re-execute the function block.
0x002 80	SMC_CB_NOT_ IMPLEMENTED	The selected cam format is not executed.	Modify the cam table format to the one supported by the function block, then re-execute the function block.(Currently only support "XYVA" format)
0x002 A3	SMC_GI_RATIO_DENOM	RatioDenominator = 0	Change the value of "RatioDenominator" to be non- zero and re-execute the function block.
0x002 A4	SMC_GI_INVALID_ACC	Invalid value of acceleration.	 Execute MC_Reset to make the axis back to standstill state and check the inputs. Make sure the value of "Acceleration" is greater than zero, then re-execute the function block.
0x002 A5	SMC_GI_INVALID_DEC	Invalid value of deceleration.	 Execute MC_Reset to make the axis back to standstill state and check the inputs. Make sure the value of "Deceleration" is greater than zero, then re-execute the function block.
0x002 A6	SMC_GI_MASTER_ REGULATOR_CHANGED	The master state (Enable/Disable) is changed without the permission.	Execute MC_Reset to make the axis back to standstill state and re-execute the function block.
0x002 A7	SMC_GI_INVALID_JERK	Invalid jerk value.	 Execute MC_Reset to make the axis back to standstill state and check the inputs. Make sure the value of "Jerk" is greater than zero, then re- execute the function block.
0x002 D5	SMC_PH_INVALID_ VELACCDEC	Invalid values of velocity, acceleration and deceleration.	Make sure the values of "Velocity", "Acceleration" and "Deceleration" are non-zero before re-execute the function block.
0x002 EE	SMC_NO_CAM_REF_ TYPE	The chosen cam type is not MC_CAM_REF	Correct the input variable to the correct variable in "MC_CAM_REF" type.

Error code	Description	Contents	Corrective Action
0x002 EF	SMC_CAM_TABLE_ DOES_NOT_COVER_ MASTER_SCALE	The curve data does not include the master scale, xStart and xEnd, on the CamTable.	Correct the values of "xStart" and "xEnd" to make these two values are included in the master scale.
0x002 F0	SMC_CAM_TABLE_ EMPTY_MASTER_ RANGE	There's no master range on the cam table.	Fix the "xStart" and "xEnd" on the cam table to make the "xEnd" value greater than the value of "xStart".
0x002 F2	SMC_CAM_TABLE_ INVALID_SLAVE_ MINMAX	Invalid min/ max values of the slave axis on the cam table.	Make sure that the values of fTableSlaveMin and fTableSlaveMax are not equal before you re-execute the function block.
0x003 07	SMC_GIP_MASTER_ DIRECTION_CHANGE	The master axis changes its direction while being synchronizing with the slave axis.	Execute MC_Reset to make the axis back to standstill state and re-execute the FB. At the same time, do not reverse the master direction when "StartSync" is True.
0x003 08	SMC_GIP_SLAVE_ REVERSAL_CANNOT_BE_AVOIDED	AvoidReversal is set but cannot avoid the slave axis to be reversed.	Adjust the input values of "MasterSyncPosition", "SlaveSyncPosition" and "MasterStartDistance" as well as the velocity of master and slave axis after being coupled. Then re- execute the function block.
0x003 09	SMC_GIP_AVOID_ REVERSAL_FOR_ FINITE_AXIS	AvoidReversal cannot be configured while using linear axes.	Change the "Axis type" of slave to "Modulo"(Need to re- download) or set the input "AvoidReversal" to False, then re- execute the function block.
0x186 A0	DMC_TPC_INVALID_PDO_MAPPING	PDO mapping error.	Please do not configure Touch probe function (60B8h) in PDO.
0x186 A1	DMC_TPC_TRIGGER OCCUPIED	Trigger has been created.	Please do not execute the function block with MC_TouchProbe, which has been executed.
0x186 A2	DMC_TPC_ETC_CO_ FIRST_ERROR	SDO read-write error	Invalid SDO command, please check the related configuration.
0x186 A3	DMC_TPC_ETC_CO_ OTHER_ERROR	Communication error	Cannot find the corresponding master station, please check the master status first.
0x186 A4	DMC_TPC_ETC_CO_ DATA_OVERFLOW	Communication error	The size of SDO is too large to be sent. Please re-execute the FB after modification.
0x186 A5	DMC_TPC_ETC_CO_ TIMEOUT	Communication error	SDO time outs. Please check if there's a corresponding OD to the servo.
0x186 A8	DMC_TPC_ECAT_ MASTER_DISABLE	Communication error	Master initialization failed. Please check the status of the master station.
0x187 CC	DMC_CRTS_TAPPETID_ VALUE_OUTOFRANGE	The value of track ID of the tappet is set out of range.	Re-execute the FB after correcting Track ID.

Error code	Description	Contents	Corrective Action
0x187 D2	DMC_CRTV_TAPPETID_ VALUE_OUTOFRANGE	The value of track ID of the tappet is set out of range.	Re-execute the FB after correcting Track ID.
0x187 D3	DMC_CRTV_NO_ TAPPETID	The track ID to read does not exist.	Re-execute the FB after checking the tappet inputs.
0x187 D4	DMC_CRTV_NO_ TAPPETS_IN_CAM	There's no tappets set in the cam table.	Re-execute the FB after adding new tappets.
0x187 DA	DMC_CWTV_INVALID_ TAPPETID	Invalid Track ID.	Re-execute the FB after correcting Track ID.
0x187 DB	DMC_CWTV_INVALID_ MASTER_POS	Invalid master position.	Please correct the input of master position, then re-execute the FB.
0x187 DC	DMC_CWTV_CAM_ TABLE_NUM_EXCEED_ LIMIT	The number of cam table exceeds the limit.	The limit has been reached. Cannot write in more tappets.
0x187 DD	DMC_CWTV_TAPPETID_ NOT_FOUND	The track ID to modify does not exist.	Re-execute the FB after correcting Track ID.
0x187 DE	DMC_CWTV_TAPPET_ NUM_EXCEED_LIMIT	The number of tappets exceeds the limit.	Re-execute the FB after checking the tappet number.
0x187 DF	DMC_CWTV_INVALID_MODE	Tappet input is not an existed mode.	Correct the tappet mode and re- execute the FB.
0x187 E4	DMC_CAT_INVALID_ MASTER_POS	The user-defined master position is out of range.	Re-execute the FB after correcting the master position.
0x187 E5	DMC_CAT_CAM_TABLE_NUM_EXCEED_LIMIT	The number of cam table exceeds the limit.	The limit has been reached. Cannot write in more tappets.
0x187 E6	DMC_CAT_TAPPET_ NUM_EXCEED_LIMIT	The number of tappets exceeds the limit.	Re-execute the FB after checking the tappet number.
0x187 E7	DMC_CAT_NO_TAPPET_ TO_BE_ADDED	No tappet action set in the input variable.	There're no newly-added tappets in the input data. Please confirm that either PositiveMode or NegativeMode is not set to TAPPETACTION_none before re-execute the function block.
0x187 E8	DMC_CAT_INVALID_MODE	Tappet input is not an existed mode.	Correct the tappet mode and re- execute the FB.
0x187 ED	DMC_CDT_NO_ TAPPETS_IN_CAM	There's no tappet in the tappet table.	Re-execute the FB after specifying a tappet table which has tappets in it.
0x187 EE	DMC_CDT_CAM_TABLE_NUM_EXCEED_LIMIT	The number of cam table exceeds the limit.	The limit has been reached. Cannot write in more tappets.
0x187 F4	DMC_CRP_INVALID_ POINTNUM	Invalid point number.	Check if the point number of specified data is more than the point number of cam data. Re- execute the FB after modification.

Error code	Description	Contents	Corrective Action
0x187 FA	DMC_CWP_INVALID_ POINTNUM	Invalid point number.	Check if the point number of specified data is more than the point number of cam data. Re- execute the FB after modification.
0x187 FB	DMC_CWP_INVALID_ MASTERPOS	Invalid master position.	Please check if the master position of data point to be modified exceeds the master position of the front and back point. Re-execute the FB after modification.
0x188 01	DMC_TC_INVALID_VALUES	Invalid value	Confirm pin input parameter value. Re-execute the FB after modification.
0x188 02	DMC_TC_FB_CONFLICT	Function trigger repeat	FB DMC_TorqueControl is being executed, and only one FB DMC_TorqueControl is allowed to be executed at the same time.
0x188 03	DMC_TC_SDO_RW_FAIL	Wrong communication	SDO read & write failed. Reply to the servo communication, and execute this FB.
0x188 04	DMC_TC_SCM_NOT_SUPPORTED	Wrong PDO configuration	Confirm the slave OD setting. Need to open TargetTorque, ActualTorque, ModeOfOperation, and ModeOfOperationDisplay.
0x188 05	DMC_TC_SCM_AXIS_IN_WRONG_STATE	Axis at wrong state	Use MC_Reset to eliminate the error.
0x188 06	DMC_TC_SCM_INTERRUPTED	Function block execution error	Re-execute the function block.
0x188 07	DMC_TC_AXIS_NOT_READY_FOR_MOTION	Axis state error	Power on servo and re-execute the function block.
0x188 08	DMC_TC_REGULATOR_OR_START_NOT_SET	The axis state cannot execute motion control instruction.	After starting servo, execute MC_Reset, and re-execute motion function block.
0x188 09	DMC_TC_INVALID_PDO_MAPPING	Slave does not configure the related OD on PDO.	Confirm PDO configuration
0x188 11	DMC_VC_SCM_NOT_SUPPORTED	Slave does not configure the related OD on PDO.	Confirm the slave OD setting. Need to open TargetVelocity, ActualVelocity, ModeOfOperation, and ModeOfOperationDisplay.
0x188 12	DMC_VC_SCM_AXIS_IN_WRONG_STATE	Axis at wrong state	Use MC_Reset to eliminate the error.
0x188 13	DMC_VC_SCM_INTERRUPTED	Wrong function block execution	Re-execute the function block.

Error code	Description	Contents	Corrective Action
0x188 14	DMC_VC_INVALID_ACCDEC_VALUES	Wrong value	Confirm pin input parameter value. Re-execute the FB after modification.
0x188 15	DMC_VC_DIRECTION_NOT_APPLICABLE	Wrong value	Confirm pin input parameter value. Re-execute the FB after modification.
0x188 16	DMC_VC_AXIS_NOT_READY_FOR_MOTION	Wrong axis state	Power on servo, and re-execute the function block.
0x188 17	DMC_VC_AXIS_ERROR_DURING_MOTION	Axis error	Confirm servo error information. Refer to Servo manual for error elimination, and execute MC_Reset.
0x188 18	DMC_VC_REGULATOR_OR_START_NOT_SET	Axis error	Power on servo, execute MC_Rest, and re-execute motion function block.
0x188 19	DMC_VC_WRONG_CONTROLLER_MODE	Axis is in the wrong controller mode.	Function block does not support execution in the current mode. To execute this function block, execute SMC_SetControllerMode first to switch the axis to the appropriate mode.
0x188 1A	DMC_VC_INVALID_PDO_MAPPING	Slave does not configure the related OD to PDO.	Confirm PDO configuration.
0x188 1B	DMC_CMGR_ZERO_VALUES	Wrong value	After modifying udiInputRotation, udiPulsePerRotation, udiOutputRotation, and udiUnitsPerRotation to non-zero values, re-execute the function block.
0x188 1C	DMC_CMGR_DRIVE_POWERED	Wrong axis state	After making the axis state goes into Disable, re-execute the function block.
0x188 1D	DMC_CMGR_INVALID_POSPERIOD	Wrong value	When setting iMovementType = 0, set fPositionPeriod to a value greater than 0 and less than half of dwBusBandWidth. Then, re- execute the function block.
0x188 1E	DMC_CMGR_POSPERIOD_NOT_INTEGRAL	Wrong value	After correcting fPositionPeriod parameter, re-execute the function block.
0x188 1F	DMC_CMGR_RAG_ERROR_DURING_STARTUP	Communication error	Confirm if the bus configuration is normal, and re-execute DMC_ChangeMechanismGearRa tion.
0x188 20	DMC_CMGR_RAG_ERROR_AXIS_NOT_INITIALIZED	Axis initializing	EtherCAT Master cannot execute DMC_ChangeMechanismGearRa tion during Initialization.
0x188 2E	DMC_GM_NO_ERROR_ TO_RESET	There's no error to be reset.	Re-execute DMC_GroupReset when an error occurs in the axis group.

Error code	Description	Contents	Corrective Action
0x188 2F	DMC_GM_DRIVE_ DOESNT_ANSWER	One or more axes in the group does not execute the reset action.	After the communication status of the axis is back to normal, re- execute the FB. (DFB_ResetECATMaster/DFB_R esetECATSlave)
0x188 30	DMC_GM_ERROR_NOT_RESETTABLE	Error is not resettable.	Remove the error in axis group (Modify parameter settings/ check on a normal axis path) before download the program once again.
0x188 31	DMC_GM_DRIVE_ DOESNT_ANSWER_IN_ TIME	Communication timeout	After the communication status of the axis is back to normal (DFB_ResetECATMaster/DFB_R esetECATSlave), re-execute the FB.
0x188 32	DMC_GM_CANNOT_ RESET_ COMMUNICATION_ ERROR	Communication error cannot be reset.	After the communication status of the axis is back to normal (DFB_ResetECATMaster/DFB_R esetECATSlave), re-execute the FB.
0x188 33	DMC_GM_AXIS_GROUP_RESET_FAILED	Fail to reset the axis group.	Remove the error in axis group (Modify parameter settings/ check on a normal axis path) before download the program once again.
0x188 39	DMC_GM_LINEAR_AXIS_MAPPING_ERROR	Command a non- zero displacement to an axis, which does not exist.	Execute MC_GroupReset to make the axis group back to GroupStandby state. Then check the parameter setting and the input position of axis group so as to make sure the existing displacement has been mapped to an appointed axis.
0x188 3F	DMC_GM_CIRCULAR_ AXIS_MAPPING_ERROR	Command a non- zero displacement to an axis, which does not exist, in a circular movement.	Execute MC_GroupReset to make the axis group back to GroupStandby state. Then check the parameter setting and the input position of axis group so as to make sure the existing displacement has been mapped to an appointed axis.
0x188 40	DMC_GM_HELIX_AXIS_ MAPPING_ERROR	Command a non- zero displacement to an axis, which does not exist, in a helical movement.	Execute MC_GroupReset to make the axis group back to GroupStandby state. Then check the parameter setting and the input position of axis group so as to make sure the existing displacement has been mapped to an appointed axis.
0x188 41	DMC_GM_CIRCLE_ DISTANCE_LARGER_ THAN_DIAMETER	Under the DMC_CIRC_MOD E. radius mode, the distance between the start and end point is larger than the diameter.	 Execute MC_GroupReset to make the group state back to GroupStandby. While using DMC_CIRC_MODE.radius, the input value of radius must be larger than half of the distance between the start and end point. Re-execute the function block.

Error code	Description	Contents	Corrective Action
0x188 42	DMC_GM_CIRCLE_ START_AND_ENDPOINT_EQUAL	Under DMC_CIRC_MOD E. radius / DMC_CIRC_ MODE.border mode, the start point and the end point are at the same position.	 Execute MC_GroupReset to make the group state back to GroupStandby. While using DMC_CIRC_MODE.radius / DMC_CIRC_MODE.border the input value of radius must be larger than half of the distance between the start and end point. Re-execute the function block.
0x188 43	DMC_GM_CIRCLE_ COLLINEAR_POINTS	Under DMC_CIRC_MOD E. border mode, three points are defined to lie on a same line.	 Execute MC_GroupReset to make the group state back to GroupStandby. While using DMC_CIRC_MODE.border, start point, end point and assist point should not be set on the same line. Re-execute the function block.
0x188 44	DMC_GM_CIRCLE_ CENTER_NOT_ON_ BISECTOR	Under DMC_CIRC_MOD E. center mode, the center of a circle is not on the bisector line.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure that the center must locates on the bisector line between the start and end point. Re-execute the function block.
0x188 45	DMC_GM_CIRCLE_ RADIUS_ZERO	Under DMC_CIRC_MOD E. radius mode, the radius is zero.	 Make sure the radius is not 0 while using DMC_CIRC_MODE.radius mode. Re-execute the function block.
0x188 4B	DMC_GM_CONTINUE_ WRONG_POSITION	The current position is not the start position recorded in continue data.	 Move the axis group to the position recorded in Continue Data. (DMC_AXIS_GROUP_REF.C ontinuePos) Re-execute the function block.
0x188 4C	DMC_GM_CONTINUE_ DATA_NOT_WRITTEN	ContinueData is not written.	After confirming there's Continue Data in the axis group (DMC_AXIS_GROUP_REF.bCon tinueDataWriten), then execute DMC_GroupContinue.
0x188 52	DMC_GM_NO_AXIS_IN_ AXIS_GROUP	There're no axes in the axis group.	At least one axis must be specified in the parameter setting of axis group before re-execute the function block.
0x188 53	DMC_GM_SINGLE_AXIS_ERROR	Axis error occurs in the axis group.	 After troubleshoot the error, execute MC_GroupReset to make the group state back to

Error code	Description	Contents	Corrective Action
			GroupStandby, while each axis leaves errorstop state. 2. Re-execute the function block.
0x188 54	DMC_GM_AXIS_NOT_ READY_FOR_MOTION	One or more axes in the group are not ready for motion.	 Execute MC_GroupReset to make the group state back to GroupStandby, while each axis leaves errorstop state. Make sure that each axis has been successfully powered on and entered standstill state. Re-execute the function block.
0x188 55	DMC_GM_AXIS_LIMIT_ VIOLATED	One or more limits for an axis are violated.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure that the position, velocity, acceleration and jerk of each axis do not exceed the limits. Re-execute the function block.
0x188 56	DMC_GM_AXIS_GROUP_WRONG_STATE	Axis group is in wrong state.	Make sure the axis group is under the proper state and ready to be executed before execute the function block.
0x188 57	DMC_GM_AXIS_GROUP_AXIS_IN_DIFFERENT_ TASK	Some axes in the group and the axis group itself are not in the same task.	Correct the settings of the axis and the group so as to make both bus cycle tasks are appointed to the same task
0x188 58	DMC_GM_INVALID_VEL_ACC_DEC_JERK	Invalid values of velocity, acceleration, deceleration and jerk.	 Adjust the values to be reasonable and non-zero. Re-execute the function block.
0x188 59	DMC_GM_INVALID_ BUFFER_MODE	Invalid buffer mode.	 Change to a supported buffer mode. Re-execute the function block.
0x188 5A	DMC_GM_CMD_ ABORTED_DUE_TO_ ERROR	Command is aborted due to an error.	 Troubleshoot the error. Execute MC_GroupReset to make the group state back to GroupStandby. Re-execute the function block.
0x188 5B	DMC_GM_ TRANSITIONING_FROM_ SINGLE_AXIS_ MOVEMENT_NOT_ SUPPORTED	Transitioning from the single-axis movement is not supported.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure each axis is back to standstill. Re-execute the function block.
0x188 5C	DMC_GM_AXIS_GROUP_VELOCITY_EXCEED_ LIMIT	The velocity of axis group exceeds the limit set in the parameter setting.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure the group velocity does not exceed the limit set in the parameter setting. Re-execute the function block.

Error code	Description	Contents	Corrective Action
0x188 5D	DMC_GM_AXIS_GROUP_ACCELERATION_ EXCEED_LIMIT	The acceleration of axis group exceeds the limit set in the parameter setting.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure the group acceleration does not exceed the limit set in the parameter setting. Re-execute the function block.
0x188 5E	DMC_GM_AXIS_GROUP_DECELERATION_ EXCEED_LIMIT	The deceleration of axis group exceeds the limit set in the parameter setting.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure the group deceleration does not exceed the limit set in the parameter setting. Re-execute the function block.
0x188 5F	DMC_GM_AXIS_GROUP_JERK_EXCEED_LIMIT	The jerk of axis group exceeds the limit set in the parameter setting.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure the group jerk does not exceed the limit set in the parameter setting. Re-execute the function block.
0x188 60	DMC_GM_AXIS_GROUP_PLANNING_ERROR	Axis group planning error.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure the parameters set for the motion instruction are reasonable for planning paths. Re-execute the function block.
0x188 61	DMC_GM_AXIS_GROUP_MOVE_ERROR	Axis group move error.	 Execute MC_GroupReset to make the group state back to GroupStandby. Make sure the parameters set for the motion instruction are reasonable for planning paths. Re-execute the function block.
0x188 62	DMC_GM_CMD_BUF_ FULL	Command buffer is full.	 Make sure there's still some space in the command buffer. Re-execute the function block.
0x188 81	DMC_GM_AXIS_GROUP_INIT_FAILED	Axis group initialization failed.	 Please use the axis group in the device tree as the input to the instruction. Re-execute the function block.

Error code	Description	Contents	Corrective Action
0x188 82	DMC_GM_INVALID_AXIS_IN_AXIS_GROUP	Invalid axes in axis group.	 Make sure all the axes specified in the parameter setting exist in the device tree. Download the program again. Re-execute the function block.
0x188 83	DMC_GM_DUPLICATE_ AXIS_IN_AXIS_GROUP	Duplicated axes in axis group.	 Make sure there's no duplicated axis specified in the parameter setting. Download the program again. Re-execute the function block.
0x188 84	DMC_GM_AXIS_ ALREADY_IN_OTHER_ ENABLED_AXIS_GROUP	Some axes have been already existed in another enabled axis group.	 Make sure the specified axis does not exist in other enabled axis group or disable the axis group which has the axis in it. Re-execute the function block.
0x188 85	DMC_GM_AXIS_GROUP_INVALID_TASK_ CONFIGURATION	Task is not configured correctly.	 Make sure that the setting values of bus cycle task meet the requirement. (Type: Cyclic, Interval:> 1ms) Download the program again. Re-execute the function block.
0x188 86	DMC_GM_AXIS_GROUP_COUNT_REACH_LIMIT	The axis group count has reached the limit.	 To activate more groups, please make sure the number of activated axis group is less than the max.value. Re-execute the function block.
0x18 890	DMC_GM_AXIS_GROUP_INVALID_PARAMETER	Invalid axis group parameter	After confirming that Parameter input pin has correct readable and writable parameters, re- execute the function block.
0x18 891	DMC_GM_AXIS_GROUP_CANT_WRITE_PARAMETER_ DURING_GROUP_ENABLED	Cannot modify parameter during the axis group is enabled.	After using DMC_GroupDisable to disable this axis group, re-execute the function block.
0x18 892	DMC_GM_AXIS_GROUP_INVALID_PARAMETER_SETT ING	Invalid axis group parameter	After confirming that IrValue input pin has correct parameter setting value, re-execute the function block.
0x188 B5	DMC_CKPW_WRITE AMOUNT_OUTOFRANGE	WriteAmount input error	Check and correct the input value of WriteAmount before execute the function block.
0x188 B6	DMC_CKPW_INVALID_ MASTERPOS	Invalid master position.	Re-execute the FB after correcting the input of master position.
0x188 B7	DMC_CKPW_INVALID_ ACC	Invalid acceleration.	Re-execute the FB after correcting the acceleration input value of master position.
0x188 B8	DMC_CKPW_INVALID_ ACC_SETTING	Invalid acceleration setting.	Re-execute the FB after determining the velocity, acceleration and curve type.

Error code	Description	Contents	Corrective Action
0x188 B9	DMC_CKPW_INVALID_ CURVE_TYPE_SETTING	Invalid curve type setting.	The input curve type is not supported. Re-execute the FB after correcting the curve type.
0x188 BA	DMC_CKPW_SPLINE_ HAS_NO_BOUNDARY	Spine has no boundary.	Make sure there's boundary condition (Nature or Clamp) set for the previous and the latter part of the selected curve "Spline", which the condition should be the same at the start and end of the boundary. Then re-execute the FB.
0x188 BB	DMC_CKPW_CAM_IS_ WRITING_BY_OTHER_ FUNCTION	Failure to write CAM.	Check if the cam table you're currently using is being written by other FBs, then wait for the writing completed before you re- execute the FB.
0x188 C5	DMC_HP_INVALID_ HOME_SPEED	Invalid home speed value.	Please set "Search for switch" and "Search for Z phase pulse" with non-zero values for the home speed setting on Pulse Axis configuration page.
0x188 C6	DMC_HP_INVALID_ HOME_ACC_DEC	Invalid home acceleration or deceleration value.	Please set the homing acceleration and deceleration with non-zero values on Pulse Axis configuration page.
0x188 C7	DMC_HP_INVALID_ HOME_POSITION	Invalid setting value of home position.	Set "IrPosiotion" to be in the rotary range of pulse axis. [0 ~ PulseAxis.Modulo Value]
0x188 C8	DMC_HP_AXIS_NOT_ PULSEAXIS	The input variable type is not set to be PulseAxis_REF.	After select "Pulse Axis" in IO Configuration, enter the IEC Object variable to the input "Axis" of FB DMC_Home_P.
0x188 C9	DMC_HP_HOMING_ METHOD_RESERVED	Homing method is not supported by current version.	Check if the homing method is supported by the version you're currently using. Please refer to the specification document for mode modification.
0x188 CA	DMC_HP_HOMING_ MOVEMENT_HW_LIMIT	Positive or negative limit signal is activated and axis cannot perform homing in this circumstances.	Check if the hardware limit signal you're using is supported by the current homing mode. Please refer to the specification document for changing the mode and hardware limit signal configuration.
0x188 CB	DMC_HP_HOMING_AXIS_STATE_NOT_STAND STILL	Axis state is not Standstill.	Confirm that DMC_Home_P is executed when the axis state is Standstill.
0x18 8D5	DMC_ISP_AXIS_NOT_READY_FOR_MOTION	Wrong axis state	Power on servo and re-execute the function block.
0x18 8D6	DMC_ISP_WRONG_CONTROLLER_MODE	Wrong axis state	Switch the control mode to SMC_position, and re-execute the function block.

Error code	Description	Contents	Corrective Action
0x189 6C	DMC_STL_WP_PARAM_ INVALID	Invalid parameter.	The input parameter is too large. Re-execute the FB after correcting the input parameter.
0x189 6D	DMC_STL_WP_SENDING_ERROR	No corresponding OD or the OD is not allowed to be written.	No such error should occur while matching ASDA-A2-E to use. Please check if the servo you're currently using meets Cia402, or the function block cannot be executed.
0x189 6E	DMC_STL_WP_DRIVE_ PARAMETER_NOT_ MAPPED	The input parameter number does not exist.	No such error should occur while matching ASDA-A2-E to use. Please check if the servo you're currently using meets Cia402, or the function block cannot be executed.
0x189 6F	DMC_STL_WP_PARAM_CONVERSION_ERROR	Parameter conversion error.	No such error should occur while matching ASDA-A2-E to use. Please check if the servo you're currently using meets Cia402, or the function block cannot be executed.
0x189 7A	DMC_SSWL_LIMIT_ SETTING_OPPOSITE	Negative limit input error.	Negative software limit is greater than positive software limit. Please correct the input limit before you re-execute the FB.
0x189 7B	DMC_SSWL_NEGPOS_ LIMT_EQUAL	Negative limit input error.	Negative software limit is equal to positive software limit. Please correct the input limit before you re-execute the FB.
0x189 8A	DMC_PL_INVALID_ POSITIONLAG	Invalid MaxPositionLag input.	The input value of fMaxPositionLag is negative, please correct the value before re-execute the FB.
0x189 8B	DMC_PL_INVALID_ LAGCYCIES	Invalid SetActTimeLagCy cles input.	The input value of SetActTimeLagCycles is negative, please correct the value before re-execute the FB.
0x189 96	DMC_MVSBP_INVALID_DIRECTION	Invalid direction.	Only positive and negative direction are allowed, please correct the direction of movement before re-execute the FB.
0x189 97	DMC_MVSBP_INVALID_PHASE	Invalid phase input.	RoundPhase/ StopPhase input error. Please correct the input parameters before re-execute the FB.
0x189 98	DMC_MVSBP_AXIS_NOT_READY_FOR_MOTION	Slave axis is not ready for motion.	The slave is not under control. Please check if the target axis is powered on or in error, then enable the axis or execute MC_Reset depending on the situation.

Error code	Description	Contents	Corrective Action
0x189 99	DMC_MVSBP_AXIS_ ERROR_DURING_ MOTION	Errors occur during motion.	Please check the error information. Refer to the corresponding servo's user manual to troubleshoot the error and execute MC_Reset.
0x189 9A	DMC_MVSBP_ REGULATOR_OR_ START_NOT_SET	The motion control instruction cannot be executed under the current axis state.	After activating the servo, execute MC_Reset before re-execute the FB.
0x18 99B	DMC_MVSBP_INVALID_ACCDEC_VALUES	Invalid velocity, acceleration, deceleration, and jerk	After correcting the parameter, re-execute the function block.
0x18 9A5	DMC_AO_INVALID_REFERENCE_TYPE	Invalid reference type	Wrong reference type. Correct the reference type and re-execute the function block.

A.3.2 For Positioning Axis

When an error occurs, you can troubleshoot errors through error codes and the corresponding indicators. Please refer to **AX-3 Operational Manual** for more details of troubleshooting process.

The following table lists the error codes and the contents of the errors:

Error code	Description	Contents	Corrective Action
0x000000	SML_NO_ERROR	No error messages	-
0x000001	SML_DI_GENERAL_COMMUNICATION_ERROR	Communication error	Confirm if the Slave network cable is properly plugged. Execute DFB_ResetECATMaster to reset EtherCAT Master, and then re-execute MC_ReinitDrive_DML.
0x000002	SML_DI_AXIS_ERROR	Axis error	Confirm Slave error information and eliminate the error, and then re- execute MC_Reset_DML.
0x000015	SML_WRONG_OPMODE	Wrong control mode	Function block does not support execution in the current mode. To execute this function block, execute SMC_SetControllerMode first to switch the axis to the appropriate mode.
0x000022	SML_AXIS_NOT_READY_FOR_MOTION	The Slave state cannot execute the motion control instruction.	Axis is at the state that cannot be controlled. Please confirm whether it is at the Power on or error state. Start the axis or execute MC_Reset_DML depending on the situation.
0x000023	SML_MA_MR_MODULO_ACT_POS_NOT_MAPPED	PDO lacks the essential parameter.	Configure Actual Position (16#6064) to PDO.

Error code	Description	Contents	Corrective Action
0x000024	SML_MV_INVALID_VELACCDEC_VALUES	Invalid velocity or acceleration/deceleration setting value	Use MC_Reset_DML to eliminate error
0x000050	SMC_RAG_ERROR_DURING_STARTUP	Error occurs during axis re-startup	Confirm if the bus configuration is normal, and re-execute MC_ReinitDrive_DML.
0x00005A	SML_CGR_ZERO_VALUES	Cannot enter 0 for dwRatioTechUnitsDenom and iRatioTechUnitsNum	After modifying dwRatioTechUnitsDenom and iRatioTechUnitsNum to non-zero values, re- execute the function block.
0x00005B	SML_CGR_AXIS_POWERED	Cannot change gear ratio parameter at the wrong state.	After making the axis state goes into Disable, re- execute the function block.
0x00005D	SML_CGR_MODULOPERIOD_NOT_INTEGRAL	Module period is not an integer.	After modifying the fModuloPeriodU parameter, re-execute the function block.
0x00005E	SML_CGR_MOVEMENTTYPE_INVALID	Wrong axis type (Must be either a linear axis or rotary axis).	After modifying the iMovementType parameter, re-execute the function block.
0x00005F	SML_CGR_MODULOPERIOD_NON_POSITIVE	Module period cannot be a negative number.	After modifying the fPositionPeriod parameter, re-execute the function block.
0x000060	SML_CGR_MODULOPERIOD_TOO_SMALL	Module period is too small.	After modifying the fPositionPeriod parameter, re-execute the function block.
0x000061	SML_CGR_MODULOPERIOD_TOO_LARGE	Module period is too large.	After modifying the fPositionPeriod parameter, re-execute the function block.
0x000078	SML_R_NO_ERROR_TO_RESET	No axis error after using MC_Reset_DML	Confirm whether the axis is incorrect, and then re- execute the function block.
0x00007A	SML_R_ERROR_NOT_RESETTABLE	Error, non-resettable.	Confirm whether the Slave error has been eliminated. After error elimination, restart MC_Reset_DML.
0x000083	SML_RP_REQUESTING_ERROR	Slave has no corresponding OD, or reading the OD is not allowed.	The OD you visit does not exist or is not allowed to be accessed. Confirm the input OD is correct and can be read.
0x000084	SML_RP_RCV_PARAM_CONVERSION_ERROR	Conversion error of the axis parameter to servo OD. Unknown SoftMotionLight parameter.	The parameter you visit does not exist.
0x00008D	SML_WP_SENDING_ERROR	Slave has no corresponding OD, or writing the OD is not allowed.	The OD you visit does not exist or is not allowed to be written. Confirm the input OD is correct and can be written.

Error code	Description	Contents	Corrective Action
0x00008E	SML_WP_TMT_PARAM_CONVERSION_ERROR	Conversion error of the axis parameter to servo OD. Unknown SoftMotionLight parameter.	The written parameter does not exist.
0x0000AA	SML_H_AXIS_WASNT_STANDSTILL	Axis is not at the Standstill state.	Make axis enter the Standstill state, and re- execute the function block.
0x0000B7	SML_MS_AXIS_IN_ERRORSTOP	Driver is at the Errorstop state. Cannot execute MC_Stop_DML.	Make axis leave the ErrorStop state, and re- execute the function block.
0x0186A0	DML_MA_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.
0x0186A1	DML_MA_AXIS_NOT_READY_FOR_MOTION	The axis state cannot execute motion control instructions.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186A2	DML_MA_INVALID_VALUES	The input parameter is invalid setting value.	Confirm the pin input parameter value. After the confirmation, re-execute the function block.
0x0186A4	DML_MA_AXIS_NOT_SUPPORT_PP_MODE	Slave does not support the PP mode.	The current selected slave does not support Profile Position Mode. Please use another model.
0x0186AA	DML_MR_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.
0x0186AB	DML_MR_AXIS_NOT_READY_FOR_MOTION	The motion FB cannot be executed under the current axis state.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186AC	DML_MR_INVALID_VALUES	The input parameter is invalid setting value.	Confirm pin input parameter value. Re- execute the FB after modification.
0x0186AE	DML_MR_AXIS_NOT_SUPPORT_PP_MODE	Slave does not support the PP mode.	The current selected slave does not support Profile Position Mode. Please use another model.
0x0186B4	DML_MV_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.

Error code	Description	Contents	Corrective Action
0x0186B5	DML_MV_AXIS_NOT_READY_FOR_MOTION	The axis state cannot execute motion control instructions.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186B6	DML_MV_INVALID_VALUES	The input parameter is invalid setting value.	Confirm pin input parameter value. Re- execute the FB after modification.
0x0186B8	DML_MV_AXIS_NOT_SUPPORT_PV_MODE	Slave does not support the PV mode.	The current selected slave does not support Profile Velocity Mode. Please use another model.
0x0186BE	DML_TC_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.
0x0186BF	DML_TC_AXIS_NOT_READY_FOR_MOTION	The axis state cannot execute motion control instructions.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186C0	DML_TC_INVALID_VALUES	The input parameter is invalid setting value.	Confirm pin input parameter value. Re- execute the FB after modification.
0x0186C2	DML_TC_AXIS_NOT_SUPPORT_PT_MODE	Slave does not support the PT mode.	The current selected slave does not support Profile Torque Mode. Please use another model.
0x0186C8	DML_VC_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.
0x0186C9	DML_VC_AXIS_NOT_READY_FOR_MOTION	The axis state cannot execute motion control instructions.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186CA	DML_VC_INVALID_VALUES	The input parameter is invalid setting value.	Confirm pin input parameter value. Re- execute the FB after modification.
0x0186CC	DML_VC_AXIS_NOT_SUPPORT_VL_MODE	Slave does not support the VL mode.	The current selected slave does not support Velocity Mode. Please use another model.
0x0186D2	DML_HA_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.

Error code	Description	Contents	Corrective Action
0x0186D3	DML_HA_AXIS_NOT_READY_FOR_MOTION	The axis state cannot execute motion control instructions.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186D4	DML_HA_INVALID_VALUES	The input parameter is invalid setting value.	Confirm pin input parameter value. Re- execute the FB after modification.
0x0186D6	DML_HA_AXIS_NOT_SUPPORT_PV_MODE	Slave does not support the PV mode.	The current selected slave does not support Profile Velocity Mode. Please use another model.
0x0186DC	DML_MS_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.
0x0186DD	DML_MS_AXIS_NOT_READY_FOR_MOTION	The axis state cannot execute motion control instructions.	After confirming the axis at the state that can execute motion instructions, re- execute the function block.
0x0186EA	DML_H_AXIS_NOT_SUPPORT_HM_MODE	Slave does not support the HM mode.	The current selected slave does not support Homing Mode. Please use another model.
0x0186F0	DML_R_SDO_RW_FAIL	SDO read & write failed.	Reply to the slave communication, confirm the pin input parameter value meets the definition range of slave Object, and then re-execute the function block.

A.4 Explanation of DMC_Home_P

DFB_Home_P provides many homing modes from which user can choose the appropriate one in accordance with the field condition and technical requirement.

- Mode 1: Homing which depends on the negative limit switch and Z pulse.
- Circumstance 1 : MC_Home instruction is executed when the negative limit switch is OFF and the axis moves in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed when the axis encounters that the negative limit switch is ON. Where the first Z pulse is met is the home position when the negative limit switch is OFF.
- Circumstance 2 : MC_Home instruction is executed when the negative limit switch is ON and the axis moves in the positive direction at the second-phase speed. Where the first Z pulse is met is the home position when the negative limit switch is OFF.



- Mode 2: Homing which depends on the positive limit switch and Z pulse
- Circumstance 1 : MC_Home instruction is executed when the positive limit switch is OFF and the axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed when the axis encounters that the positive limit switch is ON. Where the first Z pulse is met is the home position while the positive limit switch is OFF.
- Circumstance 2 : MC_Home instruction is executed when the positive limit switch is ON and the axis moves in the negative direction at the second-phase speed. Where the first Z pulse is met is the home position while the positive limit switch is OFF.



• Mode 3: Homing which depends on the home switch and Z pulse

- Circumstance 1 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed. When the axis encounters that the home switch is ON, the motion direction changes and the axis moves at the second-phase speed. Where the first Z pulse is met is the home position when the home switch is OFF.
- Circumstance 2 : When the home switch is ON, MC_Home instruction is executed and the axis directly moves in the negative direction at the second-phase speed. Where the first Z pulse is met is the home position while the home switch is OFF.



• Mode 4: Homing which depends on the home switch and Z pulse

Circumstance 1 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed. The axis moves at the second-phase speed when the axis encounters that the home switch is ON. Where the first Z pulse is met is the home position.

Circumstance 2: When the home switch is ON, MC_Home instruction is executed and the axis moves in the negative direction at the second-phase speed. When the axis encounters that the home switch is OFF, the motion direction changes and the axis moves at the second-phase speed. Where the first Z pulse is met is the home position.



- Mode 5 : Homing which depends on the home switch and Z pulse
- Circumstance 1 : When the home switch is ON, MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed. Where the first Z pulse is met is the home position while the home switch is OFF.
- Circumstance 2 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the negative direction at the first-phase speed. When the home switch is ON, the motion direction changes and the axis moves at the second-phase speed. Where the first Z pulse is met is the home position when the home switch is OFF.



• Mode 6: Homing which depends on the home switch and Z pulse

- Circumstance 1 : When the home switch is ON, MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed. When the home switch is OFF, the motion direction changes and the axis moves at the second-phase speed. Where the first Z pulse is met is the home position.
- Circumstance 2 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the negative direction at the first-phase speed. While the home switch is ON, the axis moves at the second-phase speed and where the first Z pulse is met is the home position.



• Mode 7: Homing which depending on the home switch, positive limit switch and Z pulse

- Circumstance 1 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is ON. Where the first Z pulse is met is the home position when the home switch is OFF.
- Circumstance 2 : When the home switch is ON, MC_Home instruction is executed and the axis moves in the negative direction at the second-phase speed. Where the first Z pulse is met is the home position when the home switch is OFF.
- Circumstance 3 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. The axis starts to move at the second-phase speed when the home switch is ON. Where the first Z pulse is met is the home position when the home switch is OFF.



• Mode 8: Homing depending on the home switch, positive limit switch and Z pulse.

Circumstance 1 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed. The axis moves at the second-phase

speed when the home switch is ON and where the first Z pulse is met is the home position.

- Circumstance 2 : MC_Home instruction is executed and the axis moves in the negative direction at the second-phase speed when the home switch is ON. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. And where the first Z pulse is met is the home position.
- Circumstance 3 : When the home switch is OFF, MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. The axis still moves at the first-phase speed when the home switch is ON. The motion direction changes and the axis moves at the first-phase speed when the home switch is ON. The switch is OFF. The axis moves at the second-phase speed and where the first Z pulse is met is the home position when the home switch is ON.



• Mode 9: Homing depending on the home switch, positive limit switch and Z pulse

- Circumstance 1 : MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed when the home switch is OFF. The axis moves at the second-phase speed when the home switch is ON. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. And where the first Z pulse is met is the home position.
- Circumstance 2 : When the home switch is ON MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. And where the first Z pulse is met is the home position.
- Circumstance 3 : MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed when the home switch is OFF. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. The axis moves at the second-phase speed and where the first Z pulse is met is the home position when the home switch is ON.



• Mode 10: Homing depending on the home switch, positive limit switch and Z pulse.

Circumstance 1 : MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed when the home switch is OFF. The axis moves at the second-phase speed when the home switch is OFF. The axis moves at the home position while the home switch is OFF.

- Circumstance 2 : MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed when the home switch is ON. And where the first Z pulse is met is the home position while the home switch is OFF.
- Circumstance 3 : MC_Home instruction is executed and the axis moves in the positive direction at the first-phase speed when the home switch is OFF. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. The motion direction changes again and the axis moves at the second-phase speed when the home switch is ON. Where the first Z pulse is met is the home position while the home switch is OFF.



Mode 11~ mode 14 Homing which depends on the home switch, negative limit switch and Z pulse

- Mode 11:
- Circumstance 1 : MC_Home instruction is executed and the axis moves in the negative direction at the firstphase speed when the home switch is OFF. The motion direction changes and the axis moves at the second-phase speed when the home switch is ON. And where the first Z pulse is met is the home position while the home switch is OFF.
- Circumstance 2 : MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed while the home switch is ON. And where the first Z pulse is met is the home position while the home switch is OFF.
- Circumstance 3 : MC_Home instruction is executed and the axis moves in the negative direction at the firstphase speed while the home switch is OFF. The motion direction changes and the axis moves at the first-phase speed while the home switch is OFF and the negative limit switch is ON. The axis moves at the second-phase speed when the home switch is ON. Where the first Z pulse is met is the home position while the home switch is OFF.



• Mode 12: Homing depending on the home switch, negative limit switch and Z pulse

- Circumstance 1 : MC_Home instruction is executed and the axis moves in the negative direction at the firstphase speed when the home switch is OFF. The axis moves at the second-phase speed when the home switch is ON. And where the first Z pulse is met is the home position.
- Circumstance 2 : MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed while the home switch is ON. The motion direction changes and the axis moves at the second-phase speed while the home switch is OFF. And where the first Z pulse is met is the home position.
- Circumstance 3 : MC_Home instruction is executed and the axis moves in the negative direction at the firstphase speed while the home switch is OFF. The motion direction changes and the axis moves at the first-phase speed while the home switch is OFF and the negative limit switch is ON. The axis still moves at the first-phase speed when the home switch is ON. The motion direction changes and the axis moves at the first-phase speed while the home switch is OFF. The axis moves at the second-phase speed while the home switch is ON. And where the first Z pulse is met is the home position.



• Mode 13: Homing depending on the home switch, negative limit switch and Z pulse

- Circumstance 1 : MC_Home instruction is executed and the axis moves in the negative direction at the first-phase speed while the home switch is OFF. The axis moves at the second-phase speed while the home switch is ON. The motion direction changes and the axis moves at the second-phase speed while the home switch is OFF. And where the first Z pulse is met is the home position.
- Circumstance 2 : MC_Home instruction is executed and the axis moves in the negative direction at the second-phase speed while the home switch is ON. The motion direction changes and the axis moves at the second-phase speed while the home switch is OFF. And where the first Z pulse is met is the home position.
- Circumstance 3 : MC_Home instruction is executed and the axis moves in the negative direction at the first-phase speed while the home switch is OFF. The motion direction changes and the axis moves at the first-phase speed while the home switch is OFF and the negative limit switch is ON. The axis moves at the second-phase speed and where the first Z pulse is met is the home position when the home switch is ON and the negative limit switch is OFF.



- Mode 14: Homing depending on the home switch, negative limit switch and Z pulse
- Circumstance 1 : MC_Home instruction is executed and the axis moves in the negative direction at the firstphase speed while the home switch is OFF. The axis moves at the second-phase speed once the home switch is ON. And where the first Z pulse is met is the home position while the home switch is OFF.
- Circumstance 2 : MC_Home instruction is executed and the axis moves in the negative direction at the second-phase speed while the home switch is ON. Where the first Z pulse is met is the home position while the home switch is OFF.
- Circumstance 3 : MC_Home instruction is executed and the axis moves in the negative direction at the firstphase speed while the home switch is OFF. The motion direction changes and the axis moves at the first-phase speed while the home switch is OFF and the negative limit switch is ON. The motion direction changes again and the axis moves at the secondphase speed when the home switch is ON. Where the first Z pulse is met is the home position while the home switch is OFF.



Mode 15 and mode 16 are reserved for future development.

Mode 17~mode 30 Homing which has nothing to do with Z pulse

In mode 17~mode 30 which are respectively similar to mode1~mode 14 mentioned previously, the axis has nothing to do with Z pulse but the relevant home switch and limit switch status while returning to the home position.

- Mode 17: Homing which depends on the negative limit switch, similar to mode 1, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed when the negative limit switch is OFF and the axis moves in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed when the axis encounters that the negative limit switch is ON. Where the servo is when the negative limit switch is OFF is the home position.
- Circumstance 2 : MC_Home instruction is executed when the negative limit switch is ON and the axis moves in the positive direction at the second-phase speed. Where the servo is the home position when the negative limit switch is OFF.



- Mode 18: Homing which depends on the positive limit switch, similar to mode 2, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed when the positive limit switch is OFF and the axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed when the axis encounters that the positive limit switch is ON. Where the servo is the home position while the positive limit switch is OFF.
- Circumstance 2 : MC_Home instruction is executed when the positive limit switch is ON and the axis moves in the negative direction at the second-phase speed. Where the servo is the home position while the positive limit switch is OFF.



- Mode 19: Homing which depends on the home switch, similar to mode 3, but has nothing to do
 with Z pulse.
- Circumstance 1 : MC_Home instruction is executed and the axis moves in the positive direction at the firstphase speed while the home switch is OFF. The motion direction changes and the axis moves at the second-phase speed once the home switch becomes ON. And where the axis stands is the home position at the moment the home switch becomes OFF.
- Circumstance 2 : MC_Home instruction is executed and the axis directly moves in the negative direction at the second-phase speed while the home switch is ON. And where the axis stands is the home position at the moment when the home switch becomes OFF.



- Mode 20: Homing which depends on the home switch, similar to mode 4, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed when the home switch is OFF and the axis moves in the positive direction at the first-phase speed. Where the servo is the home position when the home switch is ON.
- Circumstance 2 : MC_Home instruction is executed when the home switch is ON and the axis moves in the negative direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch becomes OFF. Where the servo is the home position when the home switch is ON.

Œ		
Circumstances 1	Start Position	Stop Position
Circumstances 2		Stop Position Positive Direction
Homeswitch		

- Mode 21: Homing which depends on the home switch, similar to mode 5, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed and the axis moves in the positive direction at the second-phase speed while the home switch is ON. And where the axis stands is the home position at the moment the home switch becomes OFF.
- Circumstance 2 : MC_Home instruction is executed and the axis moves in the negative direction at the first-phase speed while the home switch is OFF. The motion direction changes and the axis moves at the second-phase speed once the home switch becomes ON. And where the axis stands is the home position at the moment the home switch becomes OFF.



- Mode 22: Homing which depends on the home switch, similar to mode 6, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed while the home switch is ON and the axis moves in the positive direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed once the home switch becomes OFF. Where the axis stands is the home position when the home switch is ON.
- Circumstance 2 : MC_Home instruction is executed while the home switch is OFF and the axis moves in the negative direction at the first-phase speed. Where the axis stands is the home position when the home switch becomes ON.

	[
Circumstances 1	Start Position Stop Position Negative Direction 2	
Circumstances 2	Stop Pos ition	Start Position
	Home switch	

- Mode 23: Homing which depends on the home switch and positive limit switch, similar to mode 7, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed once the home switch becomes ON. Where the axis stands is the home position when the home switch is OFF.
- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the negative direction at the second-phase speed. And where the axis stands is the home position when the home switch becomes OFF.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. When the home switch is ON, the axis starts to move at the second-phase speed. Where the axis stands is the home position when the home switch is OFF.

Circumstances 1	Start Position Stop Position Negative Direction 23	
Circumstances 2	Stop Position Negative Direction 🚽 🕺 Start Position	
Circumstances 3	Stop Position Position Negative Direction 4	
Hor	meswitch	
Positive li	mitswitch	

• Mode 24: Homing which depends on the home switch and positive limit switch, similar to mode 8, but has nothing to do with Z pulse.

Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move in the positive direction at the first-phase speed. Where the axis stands is the home position when the home switch is ON.

Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the negative direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. Where the axis stands

is the home position when the home switch is ON.

Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. When the home switch is ON, the axis still moves at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.



- Mode 25: Homing which depends on the home switch and positive limit switch, similar to mode 9, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move in the positive direction at the first-phase speed. The axis moves at the second-phase speed when the home switch is ON. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.
- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the positive direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. Where the axis stands is the home position when the home switch is ON.



- Mode 26: Homing which depends on the home switch and positive limit switch, similar to mode 10, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move in the positive direction at the first-phase speed. The axis moves at the second-phase speed when the home switch is ON. Where the axis stands is the home position when the home switch is OFF.
- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the positive direction at the second-phase speed. Where the axis stands is the home position when the home switch is OFF.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the positive direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the positive limit switch is ON. The motion direction changes again and the axis moves at the second-phase speed when the home switch is ON. Where the axis stands is the home position when the home switch is OFF.



• Mode 27: Homing which depends on the home switch and negative limit switch, similar to mode 11, but has nothing to do with Z pulse.

- Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is ON. Where the axis stands is the home position when the home switch is OFF.
- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the positive direction at the second-phase speed. Where the axis stands is the home position when the home switch is OFF.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the negative limit switch is ON. When the home switch is ON, the axis starts to move at the second-phase speed. Where the axis stands is the home position when the home switch is OFF.



• Mode 28: Homing which depends on the home switch and negative limit switch, similar to mode 12, but has nothing to do with Z pulse.

- Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move in the negative direction at the first-phase speed. Where the axis stands is the home position when the home switch is ON.
- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the positive direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the negative limit switch is ON. When the home switch is ON, the axis still moves at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.



- Mode 29: Homing which depends on the home switch and negative limit switch, similar to mode 13, but has nothing to do with Z pulse.
- Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move in the negative direction at the first-phase speed. When the home switch is ON, the axis starts to move at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.
- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the negative direction at the second-phase speed. The motion direction changes and the axis moves at the second-phase speed when the home switch is OFF. Where the axis stands is the home position when the home switch is ON.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the negative limit switch is ON. Where the axis stands is the home position when the home switch is ON.



 Mode 30: Homing which depends on the home switch and negative limit switch, similar to mode 14, but has nothing to do with Z pulse.

Circumstance 1 : MC_Home instruction is executed while the home switch is OFF and the axis starts to move

in the negative direction at the first-phase speed. When the home switch is ON, the axis starts to move at the second-phase speed. Where the axis stands is the home position when the home switch is OFF.

- Circumstance 2 : MC_Home instruction is executed while the home switch is ON and the axis moves in the negative direction at the second-phase speed. Where the axis stands is the home position when the home switch is OFF.
- Circumstance 3 : MC_Home instruction is executed while the home switch is OFF. The axis moves in the negative direction at the first-phase speed. The motion direction changes and the axis moves at the first-phase speed when the home switch is OFF and the negative limit switch is ON. When the home switch is ON, the motion direction changes again and the axis moves at the second-phase speed. Where the axis stands is the home position when the home switch is OFF



Mode 31 and mode 32: Reserved

Mode 31 and mode 32 Reserved for future development.

Mode 33 ~ mode 34 Homing which only depends on Z pulse

• Mode 33: Homing depending on Z pulse (Negative direction)

MC_Home instruction is executed and the axis moves at the second-phase speed in the negative direction. And the place where the axis stands is the home position once the first Z pulse is met.



• Mode 34: Homing depending on Z pulse (Positive direction)

MC_Home instruction is executed and the axis moves at the second-phase speed in the positive direction. And the place where the axis stands is the home position once the first Z pulse is met.



• Mode 35: Homing which depends on the current position

MC_Home instruction is executed, the axis does not move and its current position is regarded as the home position.


Industrial Automation Headquarters

Delta Electronics, Inc. Taoyuan Technology Center No.18, Xinglong Rd., Taoyuan District, Taoyuan City 33068, Taiwan TEL: 886-3-362-6301 / FAX: 886-3-371-6301

Asia

Delta Electronics (Shanghai) Co., Ltd.

No.182 Minyu Rd., Pudong Shanghai, P.R.C. Post code : 201209 TEL: 86-21-6872-3988 / FAX: 86-21-6872-3996 Customer Service: 400-820-9595

Delta Electronics (Japan), Inc.

Tokyo Office Industrial Automation Sales Department 2-1-14 Shibadaimon, Minato-ku Tokyo, Japan 105-0012 TEL: 81-3-5733-1155 / FAX: 81-3-5733-1255

Delta Electronics (Korea), Inc.

Seoul Office 1511, 219, Gasan Digital 1-Ro., Geumcheon-gu, Seoul, 08501 South Korea TEL: 82-2-515-5305 / FAX: 82-2-515-5302

Delta Energy Systems (Singapore) Pte Ltd.

4 Kaki Bukit Avenue 1, #05-04, Singapore 417939 TEL: 65-6747-5155 / FAX: 65-6744-9228

Delta Electronics (India) Pvt. Ltd.

Plot No.43, Sector 35, HSIIDC Gurgaon, PIN 122001, Haryana, India TEL: 91-124-4874900 / FAX : 91-124-4874945

Delta Electronics (Thailand) PCL.

909 Soi 9, Moo 4, Bangpoo Industrial Estate (E.P.Z), Pattana 1 Rd., T.Phraksa, A.Muang, Samutprakarn 10280, Thailand TEL: 66-2709-2800 / FAX : 662-709-2827

Delta Electronics (Australia) Pty Ltd. Unit 20-21/45 Normanby Rd., Notting Hill Vic 3168, Australia

TEL: 61-3-9543-3720

Americas

Delta Electronics (Americas) Ltd. Raleigh Office P.O. Box 12173, 5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3813 / FAX: 1-919-767-3969

Delta Electronics Brazil

São Paulo Sales Office Rua Itapeva, 26 - 3°, andar Edificio Itapeva, One - Bela Vista 01332-000 - São Paulo - SP - Brazil TEL: 55-12-3932-2300 / FAX: 55-12-3932-237

Delta Electronics International Mexico S.A. de C.V.

Mexico Office Gustavo Baz No. 309 Edificio E PB 103 Colonia La Loma, CP 54060 Tlalnepantla, Estado de México TEL: 52-55-3603-9200

EMEA

Headquarters: Delta Electronics (Netherlands) B.V.

Sales: Sales.IA.EMEA@deltaww.com Marketing: Marketing.IA.EMEA@deltaww.com Technical Support: iatechnicalsupport@deltaww.com Customer Support: Customer-Support@deltaww.com Service: Service.IA.emea@deltaww.com TEL: +31(0)40 800 3900

BENELUX: Delta Electronics (Netherlands) B.V.

De Witbogt 20,5652 AG Eindhoven, The Netherlands Mail: Sales.IA.Benelux@deltaww.com TEL: +31(0)40 800 3900

DACH: Delta Electronics (Netherlands) B.V.

Coesterweg 45, D-59494 Soest, Germany Mail: Sales.IA.DACH@deltaww.com TEL: +49(0)2921 987 0

France: Delta Electronics (France) S.A.

ZI du bois Challand 2,15 rue des Pyrénées, Lisses, 91090 Evry Cedex, France Mail: Sales.IA.FR@deltaww.com TEL: +33(0)1 69 77 82 60

Iberia: Delta Electronics Solutions (Spain) S.L.U

Ctra. De Villaverde a Vallecas, 265 1º Dcha Ed. Hormigueras – P.I. de Vallecas 28031 Madrid TEL: +34(0)91 223 74 20

Carrer Llacuna 166, 08018 Barcelona, Spain Mail: Sales.IA.Iberia@deltaww.com

Italy: Delta Electronics (Italy) S.r.l.

Via Meda 2–22060 Novedrate(CO) Piazza Grazioli 18 00186 Roma Italy Mail: Sales.IA.Italy@deltaww.com TEL: +39 039 8900365

Russia: Delta Energy System LLC

Vereyskaya Plaza II, office 112 Vereyskaya str. 17 121357 Moscow Russia Mail: Sales.IA.RU@deltaww.com TEL: +7 495 644 3240

Turkey: Delta Greentech Elektronik San. Ltd. Sti. (Turkey)

Şerifali Mah. Hendem Cad. Kule Sok. No:16-A 34775 Ümraniye – İstanbul Mail: Sales.IA.Turkey@deltaww.com TEL: + 90 216 499 9910

GCC: Delta Energy Systems AG (Dubai BR)

P.O. Box 185668, Gate 7, 3rd Floor, Hamarain Centre Dubai, United Arab Emirates Mail: Sales.IA.MEA@deltaww.com TEL: +971(0)4 2690148

Egypt + North Africa: Delta Electronics

Unit 318, 3rd Floor, Trivium Business Complex, North 90 street, New Cairo, Cairo, Egypt Mail: Sales.IA.MEA@deltaww.com

*We reserve the right to change the information in this catalogue without prior notice.