




2008-03-13



5011678000-NM00



DVP-SLIM INSTRUCTION SHEET

安裝說明 安装说明

▲ Digital I/O Extension Unit(Pin Headed)

- ▲ 數位I/O擴充機(排針式)
- ▲ 數字I/O擴展机(排针式)



www.delta.com.tw/industrialautomation

Warning


- ENGLISH:**
- Please read this instruction carefully before use.
 - Switch off the power before wiring.
 - DVP-Slim is an OPEN-TYPE device and therefore should be installed in an enclosure free of airborne dust, humidity, electric shock and vibration. The enclosure should prevent most maintenance staff from operating the device (e.g. key or specific tools are required to open the enclosure). Any damage or damage to the device may occur.
 - DO NOT connect input AC power supply to any of the I/O terminals; otherwise serious damage may occur. Check all the wiring again before switching on the power. DO NOT touch any terminal when the power is switched on.

1 Introduction

■ Model Explanation & Peripherals

Thank you for choosing Delta DVP-Slim series programmable logic controller. DVP-Slim series pin-headed digital I/O extension unit offers 32 points. For DVP-SS/SX/SXSC series MPU, the maximum digital I/O extension points (including the MPU) can reach 128 points. For SV series MPU, the maximum digital I/O extension points (including the MPU) can reach 256 points. In addition, maximum 8 additional special modules (AD/DA/P/T/XA/PU) can be extended to DVP-Slim series extension unit.

■ Product Profile



Unit: mm

■ Model Information

Model name	Power supply	Input Points	Type	Output Points	Type	Dimension (mm)	Outline
DVP32SM11N	24VDC	32	DC Type Sink/Source	0	N/A	25.2 90 60	
DVP32SN11TN	24VDC	0	N/A	32	(NPN) Transistor		

2 Specifications

■ Electrical Specifications

Item	Model	DVP32SM11N	DVP32SN11TN
Power supply voltage	24V DC (-15% ~ 20%) (with DC input polarity reverse protection)		
Motion specification	Within 5ms of the momentary power loss, the device will keep on operating.		
Power consumption	1W	1W	
Insulation resistance	>5 MΩ (all I/O point-to-ground: 500V DC)		
Noise immunity	ESD (IEC 61013-2, IEC 61000-4-2): 8kV Air Discharge EFT (IEC 61013-2, IEC 61000-4-4): Power Line: 2kV, Digital I/O: 1kV, Analog & Communication I/O: 1kV Damped-Oscillatory Wave: Power Line: 1kV, Digital I/O: 1kV RS (IEC 61131-2, IEC 61000-4-3): 26MHz ~ 1GHz, 10V/m		
Earth	The length of grounding wire shall not be less than that of L, N terminal of the power. (When many PLCs are used at the same time, please make sure every PLC is properly grounded.)		
Operation/storage environment	Operation: 0°C ~ 55°C (temperature); 50% ~ 95% (humidity); pollution degree 2 Storage: -25°C ~ 70°C (temperature); 5% ~ 95% (humidity)		
Shock/vibration immunity	IEC 61131-2, IEC 662-6 (TEST Fc) IEC 61131-2 & IEC 68-2-27 (TEST Ea)		
Weight (g)	70g	70g	

■ I/O Point Specifications

Input Point	Output Point	Temp. & Load Current
Input type: DC (SINK or SOURCE)	Output type: Transistor - T (NPN)	
Input current: 24VDC, 5mA	Current spec.: 0.1A-point	
Off → On more than 16.5VDC	Voltage spec.: 5~30 VDC	
On → Off less than 8VDC	Maximum load: 55°C/1.0A (COM), 25°C/2.2A (COM)	
Response time: Approx. 20ms	Response time: Off → On less than 0.1ms On → Off less than 0.3ms	
Circuit isolation / operation instruction: By photocoupler / LED On		

3 Installation & Wiring

■ Terminals of Digital I/O Extension Unit

DVP32SM11N	DVP32SN11TN

■ DVP32SN currently only offers TN (NPN) transistor output.

■ Please be aware of the following PIN wiring methods for DVP32SN to prevent burn-down of the extension unit.

1. PIN19, PIN20, PIN32 and PIN40 can only connected to +24V DC. The 4 points have already been designed as short-circuit with the extension unit; therefore only 1 of the points need to be connected to the power source.
2. PIN17, PIN8, PIN37 and PIN38 can only connected to GND. The 4 points have already been designed as short-circuit with the extension unit; therefore only 1 of the points need to be wired.

■ Connection


Step 1: Screw open the side cover of the extension unit and you will see the connection port.




Step 2: Lift the fixing clip by the screwdriver.



Step 3: Adjust the positioning hole of the MPU and the extension unit and meet the connection port on the MPU with the extension unit to tightly connect the two.



Step 4: Fasten the fixing clip on the extension unit to complete the connection.



■ Installation & Wiring



Install the PLC in an enclosure with sufficient space around it to allow heat dissipation as shown in the figure.

How to Install DPL:

DPL can be secured to a cabinet by using the DIN rail of 35mm in height and 7.5mm in depth. When mounting DPL to DIN rail, be sure to use the end bracket to stop any side-to-side movement of DPL and reduce the chance of wires being loose. A small retaining clip is at the bottom of DPL. To secure DPL to DIN rail, place the clip onto the rail and gently push it up. To remove it, pull the retaining clip down and gently remove DPL from the rail.

Wiring:

1. Use 22-16AWG (1.5mm) single or multiple core wire on I/O wiring terminals. The specification of the terminal is shown in the figure on the left. The PLC terminal screws shall be tightened to 1.95 kg-cm (1.7 in-lbs).
2. DO NOT place the I/O signal wires and power supply wire in the same wiring duct.
3. Use 0.06/0.50 copper wires only.

DO NOT install PLC in an environment with:

- Dust, smoke, metallic debris, corrosive or flammable gas
- High temperature, humidity
- Direct shock and vibration

■ Notes

During the Engineering

1. DO NOT drop tiny metallic conductor into the PLC when screwing and wiring.
2. There should be a margin of more than 50mm between the PLC and other control device and the PLC should be placed away from high voltage wire and power equipments.


Arrangement of I/O Points:

No matter the MPU with how many points you are using, the input point No. of the first connected extension unit has to start from X20 and output point No. from Y20. The connection of MPU and extension units is demonstrated in the figure below.

PLC	Model	Input points	Output points	Input point No.	Output point No.	
		SS/SX/SC	8	4/6	X0 ~ X7	Y0 ~ Y5
EXT1	32SM11N	32	0	X20 ~ X57	-	
EXT2	32SN11TN	0	32	-	Y20 ~ Y57	
EXT3	32SN11TN	0	32	-	Y60 ~ Y77, Y100 ~ Y117	
EXT4	32SM11N	32	0	X60 ~ X77, X100 ~ X117	-	

Input Point Wiring & Specification

The input signal is DC. There are 2 types of DC inputs, SINK and SOURCE. The wirings are as follows



Transistor Output Circuit Wiring:

NPN transistor output



*1: Manual exclusive output uses external circuit and forms an interlock, together with the PLC internal program, to ensure safety protection in case of any unexpected errors.

*2: Zener diode (39V) inside PLC protects the transistor output. When activating an inductive load, we suggest you parallelly connect a reverse diode to the output.

4 Trail Operation

■ POWER Indicator

The "POWER" LED indicator on the front panel of PLC MPU or extension unit will be on (in green) when the PLC is powered. If the MPU is powered but the indicator is not on indicates that the DC power supply of the PLC is abnormal. Please check if the terminal wirings of +24V and 0V are correct. That the "ERROR" LED indicator flashes continuously indicates that the +24V power supply for the PLC is insufficient. That the "LV" indicator on the extension unit is on indicates that the input voltage for the power of the extension unit is insufficient and all outputs from the extension unit will be disabled.

■ Preparation

Before powering, make sure that you have checked if the I/O wiring is correct. You may damage the PLC if AC110V or AC220V is directly supplied to input terminals or the output signal is short-circuited. When the peripheral devices are used to write program into PLC and if the ERROR indicator does not flash, the program you are using is legal and PLC is waiting for RUN instruction from you. You can use HPP to test "Force On/Off" of output contacts.

■ Operation & Test

If the ERROR indicator does not flash, you can give RUN instruction to the peripheral device and the RUN indicator should be continuously on at this time. When PLC is in operation, use HPP to monitor the set value or temporarily saved value in the timer (T), counter (C), and register (D) and force On/Off of output contacts. That the ERROR indicator is on (not flashes) indicates that part of the program exceeds the preset time-out. In this case, you have to check the program and set On/Off of the power again (PLC automatically returns to STOP status at this time).

5 How to identify abnormality of PLC

■ PLC Abnormality

To identify abnormality from the indicators on the panel, please check:

"POWER" Indicator:

When PLC is powered, the POWER LED indicator on the front panel will be on (in green). If the indicator is not on, check if the power supply is normal. If the problem still exists, your PLC is malfunctioned. Please change a new one or send your PLC back to your distributor for repair.

"LV" Indicator:

That the "LV" indicator on the extension unit is on indicates that the input voltage for the power of the extension unit is insufficient and all outputs from the extension unit will be disabled.

Input Indicator:

On/off of input point is indicated by input indicator or by the monitoring function of the device. When the action criteria of the input point are true, this indicator will be on. If abnormality is identified, check if the indicator and input circuit are normal by HPP/WPL/Soft. Use of electronic switch with too much electricity leakage often results in unexpected actions of the input point.

Output Indicator:

On/off of output point is indicated by output indicator. When the output indicator (On/Off) does not correspond to its own load, please be aware of the follows:

1. The output contact may be melted or blocked out of overloading or short-circuited load, which will result in poor contact.
2. If you are suspicious that the output point may execute undesired action, check the output wiring circuit and whether the screw is properly tightened.

■ Regular Check

DVP series PLC does not utilize any disposable components; therefore, you do not need to replace most of the components with new ones. However, if the output relay is used for activating big current load, the life of the contact will be shortened. In this case, you will need to check whether the contact is in permanently "open circuit" or "short circuit" and note that:

1. DO NOT place the PLC under direct sunlight and avoid placing it close to an over-heated object in case the high temperature will affect the functions of the PLC.
2. Clean the airborne dust or metallic particles in the panel on a regular basis.
3. Check regularly that if the wiring and terminals are tightened properly.

Suggestions for Operation

DVP series pin-headed digital extension unit is relatively more sensitive to the temperature in the operation environment; therefore, when using the unit, please note that:

1. The life of I/O points will be shortened if the voltage and the temperature are too high in the external environment.
2. When the external voltage is larger than 24VDC, it is suggested that the output load current be reduced to below 0.1A.
3. Operate the unit in 55°C/1.0A (COM), 25°C/2.2A (COM); otherwise, the life of I/O points will be shortened.

注意事項


- 請在使用之前，詳細閱讀本使用說明書。
- 實施配線時，務必關閉電源。
- 本機為開型(OPENTYPE)機殼，因此使用者使用本機時，必須將之安裝於具防塵、防潮及免於電擊/衝擊等整體之達成危險及損壞。
- 交換輸入電源不可直接接於輸入/出信號端，否則將造成嚴重損壞，因此請在上電之前再次確認電源配線。請勿在上電時短路任何端子。

1 產品簡介

■ 說明及週邊裝置

選購您採用台灣DVP-SLIM系列程式控制器，提供32點排針式數位I/O擴充機、SS/SA/SX/SC系列、含主機最大數位輸入/輸出分別可達128點、SV系列、合主機最大數位輸入/輸出擴充分別可達256點、另備特殊模組(AD/DA/P/T/XA/PU)擴充功能，最多可擴充8台特殊模組。

■ 產品外觀及各部介紹



① 電源、低電壓指示燈	② 機種名稱	③ 插拔機固定扣	④ 輸出端子	⑤ DIN固定扣	⑥ DIN螺栓 (35mm)	尺寸單位: mm
-------------	--------	----------	--------	----------	----------------	----------

2 規格

■ 電氣規格

項目	機種	電源	輸入單元	輸出單元	尺寸 (mm)	外形參考
	DVP32SM11N	24VDC	32	DC Type Sink/Source	0 無	
	DVP32SN11TN	24VDC	0	電晶體(T) NPN Transistor	32	1.5W

3 安裝及配線

■ 複數 I/O 擴充機之端子配置圖


DVP32SM11N	VP32SN11TN	DVP-32SM11N 的前部只供 TN (NPN) 電晶體輸出。
		■ DVP-32SM11N 的前部只供 TN (NPN) 電晶體輸出。
		■ DVP-32SN11TN 前部別注意以下 PIN 腳配線方式，避免燒壞機器： 1. PIN19 ~ PIN20 ~ PIN39 ~ PIN40 只能接+24VDC，接4個點於擴充槽 充電內部已設好短路，故只須接 其中一組即可。
		2. PIN17 ~ PIN18 ~ PIN37 ~ PIN38 只能接 GND，接 4 個點於擴充機 內部已設計為短路，故只須接 其中一組即可。

■ 系统组合

步骤一：利用螺丝起子将擴充側蓋打開，會出現擴充機。 步驟二：再利用螺丝起子將擴充機固定扣往上拉，接口。



步骤三：調整好主機和擴充機的定位孔，並且將主機的擴充連接口與擴充機接合，此時主機與擴充機之間緊密結合。



■ 盤內安裝及配線



DVP 系列 PLC 在安裝時，請裝配於封閉式的控制箱內，其周圍應保持一定之空間（如左圖所示），以確保 PLC 散熱功能正常。

■ DIN 鋁軌之裝置方法：

適合 35mm DIN 槍軌，主機欲掛於鋁軌時，先將主機（或擴充機）下方之固定塑膠片壓入，再將主機（或擴充機）由上方掛上往下壓即刻。欲取下主機時，主機背面下之固定塑膠片，以一字形起子插入凹槽，向上撥開即可。該固定機殼塑膠片為保護殼，因此該固定片斷開後不會彈回去。當所有的固定片斷開後，再將主機往上向外方取出。

■ 配線：

1. 輸出入配線請使用 22-16AWG (1.5mm) 單蕊線裸或多蕊線，端子規格如左所示，PLC 端子螺絲扭力為 1.95 kg-cm (1.7 in-lbs)。
2. 輸入點：多蕊線與輸出點式端子頭請勿共用於同一線槽內或使用同一多蕊之電線裸。
3. 只能使用 60/75°C 的銅導線。

請勿將數位 I/O 擴充機裝置於以下環境中
➤ 激盪大、油煙、金屬性粉塵、腐蝕性或可燃性氣體
➤ 高溫、結露
➤ 直接衝擊、衝擊

■ 注意事項

■ 施工注意：

1. 擬接線及配線時請避免小的金屬體掉入 PLC 內部。
2. PLC 與其之控制元件應保持 50mm 以上之距離，並應遠離高壓線及動力設備。


■ 輸出入點號辨識：

無論使用何種類型的主機連接擴充機，所連接的第一台擴充機，輸入點編號由 X20 依序排列，輸出點編號亦由 Y20 依序排列。若使用所連接的系統如下：


PLC	機種	輸入點數	輸出點數	輸入點編號	輸出點編號	系統組合類別
MPU	SS/SAS/SX/SC	8	4/6	X0 ~ X7	Y0 ~ Y5	
EXT1	32SM11N	32	0	X20 ~ X57	-	
EXT2	32SN11TN	0	32	-	Y20 ~ Y57	
EXT3	32SN11TN	0	32	-	Y60 ~ Y77, Y100 ~ Y117	
EXT4	32SM11N	32	0	X60 ~ X77, X100 ~ X117	-	

■ 輸入點配線及規範：

輸入點之入力信號只有一種：為直流電源 DC 輸入，DC 型式共有兩種接法：SINK 及 SOURCE，其配線如下：



■ 電晶體輸出回路配線：



*1: 利用外部電路形成互鎖，配合 PLC 內部程式，確保任何異常發狀況發生時，均有安全的保護措施。
*2: 若觸動電容性負載時，建議並聯上一個反向電容保護二極體。

4 試運轉

■ 電源指示

主機或擴充機之正面均有一個 POWER 的 LED 指示燈，當主機通上電源時，該指示燈 LED (綠色) 亮，如果主機通上電源時此指示燈不亮，表示 PLC 的直流電源供應有問題，此時請檢查+24V 及 0V 之端子配線是否正確，若發現錯誤 (ERROR) 指示燈 LED 快速閃爍，則表示供應 PLC 電源+24V 不足，擴充機正面另有一指示燈 L.V.

當亮起時，表示擴充機的輸入電源電壓不足，此時擴充機輸出全部禁止。

■ 備準動作

在通上電源前，請務必檢查電線及輸入/輸出配線是否正確，如果將 AC110V 或 AC220V 直接加入輸入端或者是輸出端配線錯亂，將直接造成 PLC 本體的損壞。其點請務必注意，使用變壓器裝置將AC 轉為主機之後，若主機 ERROR 指示燈沒亮，請將變壓器之輸出端子對地短路，表示使用者程式合法，等待進一步由使用者下達 RUN 的命令，可使用 HPP 執行輸出接點強制 On/Off 的測試。

■ 運轉及測試

若當 ERROR 指示燈沒有閃爍，使用遙控裝置下達 RUN 的命令，此時 RUN 指示燈亮起，運轉中可藉由 HPP 來監視計時器 (T)、計數器 (C)、暫存器 (D) 之設定值及暫存值，並可強制輸出點作 On/Off 动作。若 ERROR 指示燈不亮，但不閃爍，表示使用者程式中部分超過預設的延時時間，請使用者重新組成程式，並將電源重新 On/Off 一次，此時 PLC 自動回到 STOP 狀態。

5 異常檢修

■ 當 DVP PLC 發生異常時，請檢查：

■ 電源指示 POWER LED

主機正面均有一個 POWER 之 LED 指示燈，當主機通上電源時 LED 之綠色亮，如果主機通上電源時此指示燈不亮，而且確認電源輸入正常，該指示燈仍不亮，則表示此 PLC 已故障，請更換，並送回原代理商維修。

■ 低電壓指示 L.V LED

擴充機正面另有一個指示燈 L.V 當亮起時，表示擴充機的輸入電源電壓不足，此時擴充機輸出全部禁止。

■ 電壓指示 LED

輸入點信號 On/Off 可由輸入點指示燈之亮/滅來顯示，亦可由變壓器功能叫出輸入點之狀態來監控，當點狀態變為 On/Off 時，該指示燈會亮，因若發現有異常時請利用 HPP/WPL，檢查指示燈號及輸入/信號回路是否正常，尤其當使用者使用偏流很大的電子式開關時，會常造成輸入點有不預期的動作。

■ 輸出點指示 LED

輸出指示燈專門輸出信號之 On/Off，當輸出指示燈 On/Off 而負載卻不同樣動作時請注意下列事項：

1. 輸出點可能因為負載或負載加路而造成接點掉掉而黏住造成接觸不良。

2. 輸出點有不良好動作時請檢查輸出配線回路及螺絲是否鬆緊。

■ 定期檢查

DVP 系列 PLC 並無使用消耗性零件，所以大部分零件不需更換，但是如果輸出晶體使用在驱动大电流负载的話，輸出接點的壽命會減短，請檢查其狀況，是否接點發生永久性的開路或短路，並同時注意下列各項：

1. 請勿將 DVP 置於太陽直射下並避開過熱之物體，以免機器內溫度過高影響性能。

2. 請定期潔面面內空氣灰塵或導電灰塵。

3. 請定期檢查配線及端子是否鬆脫。

■ 操作建議

DVP 系列排針式數位擴充機對工作環境溫度較敏感，使用時應注意如下：

1. 若外部工作溫度高及腳底溫度高時，將造成 I/O 壽命減少。

2. 當外部溫度大於 DC24V 時，建議降低輸出負載電流 0.1A 以下。

3. 結合於過兩端建議，於 55°C/1.0A (COM), 25°C/2.2A (COM) 條件操作下，若超過最大負載額定，將造成 I/O 壽命減少。

2 規格

■ 电气规格

机种	DVP32SM11N	DVP32SN11TN
电源电压	由主机经由内部总线供应 24VDC (-15% ~ 20%) (其直连输入电源极性接反保护)	
动作速度	电涌瞬时断电 5ms 以内连续动作	
消耗电力	1W	1.5W
热阻系数	5 °C/W (以上 (所有输出点对地之间) 500V DC)	
ESD (IEC 61131-2, IEC 61000-4-4) & RFI Air Discharge EFT (IEC 61131-2, IEC 61000-4-4) & Power Line: 2kV, Digital I/O: 1kV Analog & Communication I/O: 1kV Damped-Oscillation Wave: Power Line: 1kV, Digital I/O: 1kV RS (IEC 61131-2, IEC 61000-4-5): 26MHz ~ 1GHz, 10V/m		
接地		
操作/存储环境	操作: -10°C ~ 55°C (湿度: 5 ~ 95%) 清洁等级 2 储存: -25°C ~ 70°C (温度): 5 ~ 95% (湿度)	
振动/冲击		
重量 (约) , (g)	70g	70g

■ 输出输入点规格

输入点电气规格	输出点电气规格	温度与负载曲线图
输入形式 直流 (SINK or SOURCE)	晶体管 T (NPN)	
输入电流 24V DC 5mA	0.1A/点	
动作电压 Off-On 16.5VDC 以上	5 ~ 30V DC	
动作位准 On/Off SVDC 以下	55°C/1.0A (COM), 25°C/2.2A (COM)	
反应时间 约 20ms	OFF~ON 0.1ms 以下	
电路隔离 无	ON~OFF 0.3ms 以下	
操作指示 LED		



(Current COM)

2.2A
1.8A
1.4A
1.0A
0.6A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A

25°C 35°C 45°C 55°C (°C)

1.0A
0.6A
0.2A
0.1A