

DVS Series Managed Industrial Rack Mount Ethernet Switch





Instruction Sheet

✓ This instruction sheet only provides information on electrical specifications and general specifications.

Please refer to the DELTA Industrial Ethernet Hardware Installation Guide for more detail information.

Managed Industrial Ethernet Switches

- Delta DVS series Managed Industrial Rack Mount Ethernet Switch
- Protective Caps for unused RJ45 ports and fiber ports (inserted to the switch)
- USB Type A to Type B console cable
- User manual and software CD
- Instruction Sheet
- Rack bracket*4
- M4 screw*20
- M5 screws*6
- T4 screw*6 and anchor screw*6
- Rubber feet*4
- Rubber Plug*16(Inserted to the switch)

Input Voltage

Operating Voltage

- PWR1:100-240V_{AC}
- (85-264V_{AC}, 88-370V_{DC})
- PWR2/PWR3:36-60V_{DC}(36-72V_{DC})

Mechanical Characteristics

- Case
 - IP40 metal case
- Dimension(mm)
 - 43.66(H)x482.6(W)x275(D)
- Weight(g)
- 5360

Ethernet interface connection definition				
	10/100Base-T(X)		1000Base-T	
PIN	MDI Mode	MDI-X Mode	MDI/MDI-X Mode	8-PIN RJ45
1	Tx+	Rx+	TP0+	
2	Tx-	Rx-	TP0-	
3	Rx+	Tx+	TP1+	
4	n.c.	n.c.	TP2+	
5	n.c.	n.c.	TP2-	
6	Rx-	Tx-	TP1-	
7	n.c.	n.c.	TP3+	
8	n.c.	n.c.	TP3-	

100/1000Base-SFP Fiber Connection				